



POWERLOGY

USER MANUAL



10000mAh
QUICK CHARGING
POWER BANK

PPBCHA14

- LED display
- Button
- USB QC3.0 18W Output
- USB QC3.0 18W Output
- Micro USB Input
- Type-C PD Input & Output

Product specifications

- Capacity: 10000mAh/ 37Wh
- Battery type: 10000mAh Li-polymer x1 piece
- Type-C input: PD18W- (DC 5V/3A,9V/2A,12V/1.5A)
- Micro USB Input: 10.5W 5V/2.1A
- Type-C output: PD20W- (DC 5V/3A,9V/2.22A,12V/1.67A)
- USB1&2 output: QC3.0 (DC 5V-6.5V3A,6.5V-9V2A,9V-12V1.5A)
- Total output: DC 5V/3A MAX.
- Dimension: 150*70*15.5MM
- Weight: about 235g

Features

- 4 LED Indicators
- Rubberized coating
- High transfer efficiency
- Li-polymer battery cell with high safety and stability
- Low self-discharge; Long time standby
- High compatibility fits for different mobile phones
- Intelligent protect program to avoid overcharging/ discharging, short circuit, etc.
- Compact design, easy operation
- Accessory: 30cm Type-C to USBA fast charging cable

Usage

Recharge your power bank:
To recharge your power bank, using the Micro USB or Type-C cable to connect it to a computer, car-charger or wall-charger and then the power bank would get charged automatically,when charging, the number indicator will flash, indicating remaining power.

Charge your device:
Using your device's charging cable (not included), connect your device to the USB outputs or Type-C output,the power bank will start charging your device automatically, the LCD display will indicate your power bank's remaining charge. After finished the charging you can press the button for twice to turn it off or it would be turned off automatically without working after 35 seconds.

Warnings

- Never leave a charging battery unattended.
- Do not expose the power bank to excess humidity or liquids. It should be stored in a cool, dry place when not in use.
- Do not damage or puncture the casing of the power bank. This may cause over-heating,fire or an explosion.
- Do not expose the power bank to sources of heat, including radiators, stoves, or fires. Do not expose to ambient temperatures above 40°C, such as in a car on hot day, or in direct sunlight. Failure to do so may cause over-heating, fire, or explosion.

- Do not use in a strong electrostatic or electromagnetic environment, including near microwaves as this may shorten the device's life.
- If the power bank emits an odour, excessive heat or becomes discoloured or distorted, please discontinue use immediately.
- Refer all servicing to qualified service personnel, which is required if power bank is damaged in any way,is exposed to liquid or does not operate normally. Please do not attempt to service or open the device.This may cause over-heating, fire or an explosion.
- At the end of the device's life, please dispose of this product at a battery recycling station. It is not suitable for domestic waste disposal.
- If a new power bank is not used for a period of three months or more, its battery capacity will be reduced, but will restore to normal capacity after 3-4 charge and discharge cycles.

For more information, please contact our support team:
support@teqtronixme.com

Designed and produced by Teqtronix international Inc.
All rights reserved 2023.
Made in China







hey@powerology.me | www.powerology.me
 f powerology i powerology.me

v. قم بإزالة جميع أعمال الصيانة إلى موظفي الخدمة المؤهلين، و هو مطلوب في حالة تلف تلك الطبقة بأي شكل من الأشكال، أو تعرضه للسوائل أو لا يعمل سطح طبيعي. يرجى عدم محاولة صيانة الجهاز أو فتحه، فقد يسبب ذلك في زيادة السخونة أو حدوث انفجار أو حدوث انفجار.

٨. في نهاية عمر الجهاز، التخلص من هذا المنتج في محطة إعادة التدوير المناسبة، أنها ليست مناسبة للتخلص من النفايات المنزلية.

٩. إذا لم يتم استخدام طابعة جديد لمدة ثلاثة أشهر أو أكثر، فسيتم تشغيل سرعة البطارية، ولكنها تستعيد سعتها الطبيعية بعد ٤٠-٤٠ ساعات شحن وتبريد.

لمزيد من المعلومات ، يرجى الاتصال بفريق الدعم لدينا:
support@teqtronixme.com
تصميم وإنتاج شركة تيكترونيكس إلكترونيات.
جميع الحقوق محفوظة ٢٠٢٣.
منع بالعين

hey@powerology.me | www.powerology.me
 f powerology i powerology.me

استعمال

أعد شحن بنك الطاقة الخاص بك:

إعادة شحن بنك الطاقة الخاص بك، استخدم كابل مايكرو يو إس بي أو تابلت-سي لتوصيله بجهاز كمبيوتر أو شاحن سيارة أو شاحن حائط ومن ثم سحب بنك الطاقة.

يتم شحنه تلقائياً، مع الشحن، سيؤدي مؤشر الأرقام إلى زيادة الطاقة المتبقية.

اشحن جهازك:
 باستخدام كابل الشحن الخاص بجهازك (غير مضمن) ، قم بتوصيل جهازك
 بمخرج يو إس بي أو تايب-سى.
 الإخراج ، سيبدأ بك الطاقة في شحن جهازك تلقائياً ، وستشير شاشة LCD
 إلى الشحن المتبقي لك الطاقة الخاص بك. بعد الانتهاء من الشحن ،
 يمكنك الضغط على الزر مرتين لتبليغ تشغيله أو سيتم إيقاف تشغيله
 تلقائياً دون العمل بعد ٣٥ ثانية.

1. لا تترك بطارية شحن بدون رقابة.
2. لا تعرض نيك البطاقة للاضواء في أماكن غير آمنة.
3. مكان بارد وجاف عندما لا تكون قيد الاستعمال.
4. لا تتلف في كتف غلاف نيك البطاقة. قد يتسبب ذلك في ارتفاع درجة الحرارة أو حدوث انفجار.
5. لا تعرض نيك البطاقة لمصادر الحرارة، بما في ذلك المشعات، والمواقد أو النيران.
6. لا تعرض لحدوث حادثة حريق لمدة ٤٠ دقيقة متوالية، كما هو الحال في السيارة في يوم حار أو في ضوء الشمس المباشرة. قد يؤدي عدم القيام بذلك إلى ارتفاع درجة الحرارة أو حدوث انفجار أو حدوث انفجار.
7. استخدم في بيئة إلكتروستاتيكية أو خوروفعناطيسية قوية، بما في ذلك الموجات الدقيقة القريبة لك أو هوائيات أو أجهزة نقل الطاقة.
8. لا ابتلع من نيك البطاقة رائحة أو حرارة رائحة أو تغير لونها أو تشوهات في التغليف عند استخدامه في المنزل.

Usage

Recharge your power bank:
To recharge your power bank, using the Micro USB or Type-C cable to connect it to a computer, car-charger or wall-charger and then the power bank would get charged automatically,when charging, the number indicator will flash, indicating remaining power.

Charge your device:
Using your device's charging cable (not included), connect your device to the USB outputs or Type-C output, the power bank will start charging your device automatically, the LCD display will indicate your power bank's remaining charge. After finished the charging you can press the button for twice to turn it off or it would be turned off automatically without working after 35 seconds.

Warnings

1. Never leave a charging battery unattended.
2. Do not expose the power bank to excess humidity or liquids. It should be stored in a cool, dry place when not in use.
3. Do not damage or puncture the casing of the power bank. This may cause over-heating, fire or an explosion.
4. Do not expose the power bank to sources of heat, including radiators, stoves, or fires. Do not expose to ambient temperatures above 40°C, such as in a car on hot day, or in direct sunlight. Failure to do so may cause over-heating, fire, or explosion.

5. Do not use in a strong electrostatic or electromagnetic environment, including near microwaves as this may shorten the device's life.
6. If the power bank emits an odour, excessive heat or becomes discoloured or distorted, please discontinue use immediately.
7. Refer all servicing to qualified service personnel, which is required if power bank is damaged in any way, is exposed to liquid or does not operate normally. Please do not attempt to service or open the device. This may cause over-heating, fire or an explosion.
8. At the end of the device's life, please dispose of this product at a battery recycling station. It is not suitable for domestic waste disposal.
9. If a new power bank is not used for a period of three months or more, its battery capacity will be reduced, but will restore to normal capacity after 3-4 charge and discharge cycles.

For more information, please contact our support team:
support@teqtronixme.com

Designed and produced by Teqtronix international Inc.
All rights reserved 2023.
Made in China

hey@powerology.me | www.powerology.me
 f powerology i powerology.me

۱. شاشة LED
۲. زر
۳. إخراج يو اس بي ١٨ وات
۴. إخراج يو اس بي ١ وات
۵. إدخال يو اس بي الصغير
٦. إدخال وإخراج بي دي تايب سي

- الساعة: ١٠٠٠ ملي أمبير / ٣٧ وات في الساعة
- نوع البطارية: ١٠٠٠ ملي أمبير ليثيوم بوليمر xl قطعة
- إدخال تايپ-سي : بي دي ١٨ وات
- (تيار مستمر ٥ فولت / ٣ أمبير، ٩ فولت / ٢ أمبير، ١٢ فولت / ١,٥ أمبير)
- مدخل مايكرو يو أس بي: ١,٥ وات ٥ فولت / ٢,١ أمبير
- خرج تايپ-سي : بي دي ١,٥ وات (تيار مستمر ٥ فولت / ٣ أمبير، ٩ فولت / ٢,٢٢ أمبير، ١٢ فولت / ١,٧٧ أمبير)
- خرج يو أس بي ١ & ٢: تيار مستمر فولت- ٦,٥ فولت ٣ أمبير، ٩ فولت- ٢,٢٢ فولت ١,٥ أمبير
- إجمالي الإخراج: تيار مستمر ٥ فولت / ٣ أمبير كحد أقصى.
- البعد: ١٥٠ × ٧٠ × ١٥ مم
- الوزن: حوالي ٢٣٥ جم

- ٤ مؤشرات LED
- طلاء بالمطاط
- كفاءة نقل عالية
- خلية بطارية ليثيوم بوليمر ذات أمان واستقرار عاليتين
- انخفاض التفرغ الذاتي وقت طويل في وضع الاستعداد
- التوافق العالي للخواص المحمولة المختلفة
- برنامج حماية ذكي لتجنب الشحن الزائد /
- التبريد ، ماس كهربائي ، إلخ
- تصميم مضغوط ، عملية سهلة
- الحمل: ٣٠ شحن سريع بطول ٣٠ سم ، تأييد سي إلى يو إس بي-٤



POWEROLOGY

دليل الاستخدام

PPBCHA14