



PRODUCT FEATURES

- Bluetooth Version: 5.3
- Voice Assistant Compatibility: Siri
- Touch Control: Music play/pause, next/previous track, volume +/-, accept/end/reject calls, voice assistant
- Charging Interface: USB Type-C

TECHNICAL SPECIFICATIONS

Bluetooth Version	5.3
Support	A2DP, AVRCP, HSP, HFP
Bluetooth Frequency	20Hz-20kHz
Bluetooth Range	10m
Earbuds Battery	30mAh
Charging Case Battery	300mAh
Charging Time	1.5h

PACKAGE CONTENTS

The product includes the following items.
If any items are missing, please contact us immediately.

S/N	Items	Quantity
1	True Wireless Earbuds Unit	1
2	USB Type-C Charging Cable	1
3	User Manual	1
4	L Size Ear tip	2
5	S Size Ear tip	2

BEFORE FIRST USE

For an optimal experience, please charge the charging case and earbuds before using them for the first time.



Charging and Power Instructions

Charging Indicator

- When charging, an orange light on the case will flash.
- Once fully charged, the light will stay lit.

-Power On: Open the case to turn the earbuds on automatically.

-Power Off: Place the earbuds back into the case and close it to turn them off automatically.

Pairing Earbuds with Your Phone

- Open the case to initiate pairing; the earbuds will connect via True Wireless Stereo (TWS).
- Activate Bluetooth on your phone and select the earbuds' name from the list to connect.

Tip: The earbuds will turn off if they haven't connected to a device within 5 minutes.

Earbud Controls

Music Navigation

- Previous Track: Triple-click the MFB on either earbud.
- Next Track: Double-click the MFB on either earbud.

Calls

- Reject a Call: Double-click the MFB on either earbud.
- Answer/End a Call: Single-click the MFB on either earbud.

Music Playback

- Pause/Play: Single-click the MFB on either earbud.

Voice Assistant

- Activate Siri or Voice Assistant: Hold down the MFB on either earbud for 2 seconds.

Note: Control functions may vary depending on the connected device.

SAFETY INSTRUCTIONS

1. Store earbuds in a dry and well-ventilated area to prevent contact with oil, steam, moisture, dust, etc., and to maintain optimal product performance.
2. Refrain from using harsh organic solvents or items containing these substances for cleaning the earbuds.
3. Use the earbuds as intended and follow the standard operating procedures. Be mindful of the environmental impact and maintain a connection distance of no more than 10 meters between your phone and earbuds for the best performance.
4. If the earbuds experience issues such as poor connectivity or compromised communication, do not attempt to disassemble them. Unauthorized repairs or modifications could void the warranty.
5. Use only a standard or manufacturer-approved car charger or charging cable to recharge the earbuds.
6. To maintain the earbuds' functionality, ensure they are adequately charged.