

PORODO
LIFESTYLE



Porodo Lifestyle

6-IN-1 Keyboard and Mouse Set

SKU: PDKBMSC2285

Table of Contents

Keyboard Instructions	2
1. Keyboard Specifications	2
2. Keyboard Switches	2
3. Keyboard Bluetooth Pairing	2
4. Keyboard Sleep Mode	2
5. Keyboard System Switching	3
6. Keyboard Restore Factory Setting Function	3
7. Keyboard FN Combination Key	3
8. Keyboard Safety Instructions	3
Mouse Instructions	4
1. Mouse Specifications	4
2. Mouse Switches	4
3. Setting up	4
3.1 Method 1 USB Receiver Mode	5
3.2 Method 2 Bluetooth Mode	5
4. Mouse Safety Instructions	5
Package Contents	6
Mousepad Specifications	6
Stand Specifications	6
Cable Specifications	6
Bag Specifications	6
Disposal	7
Warranty	7
Contact Us	7

Keyboard Instructions



1. Keyboard Specifications

Number of Keys	67
Operating Distance	10m
Dimensions	8 × 92 × 305mm
Net Weight	128g
Interface	Bluetooth V5.0
Battery Capacity	DC 5V
Input	90mAh

2. Keyboard Switches

The keyboard is powered by a lithium battery. The switch is in the ON position when the power is on, indicated by a blue power-on light that stays lit for 2 seconds before turning off. The switch is in the OFF position when the power is off.

3. Keyboard Bluetooth Pairing

When the keyboard is powered on, press the pairing button briefly to enter Bluetooth pairing mode. The blue pairing light will flash to indicate pairing mode. Select the keyboard from the list of available Bluetooth devices to establish the connection. The pairing process lasts up to 60 seconds. Once paired, the pairing light will stop flashing. After pairing, the keyboard will automatically reconnect to the Bluetooth device when powered on again. The Bluetooth name is PD_KBCB.

4. Keyboard Sleep Mode

If no key is pressed for 10 minutes, the keyboard enters sleep mode. Pressing any key will wake it and return it to active mode. If the host device disconnects from Bluetooth, the keyboard will automatically enter sleep mode.

5. Keyboard System Switching

Press FN + O to switch to Android mode and enable Android keyboard functions.

Press FN + W to switch to Windows mode and enable Windows keyboard functions.

Press FN + E to switch to iOS mode and enable iOS keyboard functions.

Note: Special characters may require using Alt or AltGr keys along with specific characters.

6. Keyboard Restore Factory Setting Function

Press and hold the J, T, and H keys simultaneously for 3 seconds to clear Bluetooth pairing information and reset the device. The blue light will stay on for 2 seconds to indicate a successful reset.

7. Keyboard FN Combination Key

		~	1	2	3	4	5	6	7	8	9	0
Android	Single Press	~	1	2	3	4	5	6	7	8	9	0
	FN+	Home Page	Search	Select all	Copy	Paste	Cut	Previous Song	Play Pause	Next Song	Volume Down	Volume Up
Win	Single Press	~	1	2	3	4	5	6	7	8	9	0
	FN+	Esc	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10
	UN+SHIFT	Home Page	Search	Select all	Copy	Paste	Cut	Previous Song	Play Pause	Next Song	Volume Down	Volume Up
iOS	Single Press	~	1	2	3	4	5	6	7	8	9	0
	FN+	Home Page	Search	Select all	Copy	Paste	Cut	Previous Song	Play Pause	Next Song	Volume Down	Volume Up

		Win	ctrl	Right	Left	Down	Up	–	=+	Delete
Android	Single Press	Win	ctrl	Right	Left	Down	Up	–	=+	Delete
	FN+	Return	Samsung Virtual Keyboard	End	Home	Page Down	Page Up	F11	F12	.com
Win	Single Press	Win	ctrl	Right	Left	Down	Up	–	=+	Delete
	FN+	Return	Samsung Virtual Keyboard	End	Home	Page Down	Page Up	F11	F12	.com
iOS	Single Press	Win	ctrl	Right	Left	Down	Up	–	=+	Delete
	FN+	Home Page	Virtual Keyboard	Win Right	Win Left	Win Down	Win Up	F11	F12	.com

8. Keyboard Safety Instructions

8.1 Keep the keyboard away from sharp objects that could cause damage.

8.2 Do not place heavy objects on the keyboard.

8.3 Avoid stretching, twisting, or applying excessive force to the keyboard.

8.4 To clean, gently wipe the keyboard with a moist cotton cloth.

8.5 Ensure the keyboard is turned off before cleaning. Do not use liquid cleaners.

Mouse Instructions



1. Mouse Specifications

Interface	Bluetooth V2.4 + 5.0GHz
Resolution	1600/1200/800 DPI
Charging Interface	USB-C
Button	4 Button
Working Distance	10m
Input	DC 5V
Battery Capacity	500mAh
Dimensions	110x61x32mm
Mousepad Dimensions	220x150mm
Net Weight	75g

2. Mouse Switches

The mouse is powered by a lithium battery. The switch is ON when the mouse is powered on.

3. Setting up


1. Turn on the mouse using the On-Off switch located on the back.
2. Use the mouse with either the USB receiver or Bluetooth mode.

3.1 Method 1 USB Receiver Mode

Step 1a: Open the mouse case and remove the USB receiver.

Step 1b: Insert the USB receiver into your laptop or PC.


Step 1c: Press the mode button on the back until the LED status light turns red, indicating USB mode.



3.2 Method 2 Bluetooth Mode

Step 2a: Press the mode button on the back until the LED status light turns blue, indicating Bluetooth mode.

Step 2b: On your tablet, laptop, smartphone, or other Bluetooth-enabled device, open the Bluetooth settings, enable Bluetooth, search for devices, and select "PD-WMCB" from the device list.



4. Mouse Safety Instructions

4.1 Keep the mouse away from sharp objects that could damage it.

4.2 Do not place heavy objects on the mouse.

4.3 Avoid stretching, twisting, or applying excessive force to the mouse.

4.4 To clean, gently wipe the mouse with a moist cotton cloth.

4.5 Ensure the mouse is turned off before cleaning. Do not use liquid cleaners.

K Package Contents

1. Keyboard
2. Mouse
3. Mousepad
4. Stand
5. Cable
6. Bag

K Mousepad Specifications

Material	Natural rubber + 200g jacquard cloth
Edge Type	Lockstitch edges
Dimensions	220 x 150 x 2mm

K Stand Specifications

Dimensions	132 x 74 x 4mm
Net Weight	43g

K Cable Specifications

Input Connector	USB-C
Material	Aluminum Alloy
Cable Length	1m
Net Weight	46g

K Bag Specifications

Fabric	PU
Material	EVA
Product Weight	133g
Dimensions	185 x 185 x 45mm



This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**