



Porodo 10000 mAh Magsafe Powerbank

Attach withType C and Lightning Cable

SKU: PD-PBFCH040

Thank you for choosing our portable power bank – a compact, lightweight, and versatile charging solution for your mobile lifestyle. Whether at home, in the office, or on the go, this power bank is designed to promptly and efficiently charge a wide range of portable electronic devices, such as smartphones, MP4/3 players, iPods, Bluetooth-enabled devices, gaming consoles, and digital cameras/camcorders. This manual provides detailed user instructions and important safety precautions. Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Important safety precautions

When using this device for the first time or after long-term storage, it may automatically be discharged to preserve battery health.

Please fully charge the power bank before its first use. It typically requires two to three charge/ discharge cycles to reach optimal performance.

- 1. Only use the specified charger and approved accessories, including the provided charging cable, to ensure safe and efficient charging.
- 2. Avoid charging in conditions where the temperature is either too high or too low, as extreme temperatures can impact the performance and safety of the device.
- 3. Ensure the power bank is positioned in a place with adequate ventilation to prevent overheating.
- 4. Do not expose the power bank to water, high humidity, or rain to prevent damage. It should not be placed on wet surfaces or submerged in water.
- 5. Handle the power bank with care. Avoid dropping, hitting, or shaking it, as these actions can damage the internal circuitry and compromise the structural integrity.

- 6. Keep the power bank and its accessories out of reach of children to prevent any potential misuse or accidental harm.
- 7. During charging, the mobile power bank may exhibit a slight increase in temperature, which is a normal phenomenon.
- 8. Do not place the power bank near sources of heat, such as fires or heaters, to prevent the risk of overheating and potential danger.
- 9. Avoid contact between the power bank and metal objects as this may lead to a short circuit and damage the device.
- 10. Unauthorized alterations or repairs to the power bank may result in safety hazards and will void the warranty.
- 11. Ensure that the use of the mobile power bank is in accordance with local laws and safety regulations.



1. To Charge the Power bank

- 1.1 Power Input: Micro USB interface for power charging.
- **1.2** Power Output Interface: Standard USB Type A interface for charging other devices.

2. Charging Station

- **2.1** Charging Interface: Use the included DC3.5 output line and Micro USB adapter to charge the power bank or to power devices through computer USB charging.
- 2.2 Charging Indicators: The indicator displays the current power level of the power bank.
- 2.3 Initial Charge: When using for the first time, or after long periods of inactivity, activate the Mobile Power charging three times before charging to its full capacity, which takes approximately 20 hours. For optimal results, charge for only 8 hours before use, as this allows the battery to reach the best power state

3. To Charge Other Devices

Digital devices, including smartphones, compatible with a 5V (DC) input voltage can be charged by this product. The red indicator light signals the connected device is being charged. Once the device is fully-charged, the indicator light turns off.

Note: Upon ceasing the charging operation, disconnect the power bank to preserve battery life.



Capacity	10000mAh
Size	21.6×68.6×110mm
USB Output	5V/3A - 9V/2A - 12V/1.5A - 5V/4.5A (22.5W)
Type-C Output	5V/3A - 9V/2.2A - 12V/1.67A (20W)
Wireless Output	5W / 7.5W / 10W / 15W
Lightning Output	5V/2A(10W)
Lightning/Typ -C /Micro Input	5V/2A - 9V/2A



Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at: **https://porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty



If you have any questions about this Privacy Policy, please contact

us at: info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo