

PORODO



Porodo

**AEROFIT
2.01" SPORT SMARTWATCH**

SKU: PDSWX

Table of Contents

Product Overview	2
Specifications	2
Platform Requirements	3
Initial Use Instructions	4
Watch and App Connection Guide	5
Smartwatch Operating Instructions	6
Smartwatch Features Overview	7
Safety Precautions	8
Common Problem	9
Disposal	10
Warranty	11
Contact Us	11

Product Overview

The Porodo AEROFIT 2.01" Sport Smartwatch is designed for the active individual who seeks to elevate their fitness journey while staying connected. Boasting a sleek 2.01-inch touchscreen display, this smartwatch offers a vibrant and crisp interface that ensures easy navigation through its intuitive features. Crafted for those who value both style and performance, the AEROFIT is equipped with advanced health-tracking capabilities, including heart rate monitoring, sleep tracking, and real-time workout data such as steps, calories burned, and distance traveled. Whether you're hitting the gym, going for a run, or practicing yoga, this smartwatch provides real-time insights into your health metrics, enabling you to make more informed decisions for a balanced lifestyle. The AEROFIT also supports smartphone notifications, ensuring you never miss an important message or alert, all while maintaining its waterproof design, making it perfect for outdoor activities. With a long-lasting battery life, sleek design, and an array of personalized fitness features, the Porodo AEROFIT 2.01" Sport Smartwatch is more than just a wearable—it's your ultimate companion for a healthier, more active life.

Specifications

Casing Material	Zinc Alloy
Bluetooth Version	5.3
Screen Size	2.01" IPS HD Screen
Resolution	240 x 296 Pixels

Battery Capacity	200mAh
Standby Time	10-12 Days
Working Time	3-5 Days
Memory	256KB+16MB
Water Resistance	IP65
Compatibility	Android 5.0+, iOS 9.0+
Band Width	22mm
Weight	54g
Model ID	PDSWX

App Installation Guide

- 1.** For Android/iOS users: Scan the QR code below to directly download and install the Porodo AEROFIT app for your mobile device.
- 2.** For Android users: Search for "LaxasFit" in the Google Play Store to find and install the app.
- 3.** For iOS users: Search for "LaxasFit" in the Apple App Store to download and install the app.

Note: Ensure your device is connected to the internet for a smooth installation and activation process.



Initial Use Instructions

1. Charge the Watch

To ensure optimal functionality, fully charge your smartwatch before its first use. This will allow the device to calibrate properly and provide accurate performance.

2. Magnetic Charging Setup

Align the wireless magnetic charging suction cup with the corresponding magnetic port on the back of the watch. Once aligned, the charging base will illuminate with a green light, indicating a secure connection and that charging is in progress.



Watch and App Connection Guide

1. APP Installation Permissions: Ensure that all permissions requested during the installation process are granted. Both the watch and the mobile phone must be connected to the app, and the phone's Bluetooth should be enabled to allow the app to perform all functions.

2. Connecting the App to the Watch:

2.1 Open the app and enable Bluetooth on your mobile device.

2.2 The app will prompt you to confirm the connection by enabling notifications.

2.3 Click the option to add a device, search for the model's name, and click Connect to pair it with your watch.

3. Mobile Phone Bluetooth Connection:

3.1 Bluetooth should be activated on the watch.

3.2 Open Bluetooth settings on your mobile phone and search for the Bluetooth device corresponding to your watch model.

3.3 Select the device name and click Connect to initiate the pairing process.

4. Troubleshooting Common Bluetooth Issues: Due to varying Bluetooth protocols across different mobile phone brands, connections may sometimes be unstable. If this happens:

4.1 Turn off Bluetooth on your mobile phone and reconnect it.

4.2 If the issue persists, reset the watch to its factory settings.

4.3 If the watch is unresponsive, press and hold the power button for 10 seconds to restart it.

5. Verifying the Bluetooth Connection:

5.1 Check the Bluetooth icon in the upper left corner of the main menu in the app. When the icon is displayed as a solid oval, it indicates a successful connection.

5.2 You can also use the app to search for the phone or use the device's built-in function to search for the app. If the watch vibrates, it confirms that the Bluetooth connection is successful.

6. Incoming Call Notifications:

6.1 If the watch has an incoming call, ensure that the relevant settings for notifications are enabled in both the watch and the app.

6.2 Navigate to the notification settings in the app and ensure the application is properly configured to receive incoming call alerts.

Smartwatch Operating Instructions

1. Power Button:

1.1 Up Button: Press briefly to return to the previous screen.

1.2 Down Button: Press briefly to wake the screen up or turn it off. A long press can be used to power on/off the smartwatch.

2. Clock Interface:


These swipe gestures enhance the navigation experience, providing quick and intuitive control of the smartwatch's features.

2.1 Swipe Right: Moves forward to the next screen or function.

2.2 Swipe Left: Typically moves to the previous screen or function.

2.3 Swipe Up: Often reveals additional options like quick settings or opens your notifications.

2.4 Swipe Down: Typically used to close or minimize open screens, or access a notification center.



Smartwatch Features Overview

 Standby Interface	- Enter the standby interface on your smartwatch when not in use to save battery.
 Dial pad	- Connect your smartwatch to your mobile phone via Bluetooth. Once connected, you can make and receive calls directly from the watch.
 Contacts	- After pairing the smartwatch with the companion app, you can add contacts to the app. Once added, the contacts will sync to the smartwatch, allowing you to view them directly on the device. You can then select a contact from the smartwatch to initiate a call. Note: Ensure your phone's Bluetooth is connected for proper functionality.
 Call History	- The smartwatch can display your call history. Simply tap the contact's name or number to dial directly from the smartwatch.
 User Information	- The product can display notifications for messages from apps. Note: iOS systems above iOS 12 will block SMS reminders by default.
 Activity Tracking	- Access various sports modes (running, rope skipping, cycling, and mountain climbing) from the selection menu. Once selected, the watch will monitor key metrics such as exercise time, distance, calories burned, and heart rate data.
 Sports Record	- Your smartwatch will record all exercise data, providing a detailed log of physical activities.
 Pedometer	- Track your step count throughout the day. The data will automatically reset at 00:00 every morning and can be reviewed in the app for progress.
 Sleep monitoring	- Turn on sleep detection to monitor and analyze the quality of your sleep during the night.
 Sedentary Reminder	- Set reminders for sedentary periods. The watch will vibrate when it's time to move, prompting you to stay active. A notification will appear on the screen to remind you to take a break.
 Heart Rate Monitoring	- Wear the smartwatch snugly on your wrist, ideally near the upper arm area, for accurate heart rate readings. The watch continuously monitors and displays your real-time heart rate, with a typical range of 100-60 beats per minute.
 Blood Pressure	-For accurate blood pressure readings, place the watch snugly on your wrist, above the wrist bone. It can measure real-time blood pressure, with the following normal ranges: a. Adult Diastolic Blood Pressure: 80-60 mmHg b. Adult Systolic Blood Pressure: 120-100 mmHg
 Blood Oxygen Monitoring	-Ensure the watch is securely positioned on your wrist, ideally above the wrist bone and over the arm. The watch can measure the real-time blood oxygen level, which generally ranges from 95% to 100%.
 Remote Camera Control	-If your phone is unlocked and the app interface is open, the watch will automatically trigger the camera interface on your phone. You can then shake the watch to take a photo, and the phone will capture and store the image. Alternatively, open the app and enter the remote-control selfie mode to trigger the camera interface and take pictures by shaking the watch.
 Music Control	-The watch allows you to control music playback on your phone. When connected, use the app to manage and control your phone's music.

 Phone Locator	-When connected to your mobile phone, tap the magnifying glass icon on the watch. This will prompt your phone to ring, helping you locate it.
 Weather Forecast	-The watch can display the current weather temperature in degrees, giving you instant access to the current climate information.
 Timer	-Use the watch to start and stop the stopwatch or timer function with ease, assisting you in keeping track of time for various activities.
 Alarm	-Set a custom alarm using the app, and the watch will vibrate to remind you at the scheduled time.
 System Settings	-You can adjust the vibration and volume settings directly through the app, allowing you to customize your watch's notifications according to your preferences.
 Style	- You can set and customize the user interface style according to your preferences.
 Device Information	- Display the MAC serial code, Bluetooth name, and the version number of your device for easy identification.
 Screen Brightness	- Adjust the screen brightness and set the backlight timeout according to your preferences for optimal visibility and battery usage.
 Scan QR Code	- The QR code can be downloaded using the mobile app for easy access and setup.
 Factory Reset	- Reset your device to clear all data, such as step count, sleep tracking, etc., and restore factory settings if needed.
 Breathing Effect	- Activate the breathing effect on your screen. The clock will animate, popping up and turning off the display after a set time.
 Language Settings	- Once connected to the app, you can set the preferred language on the app side. This language will be synchronized with the watch after you save the setting. Alternatively, you can switch the language directly from the watch, which will also sync with the app.
 Dial Function	- Enter the app's dial function to view and select your favorite watch faces, including local dials and custom DIY designs. You can also push these custom dials to the watch.
 Lingdong Mode	- Click on the settings interface of the watch to open the Lingdong Island feature and return to the main dial view to access more information.
 Casual Games	- Activate Racing Mode for a more dynamic display and functionality suited for active tracking.
 Hand Gesture Control	- Enable the hand gesture function by covering the screen with your hand. This will turn the display on or off depending on the gesture.

Safety Precautions

1. Not intended for use while bathing or swimming. Exposure to water may damage the product or affect its performance.

2. Ensure that the watch is connected when synchronizing data to avoid interruptions.
 3. Use the provided built-in charging cable for optimal charging performance.
 4. To maintain the longevity of the watch, avoid exposing it to high levels of moisture or extreme temperatures (both high and low) for prolonged periods.
 5. Avoid scratching the sensor to prevent potential damage that may affect its performance.
 6. To clean the face of the watch, gently wipe it with a soft, damp cloth. For more thorough cleaning, use mild soap and water to remove oil, dust, or dirt.
 7. Keep the watch away from harsh chemicals such as gasoline, cleaning solvents, propane, alcohol, or insect repellents. These substances can damage the watch's sealing and affect the surface of the case.
 8. Do not expose your watch to extreme heat, strong shocks, or physical stress, as these conditions can damage its internal components and exterior.
- Note:** This product does not support IP68 waterproofing. It is not water-resistant, and exposure to rain, hand washing, swimming, hot showers, saunas, or other water sources could damage the watch. Water vapor or moisture ingress caused by such exposure may void the warranty. Ensure the watch is used in accordance with the specified guidelines to avoid damage.

Common Problem

a. Issue: Unable to find the watch?

Solution: If you're unable to find the watch, ensure that it is powered and Bluetooth is activated. The mobile phone might not be detecting the Bluetooth broadcast from the watch. Make sure the watch isn't already connected to another device, and bring it closer to your mobile phone before attempting to search again. If the issue persists, turn off the Bluetooth on your mobile phone for 20 seconds, then turn it back on and try searching for the watch once more.

b. Issue: Bluetooth connection always on? Will there be any data if it is turned off?

Solution: Before synchronizing your data, the exercise and sleep information will remain stored on the watch. When the Bluetooth connection between your mobile phone and the watch is established, the watch will automatically upload the stored data to your phone. However, please note that the watch has limited storage for Bluetooth data. It can only retain data for up to one week. Once the storage is full, the oldest data will be overwritten to make room for the latest information. To avoid losing important data, it is recommended to sync your watch to your phone regularly.

Note: If the call and SMS reminder features are activated, the Bluetooth connection needs to remain enabled. Additionally, the alarm clock and reminder functions will still be offline.

c. Issue: Can not charge the watch?

Solution:

1. Ensure Proper Contact: Verify that the direction of the charging stand is correct, and ensure the charging clip is making proper contact with the watch.

2. Low Battery Power: If the watch's battery is below 3.6V, there may be a short precharging delay. It will take 5-3 minutes for the watch to enter charging mode after being plugged in if the display does not immediately activate.

Note: The watch will enter charging mode shortly after the charger is connected. If there is no display initially, allow it to charge for a few minutes before it begins to power on.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**