porodo



Porodo

Blue 7in1 Hub HDMI

2×USB-A 2×USB-C SD MicroSD

SKU: PB-71HBC-GY

Table of Contents


Features	2
Multi-Port USB-C Hub Overview	2
Operation Instructions	3
Display OS Configuration Instructions	3
Sound Output Procedure	4
Display Control	4
Specifications	5
Warranty	6
Contact Us	6

Before installing and using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Features

- 1. Aluminum Alloy Shell.
- 2. Suitable for USB Type-C PCs/Tablets/Mobile Phones.
- 3. Compatible with mainstream Windows/Mac OS/Android.
- 4. Supports Plug and Play, Hot Swappable.

Multi-Port USB-C Hub Overview





Operation Instructions

- 1. Connect the hub to your PC, tablet, or mobile phone.
- 2. Insert your devices into the 7-in-1 Type-C Hub.

The USB hub can be utilized for two display modes: the Mirror Mode replicates your laptop's screen onto a larger display, showing the same content on both screens. In contrast, the Extend Mode allows you to expand your workspace by using the second screen as an additional desktop, displaying different content from the laptop.

Expand your screen:





Display OS Configuration Instructions

Step 1. Navigate to the Apple menu, select 'System Preferences', and then click on 'Displays'.

Step 2. Choose the 'Arrangement' tab.

Step 3 and 4. Press and hold the 'Option' key while clicking and dragging an image with the mouse to reposition it to another display.





Step 1

Step 2



Display preferences control the resolution and color of your MacBook Air's displays and their arrangement with any nearby Mac or iPad signed into your Apple ID.

To rearrange displays, drag them to the desired position. To mirror displays, hold Option while dragging them on top of each other. To relocate the menu bar, drag it to a different display.

Add Display Display Settings...

Universal Control... Night Shift... ?

Step 3

Step 4

Sound Output Procedure

Step 1. Navigate to the Apple menu, select 'System Preferences', and then click on 'Sound'.

Step 2. In the 'Sound' preferences, click on the 'Output' tab.

Step 3. From the list provided, choose a device for sound output.



Step 1



Step 2



Step 3


Display Control

The shortcut key 'Windows+P' allows for quick toggling between display modes when a device is connected to a USB hub. Pressing these keys simultaneously presents options to use the PC screen only, duplicate, extend, or use a second screen exclusively.

Windows:

Windows+P

Screen switch shortcut key



Specifications

USB-A 3.0	Up to 5Gbps data transmission
USB-A 2.0	Up to 480Mbps data transmission
USB-C 2.0	Up to 480Mbps data transmission
SD Card Slot	High speed SD card reader
Micro SD Card Slot	High speed Micro SD card reader
HDMI	4K@30Hz output
Type-C PD	Up to 100W power input
Size	126.4×28×10mm
Weight	About 43gr
Material	Aluminum Alloy Shell



Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **https://porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

https://www.porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo