

# porodo



**Porodo LifeStyle**  
**3in1 Multi Functional 180°**  
**Foldable Mini Turbo Fan**

SKU: PD-LSMFTF

# **Table of Contents**

Features	2
Schematic View	2
Instructions for Use	2
Specifications	3
Caution	3
Warranty	4
Contact Us	4

Before installing and using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

## Features


**Digital Display:** Stay informed with a real-time display of wind speed and battery life for uninterrupted comfort.

**5 Speeds:** Combat the heat effortlessly; our 5-gear Turbo Wind delivers consistent cooling on the hottest days.

**Secure Comfort:** Engineered for convenience, this portable turbo fan includes a lanyard to ensure it's always within reach for secure comfort.

## Schematic View

- A. Speed Level**
- B. LED Indicator**
- C. Power Button**
- D. Type-C Charging Port**



## Instructions for Use

### 1. Fan Operation:

Press the power button once to initiate the fan at Speed 1; a white LED will indicate the current speed level. Continue pressing the button to cycle through Speeds 2, 3, 4, and 5. To turn off the fan, press the button until the LED turns off.

### 2. LED Indicator:

While the fan is operating, a constant green light displays the battery level as follows: Four lights: 75% - 100%, Three lights: 50% - 74%, Two lights: 25% - 49%, One light: 5% - 24%, Blinking light: 0% - 4%, and then the unit will turn off.

After the green light goes off, a white light signals a low battery.

### 3. Charging Indicator:

During charging, the green light flashes to indicate the battery status:

First light: 0% - 24 %, Second light: 25% - 50 %, Third light: 51% - 74 %, Fourth light: 75% -99 %, All four lights illuminated: 100 % .

## Specifications

Product Name	3in1 Multi Functional 180° Foldable Mini Turbo Fan
SKU	PD-LSMFTF
Input	5V == 2A
Power	7W
Size	171×60×52mm
Weight	192gr

## Caution

1. This product requires a USB 5V power supply; please avoid using chargers that deliver either too high or too low voltage for charging.
2. When activating the power switch and operating the motor, do not insert your fingers into the fan's protective net. Doing so when the fan is damaged may cause bodily injury.
3. Avoid stopping the fan blades with any hard objects, as this can cause excessive current that may damage the control circuit or fan motor.
4. If the product has not been used for more than three months, charge it to 75 % capacity for optimal storage.
5. Children under ten years old should use this product under adult supervision.

## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at [\*\*https://porodo.net/warranty\*\*](https://porodo.net/warranty) and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

[\*\*https://www.porodo.net/warranty\*\*](https://www.porodo.net/warranty)

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:

**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**