



**GREEN LION**



**Green Lion**

**MAKEUP MIRROR FAN with  
90° Oscillation**

SKU: GNMKMIR17

Model No: GL-MR17

## Table of Contents

Power and Charging	2
Operation Instructions	2
Oscillation Mode Activation	3
Adjust Lighting Instructions	3
Low Power Indicator	4
Auto Shut Down Function	4
Specifications	4
Disposal	5
Warranty	6
Contact Us	6

## Power and Charging

1. Power On/Off: The power switch is located at the back of the base. To turn the device on, move the switch to the "on" position. To turn it off, set the switch to the "off" position.
2. Charging: The device has a Type-C charging port and uses a standard 5V input voltage. Always use the included charging cable to charge the fan. When the battery drops below 3.3V, the screen will start flashing until the device is turned off. It is recommended to charge the fan as soon as the battery is low. The product supports simultaneous charging and use.

**Note:** This device is equipped with a battery protection board for enhanced safety.

Warning: If you won't be using the fan for a long time, turn off the power switch and store the fan in a dry place. Make sure to charge and discharge the fan every three months to keep the battery in good condition.

## Operation Instructions

1. Turn on the power switch at the back to the "ON" position. Press the gear button briefly to activate the fan, and the digital screen will display the current battery level. If no operation is performed within 5 seconds, the screen will turn off automatically.
2. After pressing the gear button to wake up the digital screen, press it again to enter the first speed setting. The display will show the battery level after 1-3 seconds.
3. In the first speed setting, press the gear button briefly to switch to the second speed. The display will show "2" for 3 seconds before switching to the battery level.
4. In the second speed setting, press the gear button briefly to enter the third speed. The display will show "3" for 3 seconds, then switch to the battery level.

5. In the third speed setting, press the gear button briefly to switch to the fourth speed. The display will show "4" for 3 seconds, then switch to the battery level.
6. In the fourth speed setting, press the gear button briefly to enter the fifth speed. The fan will cycle through speeds 5, 4, 3, 2, 1, and then turn off. The display will show "5" for 3 seconds before switching to the power display.
7. Speed Settings: Light breeze, Light breeze, Strong wind, Storm wind, Natural wind, Off

## Oscillation Mode Activation

1. After turning on the fan, press and hold the gear button to activate the oscillation, causing the fan to sway left and right. Press and hold again to turn off the oscillation.
2. When the fan is turned off, the oscillation will automatically reset to the middle position.

## Adjust Lighting Instructions

1. In standby mode, when the digital screen is off, briefly press the light button to wake up the display, showing the current battery level. If no operation is performed within 5 seconds, the screen will turn off automatically.
2. Press the light button again to turn on LED, entering the first low light mode.
3. Press the light button a third time to activate LED at a medium brightness level, entering the second gear.
4. Press the light button a fourth time to turn on LED at full brightness, entering the third high brightness mode.
5. To turn off the light, briefly press the light button once more.

Work Cycle Gear: 1 → 0 → 3 → 2 → 1

6. The product also supports infinite dimming: After briefly pressing the SW2 button to enter lighting mode, long press the SW2 button to gradually increase the brightness. Release the button, and long press it again to gradually decrease the brightness. This process will cycle through the light and dark modes.

The lighting mode and fan operation can function simultaneously without interference.

## Low Power Indicator

When the battery level drops to 3.3V during operation, the battery display will flash, indicating a low battery. If the battery voltage drops below  $3.1 \pm 0.1V$ , the digital display will show "00" and the product will shut down. Afterward, briefly press the power button, and the digital display will flash "00" five times before turning off.

## Auto Shut Down Function

The product will automatically shut down if the fan motor becomes stuck. Similarly, the product will also shut down when the motor is running but encounters an issue.

## Specifications

Model No.	GL-MR17
Material	ABS+PC+Glass
Battery	5400mAh
Power	8.5W
Light Modes	Low-Medium-High
Brightness	7.60-23.50-44.50 lm
Fan Speed	5 Levels
RPM Range	1040-1550 RPM
Airflow Rate	3.2 m/s - 5.0 m/s

Oscillation	90°
Noise Level	50-65 dB
Charging Port	USB-C
Charging Time	4 Hrs
Working Time	3-11 Hrs
Product Weight	590 g
Product Dimensions	177*112*245 mm

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



## **Warranty**

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
<https://www.greenlion.net/warranty>

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: [sales@greenlion.net](mailto:sales@greenlion.net)

Service Support: [Support@greenlion.net](mailto:Support@greenlion.net)

Telegram: [@greenlion\\_global](https://t.me/greenlion_global)

Instagram: [@greenlion\\_global](https://www.instagram.com/greenlion_global)