

LèPRESSO



LePresso

Portable Mug Burr Grinder Coffee Maker

SKU: LPGCMSM

Table of Contents

Features	2
Schematic View	2
Instructions for Use	3
Charging Instructions	3
Specifications	4
Attention	4
Reset Function	4
Cleaning and Storage	5
Warranty	5
Contact us	5

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Features

1. A portable mug designed for travel, offering a convenient 250ml capacity, ideal for enjoying your coffee on the go.
2. Features adjustable grind settings, allowing you to customize the coarseness of your coffee grounds according to your brewing preferences.
3. Includes a drip filter for a clean and efficient brewing process, ensuring a smooth and flavorful coffee experience.
4. Optimized for use with medium or dark roasted coffee beans, enhancing the rich and robust flavors preferred by coffee enthusiasts.
5. Constructed from high-quality materials: ABS for lightweight durability, a ceramic burr for precise grinding, and stainless steel for long-lasting performance.

Schematic View

- A. Lid
- B. Light Indicator
- C. Button
- D. USB Interface
- E. Motor
- F. Adjustable Ring
- G. Grinder
- H. Filter
- I. Stainless Steel Cup



Instructions for Use

- 1. Opening the Grinder:** Rotate the motor clockwise to open.
- 2. Adding Coffee Beans:** Place the coffee beans into the coffee bean container.
 - Tip: It's best to fill the container to 80 % capacity.
- 3. Closing the Grinder:** Reattach the motor and turn it counterclockwise to secure.
- 4. Adjusting Grind Size:** Set the desired grind size, fine or coarse, using the adjustable ring (F).
- 5. Starting the Grinder:** Press the button (C) to begin grinding. The motor will automatically stop once the coffee beans are depleted.
- 6. Removing Ground Coffee:** Turn the grinder counterclockwise to detach (G). The coffee grounds will collect in the filter (H). Slowly pour hot water through the filter (H).
- 7. Serving the Coffee:** Place the lid (A) on the stainless-steel cup (I) and enjoy your freshly brewed coffee.

Charging Instructions

- 1.** When the blue light flashes twice, it indicates that the grinder is out of power.
- 2.** Insert the small USB plug into the USB interface (D).
- 3.** Connect the larger USB plug into the computer socket.

Note: You can also use a cellphone adapter for charging.
- 4.** While the grinder is charging, the light (B) displays the increasing power level; each light indicates 25 % of the battery capacity.
- 5.** When all four lights are on, it signifies that the battery is fully charged.

Note: Please ensure to recharge the grinder when only one light is on.

Specifications

Battery Capacity	1600mAh
Voltage	3.7V
Charging Port	Type-C
Recharge Time	2-3h
Working Time	15 Grind cycles on a full charge
Coffee Bean Capacity	18gr
Mug Capacity	250ml
Suitable Beans	Medium or dark roasted coffee beans
Material	ABS, Ceramic Burr, Stainless Steel

Attention

1. Keep the grinder out of reach of children.
2. Store the motor in a dry place.
3. Ensure there are no hard objects inside the grinder.

Reset Function

1. Remove the motor from the grinder.
2. Press the button for 10 seconds until the electric indication light (B) flashes and the grinder starts to work.

Note: If the grinder does not stop automatically after the coffee beans are depleted, follow these instructions to reset the program.

Cleaning and Storage

1. After using the grinder, gently clean the ceramic burr with a brush.
2. You may wash all parts except the motor.
3. Ensure the product is dry before using to keep it in optimal condition.
4. Charge the product for 4 hours before the first use.
5. To maintain the battery's service life, charge the product at least once every three months.

Warranty

Products that you buy directly from our **LePresso** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **LePresso** website or store. If **LePresso** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website <https://www.lepresso.com/warranty> and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:

<https://www.lepresso.com/warranty>

Contact Us

If you have any questions or concerns about our Shipping and Returns Policy, please contact us at: info@lepresso.com

Website: <https://www.lepresso.com/>

Instagram: [lepresso_official](https://www.instagram.com/lepresso_official)