

PORODO
LIFESTYLE



Porodo Lifestyle
COOLFLEX Mini Handheld Fan
with Flexible Tripods

SKU: PDF35AWH

Table of Contents

Features	2
Specifications	2
Product Overview	3
Instructions for Use	3
Charging Current/Time	4
Precautions	4
Disposal	5
Warranty	5
Contact Us	5



Features

1. The fan offers three customizable speed settings, allowing you to select the perfect breeze for your comfort.
2. Enjoy up to 4.5 hours of uninterrupted use on a single charge, ensuring long-lasting coolness throughout the day.
3. Designed for versatility, this fan is perfect for use in a variety of environments, whether at home, in the office, or outdoors.
4. With its lightweight design, this fan ensures easy handling and portability, making it perfect for all-day comfort while on the go.

Specifications

Input	5V/1A
Battery Capacity	1200mAh
Working Time	4.5H (Level 1), 2.2H (Level 2), 1.2H (Level 3)
Charging Time	2H
Charging Interface	Type-C
Product Size	59.4 x65×241.2mm
Product Weight	175g
Model Number	PDF35A

Product Overview



Instructions for Use

- 1. Fan Button:** Click once for Gear 1, click again for Gear 2, click the third time for Gear 3, and click the fourth time to turn off the fan.
- 2. Type-C Charging Port:** The Type-C charging port on the fan body allows you to charge the fan.
- 3. Low Battery Indicator:** When the battery is low, the current gear indicator

light flashes until the fan is turned off. (If the function is turned off and restarted, the gear indicator light will flash 10 times quickly, and the function will be unavailable).

4. Charging Indicator: When charging, the charging indicator light (red) is on, and when fully charged, the charging indicator light will turn off.

Charging Current/Time

1. Charging Current: 1000mA ($\pm 20\%$)

2. Charging Time: About 2 hours

3. Full Battery Usage Time:

1st speed: About 4.5 hours

2nd speed: About 2.2 hours

3rd speed: About 1.2 hours

Precautions

1. Please charge the product before first use.

2. Please charge the fan every three months to avoid battery damage.

3. If the product is not used for an extended period, please turn off the power switch before storage.

4. Do not allow children under 6 years old or people with disabilities to use this product alone.

5. Do not use this product in bathrooms or swimming pools.

6. Do not wash the fan blades and detachable hoods directly with water.

7. Keep out of reach of children.

8. Protect from drops and impacts.

9. Avoid exposure to extreme temperatures.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**