

Porodo Soundtec

PODSHELL Wireless Earbuds

SKU: PDST2231


Table of Contents

Preface	2
Package Contents	2
Schematic View	2
Power On and Off	3
Charging Instructions	3
Pairing Instructions	4
Functionality Description	4
Troubleshooting	5
Specifications	6
Warning	6
Disposal	7
Warranty	8
Contact Us	8

Preface


Thank you for choosing a Porodo product. To ensure optimal use and performance, we kindly ask that you read this manual thoroughly before using the product. Please keep it in a safe place for future reference. We wish you a pleasant and satisfying experience with our product.

Package Contents



Earbuds, Charging Case, Additional Ear Tips, Charging Cable

Schematic View



Power On and Off

1. Power On


1.1 The earphones will automatically power on when removed from the charging case.

1.2 The earphones will power off and begin charging automatically when placed back into the charging case.

2. Power Off

2.1 To turn the earphones off, place them in the charging case, and they will disconnect and begin charging.

2.2 If the earphones are in pairing mode outside of the case, they will automatically turn off after 5 minutes without a connection.



Charging Instructions

Charging the Earbuds


When the earbuds are placed in the charging case and powered off, charging will begin automatically.

Charging the Charging Case

Connect the charging case to a Type-C charging cable.


While charging, the red indicator light will flash continuously.

Once fully charged, the indicator light will turn off.




Pairing Instructions

1. Once the earbuds are removed from the charging case, they will power on and automatically enter pairing mode. The primary earbud will blink red and blue alternately, while the secondary earbud will blink blue slowly.
2. Open the Bluetooth settings on your device and search for "TWS-T01" to establish a connection. Upon successful pairing, you will hear a prompt sound indicating the connection is complete.
3. The earbuds will automatically reconnect to the last paired device when powered on. If the Bluetooth connection is lost, the earbuds will re-enter pairing mode, indicated by rapid flashing of red and blue lights.



Functionality Description

1. Answer/End Call: Tap once on either the left or right earbud.
2. Pause/Play: Tap once on either the left or right earbud.
3. Voice Assistant: Press and hold for 2 seconds to activate.
4. Previous Track: Double-tap the left earbud to go to the previous track.
5. Next Track: Double-tap the right earbud to skip to the next track.
6. Volume Up: Triple-tap the right earbud to increase the volume.
7. Volume Down: Triple-tap the left earbud to decrease the volume.



Note:

The grey area indicates the touch-sensitive zone. This earbud operates via touch control.

Note:

The voice assistant feature requires device support and permission to be enabled on the device.

Troubleshooting

1. Indicator light does not turn on when charging the charging case
 - 1.1 Ensure that the charging port of the charging case is properly connected to the power source.
 - 1.2 If the product has not been used for an extended period, the battery may enter a sleep state. In such cases, the light will turn on after approximately 30 minutes of charging.
2. No sound from the earbuds
 - 2.1 Confirm that the earbuds are in working condition.
 - 2.2 Check if the volume of the earbuds is set to an appropriate level.
 - 2.3 Ensure that the earbuds are properly connected to your phone.
 - 2.4 Verify that the earbuds are within the normal operating range.
3. Poor call quality with the earbuds
 - 3.1 The effective usage distance of the earbuds is 10 meters. Ensure the earbuds are within range and that there are no obstacles between the earbuds and the phone.
 - 3.2 Check for dust or foreign objects blocking the microphone.
 - 3.3 Confirm that the call volume on the earbuds is not too low or set to mute.
 - 3.4 Ensure that the earbud battery is not low, as low battery can affect performance.

4. Why can't the earbuds pause or resume music play?

4.1 This feature requires the device paired with the headphones to support the AVRCP (Audio/Video Remote Control Profile) protocol.

Specifications

Model Number	PDST2231
Bluetooth Version	V5.4
Transmission Distance	10M
Case Battery Capacity	300mAh
Earbuds Battery Capacity	30mAh
Charging Interface	Type-C
Music Playtime	4 Hours (@70 %Volume)
Input	5V/1A
Talking Time	3 Hours
Total Working Time	30H (Battery Life with Charging Case)
Charging Time	1 Hour
Driver Size	Φ 10mm
Impedance	32Ω+15 %
Bluetooth Protocol	A2DP/AVDTP/AVRCP/RFCOMM/HFP/HSP/SPP/HID
Standard	GB 2011-8898, GB 2022-4943.1

Warning

- 1.** This product contains a lithium battery. Do not attempt to replace the battery yourself, as it may damage the battery or the device.
- 2.** Do not disassemble, strike, squeeze, or expose the product to fire to prevent the risk of explosion.
- 3.** If the battery becomes swollen or damaged, discontinue use immediately.

4. Do not disassemble, repair, or modify the earphones, as this may cause a fire or permanently damage the product.
5. Avoid placing the product in environments with high temperatures or humidity.
6. Do not use the device during thunderstorms, as lightning can cause the device to malfunction and increase the risk of electric shock.
7. Do not clean the product with alcohol or other volatile liquids.
8. Do not expose the product to corrosive liquids.
9. Keep the product away from children and pets to prevent accidental injury or ingestion of small parts.
10. If you encounter any electrical or mechanical malfunctions with the product, stop using it immediately and contact a service center.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**