



Green Lion

Salad Maker


SKU: GNSL40MKR BK

Model No: GL-SM40


Table of Contents

Product Components	2
Assembly Guide	3
Blade Function Guide	4
Specifications	5
Usage Introduction	5
Fault Analysis	7
Cleaning and Maintenance	8
Matters Needing Attention	8
Disposal	11
Warranty	11
Contact Us	11


Product Components



1




2



3



4



6



8



5



7




9


1. Press Rod
2. Feed Port
3. Main Engine
4. Blade Barrel
5. Slicing Knife Barrel
6. USB Type-C Interface Charging Cable
7. Storage Bucket Lid
8. Storage Bucket
9. Wide Flat Wire Knife Barrel

Assembly Guide


1



2




3




Clamp the transparent feed port on the main machine as shown, and then rotate the buckle in the indicated direction

Insert the cutter barrel, feed the silicone part at the bottom of the barrel, and need to completely clamp the cutter barrel.


Place the ingredients in the feed can and press and hold the switch to cut.



If the ingredients are short, the press bar can be used to assist cutting.



After finishing the food processing, use the press bar to assist the cutter barrel, and rotate it in the direction indicated.




Finally, the feed port is reversed again, so the machine can be cleaned properly, and the main machine can be immersed in water.

Blade Usage Introduction



Modern pioneer healthy diet concept, its low-fat, high-protein, rich types of scientific collocation way by the global nutrition experts, opinion leaders recommended.




Blade Barrel

Potato chips, sweet potato chips, yam tablets, etc., can be fried in the air fryer into a crisp and delicious snack.



Slicing Knife Barrel

Cucumber slices, potato slices, radish slices, etc., can be used as daily stir-fry.



Wide Flat Barrel


Potato shreds, turnip shreds, onion shreds, etc., can be used for cold dishes and salads, stir-fries.

Specifications

Model No.	GL-SM40
Material	ABS+PC+PP+Silicone
Blade Material	Stainless Steel 420J2
Battery	2000mAh
Power	40W
RPM Range	250 RPM
Capacity	150 ml
Cup Capacity	300 ml
Noise Level	69 dB
Charging Port	USB-C
Charging Time	180 min
Runtime	1 hr
Product Weight	1.06 kg
Product Dimensions	195*110*270 mm


Usage Instruction

1. The first time to use, please fully charge the host. Once fully charged, the blue indicator light will stay on. The product is equipped with a USB Type-C interface charging cable, and the power adapter is 5V/1A or other USB interface devices




2. When using this product, the input section must be correctly installed before the food processing. Do not install the tool barrel directly on the main machine.

Wrong



right

Ingredients



**Do not directly install the tool barrel
on the motor**

3. After the food is put into the feeding port, gently press the button the blue indicator light will stay on when the host is gently pressed to start processing the food. When there is too much food, it may cause the knife barrel to get stuck (at this time, the indicator light will turn red). Please take out some food appropriately.



4. After startup, it is recommended that the continuous use time is less than 30 seconds.

5. Indicator Status

Status	Indicate
Charging	The red light Keeps on
Full Charge	The blue light Keeps on
In Use	The blue light keeps on

Fault Analysis

Fault Phenomenon	Pilot Lamp	Cause Analysis	Troubleshooting
Food Processing Machine Stopped	Red Light Flashing	The battery is out of power/there are too many ingredients/the ingredients are stuck	Charge the main machine / remove the tool barrel, and the food can now be used. Insert the cover of the storage bucket into the tool barrel and rotate it in the direction indicated.

Cleaning and Maintenance

1. After the product is used, it is necessary to clean the cutter barrel, feed port, and press rod promptly.
2. The product body can be wiped with a soft wet cloth during cleaning. Be sure not to soak it in water.
3. If carrots and other ingredients are dyed, they can be cleaned with a cloth and detergent. Biological pigments will not affect the use or health.
4. The blade is very sharp; please do not touch the blade directly with your hand. To avoid injury, ensure the water is clear during the cleaning process so that you can see the blade.
5. Do not use abrasive or corrosive cleaning agents.
6. It is strictly prohibited to disinfect all parts of the product at high temperatures.
7. After cleaning the product, dry it thoroughly and reassemble all parts.

Storage:

Put it away and do not use the product for an extended period. Please charge the product within three months.

Matters Needing Attention

1. To avoid harm caused by misuse, please read the instruction manual carefully before using this product. Use this product strictly according to the purpose stated in the instruction manual.
2. This product is a lithium battery-driven electric product. Please charge it before the first use.
3. Before adding ingredients, ensure the blade is in place and running smoothly.
4. Do not use sharp objects to scratch the machine.
5. It is strictly prohibited to overload the product.

6.Do not place the product in the microwave oven or refrigerator, as this may cause the product to crack. It is recommended to use a water temperature below 60°C for sterilization and cleaning.

7.This product cannot be used to process hard foods such as coffee beans, soybeans, ejiao, rice, rock sugar, ice cubes, meat, or frozen food, as well as similar ingredients.

8.When the product is working, do not touch the removable parts, such as blades, to avoid injury or damage to the product.

9.The single working time of this product cannot exceed 30 seconds. After continuous working for 30 seconds, it can only be used after a rest of 2 minutes. The working interval of 2 minutes is a cycle. After continuous working for 3 cycles, the motor must be cooled for 30 minutes before working again to ensure the product's life.

10.The blade is very sharp, please do not touch the blade directly with your hand, and pinch the knife holder on the blade when removing or installing it.

11.Do not use steel wool, abrasive cleaners, or corrosive liquids (such as gasoline or acetone) to clean the product.

12.Please clean with sponge and detergent when cleaning; do not wash any part of this product in the dishwasher.

13.This product should be stored in a place that is not accessible to children, and should not be used or played by persons (including children) who are physically unsound, feel or mentally disabled, or lack relevant experience and knowledge.

14.Due to the different hardness, freshness, and fiber distribution of vegetables and fruits, the thickness of slicing and slicing will be slightly different.

15.This product is suitable for cutting melons, fruits, and vegetables; do not exceed the product use range.

16.This product is only suitable for personal or family use, not for commercial use.

17.The battery must be removed from the appliance before disposing of it.

18.When removing the battery, the appliance must be powered off, and the battery should be disposed of safely. Perform the following steps to remove the battery:

a.Remove the plastic cover at the handle.

b.Cut off the power supply of the positive and negative electrodes of the battery respectively, and wrap the power cord heads of the positive and negative electrodes of the battery with electrical tape.

c.The battery should be disposed of safely, and the battery should be put into the designated recycling location or handed over to the environmental protection recycling department for disposal.



Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
Website: <https://www.greenlion.net/>
Sales: sales@greenlion.net
Service Support: Support@greenlion.net
Telegram: [@greenlion_global](https://t.me/greenlion_global)
Instagram: [@greenlion_global](https://www.instagram.com/greenlion_global)