

**PORODO**  
**LIFESTYLE**



**Porodo Lifestyle**  
**Portable Exhaust Fan**

SKU: PD-LSPMSE

# Table of Contents


Features	2
Schematic View	2
Installation Guide	3
Filter Installation	3
Specifications	4
Safety Warnings	4
Usage Precautions	5
Warning	6
Warranty	6
Contact Us	6

Before installing and using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

## Features


1. This fan features a powerful suction mechanism that significantly enhances air quality by effectively removing smoke and odors, ensuring a fresher cooking environment.
2. The filter is designed for easy removal and can be washed, allowing for repeated use and supporting sustainability efforts.
3. Equipped with a high-efficiency polymer filter, it effectively traps grease, smoke, and water vapor, preventing the spread of cooking odors and contributing to a cleaner cooking atmosphere.
4. The fan comes with a versatile three-speed setting that can be adjusted to match different cooking scenarios, providing flexibility and enhancing user comfort.

## Schematic View




# K Installation Guide

**1.** Notice the triangular markers on both the product case and the fan housing. Align these markers to ensure the components fit perfectly in a vertical position.




**2.** Once the fan is positioned within the casing, rotate it following the direction indicated by the icon until it clicks into place, confirming it is securely locked. To disassemble the fan, rotate it in the direction opposite to the icon to unlock and remove it.




## K Filter Installation


Rotate the air inlet mask to the left to unlock it from the product case. Once unlocked, remove the middle filter for cleaning or replacement.



**1.** Find the triangle sign on the product case and the lock icon on the air inlet mask. Align these markers precisely to ensure they fit perfectly into the housing after vertical alignment.



**2.** After positioning the mask within the case, follow the direction indicated by the icon and rotate it until it clicks securely into place. To remove the mask, rotate it towards the icon's direction to unlock and gently pull it out.



## Specifications

Product Name	Porodo Lifestyle Portable Exhaust Fan
SKU	PD-LSPMSE
Rated Input	5V/2A
Power Supply Port	Type-C
Fan Speed	Level 1:2850 RPM / Level 2:3230 RPM / Level 3:3600 RPM
Product Weight	555.5g
Product Size	180×108×420mm
Standard	GB 4706.1-2005

## Safety Warnings

1. Ensure that the product is turned off and the charging cable is disconnected before cleaning, maintaining, or relocating the unit to prevent accidents.
2. The fan should be completely inactive before you start cleaning to prevent any injuries.
3. Do NOT immerse the charging cable or the main unit in water for cleaning purposes. Do not rinse under running water, and ensure that no parts of the fan become wet.
4. Do not use abrasive materials like steel wool, or harsh substances such as gasoline or other volatile corrosive liquids for cleaning the product, as these can cause damage.
5. Gently wipe the surface with a slightly damp cloth to keep it clean.
6. Ensure that all filter accessories are completely dry before reconnecting them to the power supply.
7. If the product will not be used for an extended period, store it in a dry, cool, and safe location.

- 8.** It is crucial to prevent the oil fume exhaust outlet from directing airflow towards any person.
- 9.** Make sure that no objects obstruct the air inlet or outlet during operation.
- 10.** Please use the charging cable provided to prevent electric shock and fire hazards. Replace the cable PROMPTLY if it becomes damaged to ensure safety.
- 11.** Avoid bending, bundling, dragging, or placing heavy objects on the charging cable. Keep the cable away from high-temperature sources and open flames.
- 12.** Do not attempt to modify or repair the charging cable yourself.
- 13.** Ensure that children do not have access to or play with this machine to prevent accidents.
- 14.** Avoid exposing the product to severe impacts or dropping it to prevent damage.
- 15.** Do not insert cotton swabs, iron wires, toothpicks, paper scraps, or other small objects into the air inlet and outlet.
- 16.** Always place the machine on a stable surface to avoid any damage caused by the unit tipping over or falling.
- 17.** Do not move, disassemble, or assemble parts of the machine while it is in operation, as this could lead to personal injury or machine malfunction.
- 18.** Always disconnect the power supply before cleaning, maintaining, or replacing the filter to ensure safety.

## Usage Precautions

- 1.** The filter can be replaced after extensive use if it becomes dirty.
- 2.** This product is designed for household use only. The manufacturer disclaims any responsibility for damage or injury if the product is used for non-household purposes.
- 3.** This appliance should be positioned on the same surface as other small kitchen devices during use.
- 4.** Ensure the air inlet is as close as possible to the nearby appliances to maximize smoke extraction efficiency.
- 5.** For optimal space management and ease during meals, position this appliance beside other small kitchen appliances, as illustrated.
- 6.** This product must be operated under adult supervision when used by children, the elderly, or individuals with reduced self-care capabilities to avoid accidents.

**7. Keep this appliance out of children's reach, and ensure children are educated on its proper use and not to treat it as a toy.**

## **Warning**

- 1. Store this product in conditions between -10°C to 45°C and with humidity levels not exceeding 75°C. It is imperative to avoid immersing it in water, exposing it to fire, or allowing contact with corrosive materials.**
- 2. Disassembly, squeezing, striking, knocking, or causing a short circuit with this product is strictly prohibited.**
- 3. Keep this product out of reach of children to prevent potential injuries.**

## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**porodo.net/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:  
**info@porodo.net**  
Website: **porodo.net**  
Service Support: **support@porodo.net**  
Instagram: **porodo**