

PORODO
LIFESTYLE



Porodo Lifestyle
Powerful Portable Go-Blender

SKU: PD-LFST017

Table of Contents

Features	2
Schematic View	2
Specifications	3
Indicator Light	3
First Use	4
Instructions for Use	4
Safety Precautions	5
Troubleshooting	5
Notes	6
Warranty	7
Contact Us	7

Features

1. Equipped with six high-quality 304 stainless steel blades for efficient and consistent blending every time.
2. Constructed from food-grade materials to ensure safe and reliable performance for all your blending needs.
3. Features a secure lid and an attached rope for spill-free blending and easy transport.
4. Includes a robust 220-watt motor capable of crushing ice, enhancing its versatility for various recipes.

Schematic View



Specifications

Battery Capacity	2000mAh ×2
Input	5V/1A
Charging Port	Type-C
Power	150W (220W Peak)
Recharge Time	3 hours
Blending Time	30 seconds per cycle
Total Working Time	Up to 20 cups
Jar Capacity	450ML
Jar Material	AS Material
Base Material	ABS
Blade Material	304 Stainless Steel
Net Weight	510g
Certifications	CE, ROHS, FCC

Indicator Light

A. Operation

Blending	Continuous Flashing: All indicator lights will continuously flash.
Charging	Indicator lights will flash slowly to show the current battery level.
Low Battery	All indicator lights will flash in red light during blending.
Fully Charge	All indicator lights will turn on in blue light when the blender is powered on.

B. Battery Level



100%-75 %	4 blue lights on
50%-74 %	3 blue lights on
25%-49 %	2 blue lights on
1%-24 %	1 blue light on

First Use

1. Verify that your blender is fully charged by confirming all indicator lights are illuminated before you begin blending.
2. Securely tighten the blender body and base until the magnet aligns with the power button.
3. Press the power button twice to initiate the blending process.
4. Clean the blender immediately after use to maintain optimal condition.

Instructions for Use

Starting and Stopping: Press the power button twice to begin operation. To halt blending, press the button once. To check the battery level while the blender is idle, press the power button once.

Step 1: Chop the fruits into small pieces and add them to the blender jar until it is approximately 60 % full.

Step 2: Pour water into the jar until it reaches 80 % of its capacity.

Step 3: Secure the lid firmly and tilt the blender slightly to ensure that no fruit pieces are trapped under the blades.

Step 4: Press the power button twice to start the blending process.



Step 1



Step 2



Step 3



Step 4

Safety Precautions

1. Do not remove the lid or insert any rigid objects into the blender during operation.
2. Avoid submerging the base in water to prevent damage to internal components. Ensure the blender is turned off before cleaning.
3. Do not use a microwave or hot water above 80°C to disinfect the blender.
4. Do not store the blender in a freezer.
5. Avoid using metallic spiral balls or other abrasive objects for cleaning to prevent scratches and damage to the blender.
6. Do not use a dishwasher to clean the blender.
7. Ensure the blender is dry before charging to prevent electrical hazards.
8. Do not attempt to repair or disassemble the blender yourself as this could void the warranty. If a malfunction occurs, please contact authorized service professionals.

Troubleshooting

Problem	Possible Cause	Solutions
All indicator lights are turned on in red color, indicating that the blender cannot start.	The blender has run out of battery.	Ensure a full charge by charging the blender for 4 to 5 hours.
All indicator lights flash alternately in red and blue, indicating that the blender is unable to start.	The jar is not securely fastened to the base.	Tighten the jar and base adequately. Confirm that the magnet aligns with the power button for proper functionality.
The blender stops working after 4 seconds of operation.	The blender jar is empty.	To start blending, add the required ingredients into the blender.
The blender stops working, and all indicator lights flash in red for 5 seconds.	The ingredients are too thick or the jar is overloaded.	If the mixture is too thick, either add some liquid or cut the ingredients into smaller pieces, then restart the blender.
The system has detected a leakage.	The sealing ring is not correctly positioned.	Make sure the sealing ring is correctly positioned to avoid any leakage.

Notes

1. This product is compatible with USB Type-C cables and can also be charged using a power bank.
2. If the product has not been used for an extended period, fully charge the battery before use to maintain it in a high voltage state and prevent damage.



Food Contact Compliance



Keep Away From Fire



Non- microwavable



Fragile



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**