

**PORODO**  
LIFESTYLE




**Porodo Lifestyle**  
**Sonic Vibration**  
**Facial Cleaning Brush**

SKU: PDLFST193PK

# **Table of Contents**

Product Overview	2
Cleaner Benefits	3
Cleaner Function	3
Cleaner Feature	3
Battery Guide	3
Usage Guide	4
Warning and Precaution	4
Specifications	5
Disposal	6
Warranty	7
Contact Us	7

## Product Overview



## **Cleaner Benefits**

The brush head is crafted from special materials, enhancing its cleaning and moisturizing capabilities. It utilizes comfortable materials and incorporates vibration technology to stimulate blood circulation, effectively improving cleaning and beauty results.

## **Cleaner Function**



1. The head is made from specialized materials to better penetrate and clean deep into the pores.
2. Use it with a cleaning product to achieve faster and more effective skin cleaning.
3. It also features a vibrating function to massage the skin.

## **Cleaner Feature**

1. High-frequency vibration of 6000 times per minute.
2. Compact and portable design for easy carrying.

## **Battery Guide**

1. Insert the power cord into the power socket.
2. Connect the USB to the power plug and then to a power supply or computer.



USB interface for charging

## Usage Guide

1. Apply a suitable amount of cleanser to the face, turn on the device, and adjust the intensity using the + and - buttons for cleaning and massaging.
2. Press once more to adjust the speed.
3. The device features 5 speed levels and 3 modes for various uses. Select your preferred option and proceed.
4. Start at your chin and gently move the massager upward along your jawline, towards your ear, and out onto your cheek. Repeat on the other side of your face, along your forehead and nose.
5. Press the heated importing selection button to activate the heating mode for enhanced skin absorption.
6. To turn off the unit, press the power button again.

## Warning and Precaution

1. Do not use the device while charging.
2. Do not disassemble or modify the device.
3. Keep the device out of reach of children.
4. Do not use the device in high-temperature environments or expose it to direct sunlight.

- 5. Do not use silicon-soluble or granular cleansers with the device to avoid damage.
- 6. After use, rinse the device with clear water and gently dry with a clean towel.
- 7. If you experience any discomfort or skin irritation, consult your doctor immediately.

## Specifications

Input	5V/1A
Battery Capacity	400mAh
Operating Time	3.5H (Vibration Mode), 30Min (Heat Mode)
Water-Resistant Level	IPX6
Charging Time	2H
Net Weight	112g
Charging Interface	USB-C
Product Size	161 x 31 x 54mm
Model Number	LFS193

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.





## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**porodo.net/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:  
**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**