

PORODO
LIFESTYLE




Porodo Lifestyle
Pocket Size
Handheld Fan

SKU: PDLSPF2228

Table of Contents

Product Overview	2
Instructions for Use	2
Specifications	3
Battery Life and Charging Information	4
Safety Precautions	4
Disposal	4
Warranty	5
Contact Us	5

Product Overview



Instructions for Use

1. Fan Operation:

- 1.1 Press the power button once to turn on the fan. You can then cycle through five speed settings (1 to 5). The current speed will appear on the screen.
- 1.2 After 3 seconds of inactivity, the screen will automatically show the battery level instead.

1.3 To turn off the fan, press the power button again. The screen will also turn off.

1.4 To quickly turn off the fan at any speed, press and hold the power button for

2. Charging Indicator:

2.1 While charging, the screen will flash to show the battery level.

2.2 When the battery is fully charged, the screen will display "100%" and stays on.

Specifications

Input	5V/2A
Rated Power	5W
Charging Port	Type-C
Battery Capacity	2000mAh
Motor Speed	19100RPM
Operating Time	up to 7 Hours
Charging Time	2.2 Hours
Dimensions	39 x 43 x 102 mm
Model	LFS2228

Battery Life and Charging Information

Charging Time: Approximately 2 hours and 20 minutes for a full charge.

Working Time (Battery Duration):

Level 1 (20% speed): Up to 7 hours of use.

Level 2 (40% speed): Up to 5.5 hours of use.

Level 3 (60% speed): Up to 3.5 hours of use.

Level 4 (80% speed): Up to 2 hours and 50 minutes of use.

Level 5 (100% speed): Up to 2 hours of use at maximum speed.

Safety Precautions

- 1.** Use only a 5V USB charger for this product. Using a charger with too high or too low voltage may cause damage.
- 2.** Never insert your fingers or objects into the fan's protective net while the motor is running. This can cause injury and damage the fan.
- 3.** Do not stop the fan blades with hard objects. This may damage the motor or control circuit due to excessive current.
- 4.** If not in use for over 3 months, charge the fan to 75% capacity before storing. Keep in a cool, dry place.
- 5.** Children under 10 should use the fan only under adult supervision.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at porodo.net/warranty and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
[**porodo.net/warranty**](http://porodo.net/warranty)

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**