
#### PORODO



### **Porodo**

### **Kids Daily Dua and Surah**

SKU: PD-KDDUAC

# Table of Contents

Overview	2
Product Features	2
Button Functions	2
Instructions for Use	3
Precautions	3
Disposal	4
Warranty	4
Contact Us	4



This product is a sound-enabled DUA (prayer) learning wall chart, specifically designed for children. The chart is equipped with a button-operated audio feature, which allows children to listen to prayers. It helps children learn and memorize prayers (DUA) in both English and Arabic.

#### Product Features

- 1. Convenient Learning: The wall chart features one-touch playback of DUA prayers, helping children learn quickly and efficiently.
- 2. Bilingual Support: Supports both English and Arabic audio playback for an inclusive learning experience.
- **3.** Volume Control: Allows for volume adjustment, ensuring protection for children's hearing.
- 4. Easy Operation: The button-based design makes it simple for children to operate independently.
- **5.** Energy Efficient: Powered by three AAA batteries. There is no need for charging and batteries are easy to replace.

#### **Button Functions**

Button 1(-): Decrease volume

Button 2 (-): Decrease volume


**Button 3: Play English Reading** 

**Button 4: Play Arabic Reading** 

**Button 5:** Power Off

Button 6 (Surah): Play Surah

Button 7 (DUA): Play DUA



#### Instructions for Use

- 1. Open the battery compartment cover.
- 2. Correctly insert three AAA batteries, ensuring the correct orientation of the batteries.
- 3. Press any playback button to turn on the device.
- 4. Press Button 1 or Button 2 to decrease the volume.
- **5.** Press Button 3 to play English reading.
- 6. Press Button 4 to play Arabic reading.
- 7. Press Button 6 to play Surah.
- 8. Press Button 7 to play DUA.
- 9. Press Button 5 to turn off the device.

#### **Precautions**

1. Do not pull or fold the wall chart, as it may damage the internal circuitry.

- 2. Avoid exposure to water to ensure the longevity of the device.
- **3.** When replacing batteries, ensure they are inserted in the correct direction to prevent damage.
- 4. If the device is not in use for an extended period, remove the batteries to prevent leakage and potential damage to the device.

### Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

### Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo