

**PORODO**  
**LIFESTYLE**



**Porodo Lifestyle**  
**Air Suction Beard and**  
**Body Trimmer**

SKU: PD-LFST063

# Table of Contents

Precautions	2
Package Contents	2
Product Overview	3
Specifications	3
Charging Instructions	4
Adjusting Trimming Degree	4
Suction and Clog Protection Features	5
Digital Display	5
Instructions for Use	7
Notes for After Trimming	7
Cleaning and Maintenance	8
Replacing the Head	8
Disposal	9
Warranty	9
Contact Us	9


## Precautions

**Warning:** Before washing the portable unit in water, disconnect it from the power cord.

1. This product uses a type-C charging cable. You may use a charger with a 5V/1A adapter or charge it using the USB port of a car or computer.
2. If the charging cable is damaged, replace it immediately to prevent hazards. All repairs should be carried out by a professional service technician. Do not attempt to disassemble or repair the appliance on your own.
3. Do not place the trimmer under direct sunlight or near other heat sources.
4. The product should be charged and stored in temperatures between 5°C and 35°C.
5. Ensure that both the charger and the charging cable are dry. Do not plug in or unplug the device with wet hands to avoid electric shock.
6. Before use, check that the blade and comb are not damaged or deformed to prevent skin injuries.
7. Clean the unit with clean water, but do not submerge the product in water.
8. Do not use salt water, hot water above 60°C, thinners, gasoline, alcohol, or other chemicals to clean the electric trimmer.
9. During use and charging, the product may become slightly warm. This is normal.
10. Keep away from children, infants, and pets.
11. Do not attempt to disassemble or repair the device yourself as it may result in damage and injury. Instead, refer the product to a professional service center.
12. If the device has been dropped or subjected to impact, do not use it and refer it to a professional service center for inspection.
13. Avoid leaving the product in a car on hot days to prevent heat damage.

## Package Contents

1. Hair Clipper
2. Facial Hair Comb (1-10mm)
3. Beard Comb (11-20mm)
4. Charging Cable
5. Cleaning Brush



## Product Overview



## Specifications

Battery Capacity	1400mAh
Input	DC 5V/1A
Rated Power	5W
Recharge Time	3H
Working Time	90min
Motor Speed	8000RPM
Waterproof Rating	IPX6
Weight	224g

## Charging Instructions

1. When the display indicates the remaining battery level is "05", the battery level icon will start flashing as a reminder to begin the charging process. Once the battery is fully charged, the display will show "—".
2. Insert one end of the charging cable into the device, then connect the other end to a charger with a 5V/1A output, or alternatively, plug it into a computer or car USB port with a 5V/1A output.
3. Upon connecting to a power source, the display will light up and the numbers in motion on the display will increase as the charge duration extends, indicating that the device is actively charging.
4. A complete charging cycle typically takes about 3 hours. Once the charge is complete, the display will show "—", indicating that the unit is fully charged and ready for approximately 90 minutes of use.

## Adjusting Trimming Degree

### **[A]** Facial Hair Comb

As illustrated, the facial hair comb features an adjustable range of 1 to 10 mm. Its central notch design effectively aids in removing facial hair. The beveled teeth of the comb are designed to prevent any blockage around the nose area during use.




### **[B]** Beard Comb

As shown, the beard comb has an adjustable range of 11 to 20 mm. The comb features an open serrated edge to facilitate better beard care during the trimming process.




## **[C] Adjustment Button**

As depicted, the adjustment button on this product operates through a rotating wheel mechanism, allowing for effortless fine-tuning. Each increment during adjustment corresponds to 1 mm. The outer scale, marked as 1 to 10 mm, pertains to the readings for the facial hair comb, while the inner scale 11 to 20 mm applies to the measurements for the beard comb.



## **[A] Suction and Clog Protection Features**

**[A]** This device offers dual-setting vacuum suction capabilities, providing strong suction force with minimal noise. During the trimming process, the hair is collected in the storage chamber, which can be easily cleaned after use.




**[B]** This product features a built-in protection mechanism. If the blade becomes entangled with hair, the device will automatically shut off to maximize product protection. To resume operation, simply restart the device.

## **[A] Digital Display**

### **[A] Battery Level Indicator**


This product is equipped with a battery level display. During use, a countdown is displayed from '—' to '99' to '0'. When the battery level reaches '05', it begins

to flash as a reminder to charge the device. A fully charged battery is indicated by '—'.




### **[B] Travel Lock**

The travel lock feature prevents accidental activation due to vibrations during transportation. To enable or disable the travel lock, press and hold the power button for 3 seconds.




### **[C] Cleaning Reminder**

After 5 minutes of continuous operation, a cleaning reminder icon will light up on the display, prompting the user to clean the hair storage chamber.




### **[D] Overvoltage Protection**

The device's chipset includes an overvoltage protection feature. If the charging voltage exceeds preset levels, the plug icon and exclamation mark (!) on the display will light up simultaneously before turning off after 3 seconds.




## Instructions for Use


1. Select the comb that best suits your grooming needs and attach it to the device. Adjust the rotary wheel to the desired length. Keep in mind that the two available combs offer different functionalities and sizes; choosing the right one can optimize the efficiency of your cut.
2. Press the power button to turn on the unit.
3. Guide the beard trimmer in a straight line along the direction of the blade while maintaining contact with the skin.



1



2




3

## Notes for After Trimming

1. After completing the haircut, remove the comb.
2. Use your thumb to eject the cover of the hair storage chamber.
3. Empty the contents of the hair storage chamber into a trash container.
4. The chamber can be rinsed under the faucet.
5. Once rinsed, ensure that the chamber is dry before replacing the cover in its original position.

**Caution:** Do not use damaged cutting heads, as this could cause skin injuries. If you find a damaged head, replace it immediately with an original head.





## Cleaning and Maintenance

1. Before cleaning, ensure the unit is disconnected from the charging cable and that the device is turned off.
  2. The head can be easily detached by hand.
  3. This device is rated IPX6 for water resistance and can be washed directly under running water.
- Warning:** Do not submerge the whole device in water.
4. After washing the washable components, drain any excess water, lay the device horizontally, and allow it to air dry.

## Replacing the Head

For an optimal experience, it is recommended to replace the head at least every 6 to 8 months. Except for any damage due to external factors, the unit is designed for prolonged use. Only original manufacturer heads should be used for replacements in case of any damage.



## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **[porodo.net/warranty](https://porodo.net/warranty)** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

**[porodo.net/warranty](https://porodo.net/warranty)**

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:

**[info@porodo.net](mailto:info@porodo.net)**

Website: **[porodo.net](https://porodo.net)**

Service Support: **[support@porodo.net](mailto:support@porodo.net)**

Instagram: **[porodo](https://www.instagram.com/porodo)**