

**PORODO**  
**LIFESTYLE**



**Porodo Lifestyle**  
**Polarised Sunglasses**  
**with Speaker**

SKU: PD-LFST075

# Table of Contents

Power On and Off	2
Connection Guide	2
Instructions for Use	3
Playback Controls	4
Voice Assistant Activation	4
Charging Guide	5
Specifications	5
Disposal	6
Warranty	6
Contact Us	6



## Power On and Off

### [A] Power On

1. Press and hold the button on both the left and right legs for 3 seconds to power on.
2. The device will also start automatically when charging is stopped.
3. A "Power On" prompt will be heard.

### [B] Power Off


1. Press and hold the button on either the left or right leg for 4 seconds to turn off the device and disconnect Bluetooth.
2. A "Power Off" prompt will be heard.
3. The device will automatically power off when charging.




## Connection Guide

1. Power on the glasses, open your phone's Bluetooth settings, and search for "Mi 11 Ultra".
2. Select the device to establish a connection.
3. Upon successful connection, a "Connected" sound prompt will be emitted.
4. If the device disconnects, a "Disconnected" sound prompt will be emitted.

**During Pairing:** The red and blue lights will flash alternately, indicating the device is in pairing mode.




**After Pairing:** Once the Bluetooth connection is established, the blue LED will flash once every 5 seconds.




## Instructions for Use

- 1.** Answer or Hang Up Calls: Short press the button on either the left or right leg to answer or hang up a call.
- 2.** Refuse Calls: Long press the button on either the left or right leg for 1 second to reject an incoming call.
- 3.** Switch Conversation to Receiver: Long press the button on either the left or right leg for 1 second to transfer the conversation from the glasses to the receiver.
- 4.** Adjust Volume During a Call:
  - a.** Double-click the button on the left leg to decrease the speaker volume.
  - b.** Double-click the button on the right leg to increase the speaker volume.
- Note:** Adjusting volume is not supported during a three-way call.
- 5.** Transfer Calls to Three-Way Mode: When receiving another incoming call while already on a call, short press the button on either the left or right leg once to switch to three-way mode.
- 6.** Hang Up Current Call to Answer Another: Long press the button on either the left or right leg for 1 second to end the current call and answer the incoming call.
- 7.** Keep Current Call and Reject Another Call: Double-click the button on either the left or right leg to keep the ongoing call and reject the incoming call.




## Playback Controls

1. Play or Pause Music: Short press the button on either the left or right leg to play or pause music.
2. Decrease Volume: Double-click the button on the left leg to lower the volume.
3. Play Previous Track: Triple-click the button on the left leg to play the previous track.
4. Increase Volume: Double-click the button on the right leg to raise the volume.
5. Play Next Track: Triple-click the button on the right leg to play the next track.




## Voice Assistant Activation

While in standby mode or listening to music, long press the button on either the left or right leg for 2 seconds to activate or deactivate the voice assistant.



## Charging Guide

- 1. Auto Power-Off:** The glasses will automatically turn off after 5 minutes of inactivity.
- 2. Charging Indicator:** During charging, the red LED remains steadily lit.
- 3. Charging Complete:** Once charging is completed, the LED light will turn off.



**Charging:** While charging, the red LED remains steadily lit.

**Charging Complete:** When charging is finished, the LED light will turn off.

## Specifications

Battery Capacity	110mAh*2 (220mAh)
Recharge Time	2h
Standby Time	160h
Talk Time	6h
Play Time	4h
Lens Material	Nylon
Bluetooth	V5.3
Transmission Range	9m
Product Weight	48g
Function	Open-Ear Audio, Touch Control, Hands-Free Calls, Voice Assistant

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **[porodo.net/warranty](https://porodo.net/warranty)** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**[porodo.net/warranty](https://porodo.net/warranty)**

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:

**[info@porodo.net](mailto:info@porodo.net)**

Website: **[porodo.net](https://porodo.net)**

Service Support: **[support@porodo.net](mailto:support@porodo.net)**

Instagram: **[porodo](https://www.instagram.com/porodo)**