

PORODO
LIFESTYLE



Porodo Lifestyle


Portable Heated Styling Brush

SKU: PD-LFST142-BK


Table of Contents

Product Overview	2
Instructions for Use	3
Straightening and Styling	4
Specifications	5
Creating Curls	5
Attention	6
Disposal	6
Warranty	7
Contact Us	7


Product Overview




Step 1: Take off the protective cover.



Step 2: Charge with a type-C cable.




Step 3: Connect the USB cable (2A or higher) to a power supply.



Instructions for Use

Connect the power supply. Press and hold the power button to turn the device on. Press the button briefly to adjust the temperature to your desired setting.



Tips:

The light will flash while the product is preheating and will stop once the set temperature is reached.

The flashing state may vary depending on the season or environmental temperature. If the product is flashing but the heating plate is functioning normally, this is a standard occurrence and does not affect performance.

It is recommended to preheat the product for 5-3 minutes to ensure the heating plate is evenly heated before use.

Attention:


Avoid covering the product with the protective cover while charging.

If you're not using a heat insulation pad, ensure that no flammable or poorly heat-resistant objects are placed nearby, as this may cause discoloration or deformation.

Note: A slight smell may occur during charging, which is completely normal.

Point:

The front end of the comb remains unheated, ensuring that you won't burn yourself when holding it.



The bottom of the comb features a circular metal plate that generates heat.

Important:

The part will become hot, so avoid touching it directly.

Preset temperature rise: it takes 2 minutes to reach 100°C and 5 minutes to reach 170°C.

Straightening and Styling

Straightening Your Hair: Place the comb into your hair and gently pull with one hand. Slowly release the hair from the roots, combing outward to enhance shine.



Styling Bangs: Insert the comb into your bangs and move it in a circular motion towards the tips of your hair for a smooth, styled finish.



Important Reminder: Do not leave the comb in one spot for more than 10 seconds to prevent potential damage to your hair.

Specifications

Rated Power	35W
Working Voltage	5V
Rated Frequency	50/60Hz
Battey Capacity	4000mAh
Working Time	1H
Charging Interface	USB-C
Heating Plate	PTC, Ceramic
Temperature Control	160°C, 180°C, 199°C
Net Weight	208g
Model Number	LFS142

Creating Curls

Inner Curls: Begin by holding the ends of the hair you wish to curl, starting from the inner side of the hair. Comb through, wrap the hair around the straightener comb, curl inward for a few seconds, and then gently remove the comb.



Outer Curls: Hold the ends of the hair to be curled, starting from the inner side. Comb through, wrap the hair around the straightener comb, curl outward for a few seconds, and then carefully remove the comb.



Upward Curls: Lift the top section of your hair and secure it at the root using the straightener comb. Hold for 4 to 6 seconds, then gently glide the comb through your hair in a circular motion to create a voluminous curl.



Attention

1. Do not use this product with household hair straighteners, liquid Bama containing reducing agents, or deodorants containing "ammonium tyrosine" and "cysteine."
2. If you have had a straightening treatment at a beauty salon or other places, avoid using this product within 3 to 4 days.
3. If you have recently dyed your hair, do not use this product within 2 to 3 days.
4. After using disposable hair dye, rinse thoroughly with shampoo and allow your hair to dry completely before using this product. Using the product while your hair is wet may cause the dye to fade.
5. Do not use if your hair is severely damaged.
6. This product is a one-time hair straightening solution. Its effectiveness may vary depending on the hair's condition and quality.
7. This straightening comb is not designed for shrinkage correction.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**