

**PORODO**  
LIFESTYLE



**Porodo Lifestyle**



**Multifunction Cooling Waist Fan  
with 10000mAh Power Bank and Flashlight**

SKU: PD-LFST164

# Table of Contents

Schematic View	2
Package Contents	3
Instructions for Use	3
Usage procedure	3
Specifications	4
Attention	4
Disposal	4
Warranty	5
Contact Us	5

**Schematic View**



## Package Contents

1. Waist Fan
2. USB Charging Cable
3. Lanyard

## Instructions for Use

1. The device operates using a lithium battery power supply.
2. Five-Speed Wind Adjustment:
  - 2.1 Press the power switch button to start the fan, beginning at the lowest wind speed.
  - 2.2 Press the button repeatedly to increase the wind speed until the highest setting is reached.
  - 2.3 Press the switch again to turn off the fan at the highest speed.
3. To activate the flashlight mode, press the lighting button. For SOS mode, long-press the button for 2 seconds, then press again to turn off the flashlight.
4. The display will show the current power supply and fan speed when the device is powered on.
5. The minimum wind speed is soft, while the maximum wind speed is strong, producing low noise. The airflow distance is long.
6. The device supports USB charging while in use, allowing continuous operation.
7. The device is designed to be worn around the waist for easy access or hung around the neck for hands-free use, offering both cooling and hand-blowing functions.

## Usage procedure

1. Attach the waist hook to a belt or strap, and adjust it to a comfortable position.
2. Use the clothes hooks to fasten the corners of your clothing, ensuring the air inlet remains unobstructed by the fabric.
3. Switch on the fan and adjust the speed to your preferred comfort level.

## Specifications

Model Number	LFS164
Battery Capacity	10000mAh
Input	5V/2A
USB Output	5V/2A
Recharge Time	4H
Working Time	Up to 40H

## Attention

1. Do not place this product near heat sources or in areas with high temperatures.
2. Avoid placing the product in humid environments.
3. When cleaning this product, ensure the power is turned off, and carefully wipe the surface.
4. Do not use metal, acidic or alkaline chemicals, detergents, or other cleaning agents that may damage the product.
5. Do not attempt to disassemble the product yourself. If the product is damaged, please contact a professional for maintenance.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

**porodo.net/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:

**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**