



Porodo Lifestyle

Dual Mode Air Duster and Vacuum

SKU: PD-LFST179-BK

Table of Contents

Package Contents	2
Product Overview	3
Button Instructions	3
Instruction for Use	4
Safety Notes	5
Specifications	6
Charging Guide	6
Disposal	7
Warranty	7
Contact Us	7

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Package Contents



- 1. Porodo Lifestyle Dual Mode Air Duster and Vacuum
- 2. Detachable Nozzles: Needle Nozzle, Wide Nozzle, Brush Nozzle, Concentrator Nozzle, Wide Mouth Nozzle
- 3. USB Type-C Cable
- 4. Dust Collector

Product Overview



Button Instructions

Power Switch

1	High Low	Speed Adjustment
	Press and Hold	Power On and Off

Charging Port

	Before each use, it is recommended to fully charge the product.	
	White light is flashing.	Charging
	Solid light is on.	Fully Charged


Instructions for Use



Press the on/off switch 3 times to toggle between blower and vacuum functions.

Caution: Connect the dust collector before switching to vacuum mode.

Note: When using the pressurized air nozzle for inflation, ensure the air valve is open for rapid inflation. See the illustration below.



Release the nozzle from the nozzle hole and attach it to the air outlet.

Safety Notes


- 1. It is not recommended to use the product while charging, as it will not charge during operation.
- 2. If the device will be idle for an extended period, ensure that the battery is fully charged before storing. Store the device in a low humidity environment.
- 3. Keep away from children.
- 4. Do not disassemble or repair the product yourself.
- 5. Keep away from heat or fire, and protect the device from impacts.

Specifications


Input	DC 5V
Rated Power	160W Max
Charging Interface	USB-C
Working Voltage	7.4V
Battery Capacity	2 ×2500mAh
Noise Level	<90dB
Motor Speed	130000RPM
Usage Time	Up to 3H
Wind Speed	10~50m/s
Working Temperature	-10°C~50°C
Product Size	40 x 106 x 140mm
Model Number	LFS179

Charging Guide

Our product can be charged using the following devices:







Car Charger



Powerbank



Computer



This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo