

Porodo Soundtec

GLIMPSE Earbuds with Touch Display

SKU: PD-STWLEP039

Table of Contents

Specifications	2
App Connectivity	2
[A] Download the App	2
[B] Pairing the Charging Case	2
[C] Pairing the Earbuds	3
Product Overview	3
Instructions for Use	4
Home Page Description	6
Warranty	6
Contact Us	6

Thank you for choosing this product. To fully understand the features and capabilities of your device, we highly recommend reading this manual thoroughly. The smart headphones primarily connect to your mobile device via Bluetooth, offering a range of practical features and services to enhance your user experience.

Specifications

Battery Capacity	300mAh	
Recharge Time	1.5H	
Playtime	4H	
Charging Interface	Type-C	
Bluetooth	5.4	
Transmission Range	10m	
Bluetooth Name	PD-STWLEP039	


App Connectivity

[A] Download the App

Search for "Fere Fit" in the App store or Google Play store to download and install the app. After installation, please register and log in.

[B] Pairing the Charging Case

- 1. Once the charging case is powered on, swipe right on the home screen to find the "About Device" section, and remove the earbuds from the case.
- 2. Enable Bluetooth on your mobile device, open the app, and tap the "+" icon to search for and add the device. Select the device to initiate pairing, and allow notifications when prompted.
- **3.** To connect to audio Bluetooth, go to your mobile device's Bluetooth settings, search for and select the connected audio Bluetooth device.



Once the charging case is connected, open the top cover but do not remove the headphones immediately. Wait for three seconds to allow the headphones to connect automatically.




[C] Pairing the Earbuds

- 1. The earphones will automatically pair when removed from the charging case.
- 2. If the earphones do not pair successfully after removal, place them back into the charging case, close the lid, then open it again and press and hold the button for 3 seconds to initiate pairing.



Product Overview



Instructions for Use

Music Playback	Play/Pause	Press the multi function button (MFB) once to activate the function.
	Next Track	Double-tap the Right multi function button (MFB).
	Previous Track	Double-tap the Left multi function button (MFB).
	Increase/Decrease Volume	Slide the multi function button (MFB) up or down.
	Auto Play/Pause	Wear or Remove the earbuds
Basic Functions	Power On	Turn on the charging case manually or open charging case lid and take out the earbuds to power on automatically.
	Power Off	The headphones will automatically shut down after 1 minute of inactivity without a Bluetooth connection.
	Auto Pairing	Earbuds automatically pair with the charging case.
	Manual Pairing	Open the lid and press and hold the power button for 3 seconds.
Charging Case Functions	Power On	Press and hold the power button for 3 seconds.
	Power Off	Navigate to "Setting" and select "Shut Down" on the display screen.
	Turn On/Off the Screen	Press the power button.
	Return to Home	Press the power button.





Play/Pause/Answer Call/End Call

Double-tap

Play the previous track.

Slid up and down

Increase or decrease volume.





• Single-tap

Play/Pause/Answer Call/End Call

• Double-tap

Play the next track.


Slid up and down

Increase or decrease volume.

[A] Powering on for the First Time

Press and hold the power button for 3 seconds to turn the device on. Then, select your preferred language and scan the QR code for the app or search for the connected device.








Automatic power on after 3 seconds of pressing the button


[B] Wallpaper Selection


You can choose a separate lock screen wallpaper and background wallpaper.






[C] Additional Settings





Click to take a photo

12:36 100% 12:36



Home Page Description



- Proom Earphone is out of the charging case and battery level is displayed.
- 1100% Earphone is in the charging case and battery level is displayed.
- Charging case battery level indicator
- Bluetooth connection status indicator

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **https://porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

https://www.porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo