



Porodo Lifestyle OPTIX Smart Glasses with Audio

SKU: PDSGUVP119

Table of Contents


Package Contents	2
Schematic View	2
Function Guide	2
Charging Your Sunglasses	3
Pairing with a Bluetooth Device	4
Playing Your Music	5
Phone Calls	5
Remote Control Photography	5
Specifications	5
Disposal	6
Warranty	6
Contact Us	6


Package Contents

- 1. Smart Sunglasses
- 2. Charging Cable
- 3. Cleaning Cloth

Schematic View

- 1. Microphone
- 2. Charging Indicator Light
- 3. Multi-function Button
- 4. Magnetic Charging Contact Area
- 5. Speaker





Schematic View

a. Charging Indicator Light:

Red LED On: Indicates the sunglasses are charging.

Red LED Off: Indicates the sunglasses are fully charged.

b. Multi-Function Button (MFB):

Power On: Press and hold the MFB button on both the left and right temple arms for 3 seconds.

Power Off: Press and hold the MFB button on either temple arm for 6 seconds to power off.

Voice Assistant: In standby mode or when music is paused, double-click the MFB button on any temple arm to activate the voice assistant. Press the MFB button again to turn it off.

Answer/Hang Up Calls: Press the MFB button on any temple arm to answer or hang up phone calls.

Reject Calls: When receiving an incoming call, press and hold the MFB button on either temple arm for 2 seconds to reject the call.

Play/Pause: Press the MFB button on either temple arm to play or pause the music. Next Track: Press the MFB button on the right temple arm twice briefly to skip

to the next track.

Previous Track: Press the MFB button on the left temple arm twice briefly to go back to the previous track.

Increase Volume: Press the MFB button on the right temple arm three times to increase the volume.

Decrease Volume: Press the MFB button on the left temple arm three times to decrease the volume.

Take a Picture: Press and hold the MFB button on either temple arm for 1 second to take a picture.

Charging Your Sunglasses

Your Sunglasses with TWS Earphones have a built-in rechargeable battery, allowing for portable use. Before using them for the first time, please fully charge the battery.

1. To charge, connect the supplied 2-in-1 magnetic charging cable to your Sunglasses with TWS Earphones.

- 2. Connect the other end of the 2-in-1 magnetic charging cable to a USB port on your computer or a USB wall charger (wall charger not included).
- 3. The red indicator light indicates that your Sunglasses with TWS Earphones are charging. When fully charged, the indicator light will turn off.
- 4. When the battery is running low, a low battery warning alert will sound.

Note: When you hear this alert, please recharge the battery. If not recharged, the indicator light will flash once every minute, and after three flashes, the Sunglasses with TWS Earphones will turn off automatically.

Pairing with a Bluetooth Device

- 1. Press and hold the MFB button on both the left and right temple arms for 3 seconds to power on the OPTIX smart glasses. The indicator lights on both sides will flash red and blue, and you will hear a prompt tone.
- 2. After powering on, the left and right temple arms will automatically pair. One side's indicator will flash blue every 5 seconds, while the other side's indicator will alternate between red and blue, with a prompt tone. The OPTIX smart glasses will automatically enter Bluetooth mode.
- **3.** Enable Bluetooth on your smartphone or tablet and search for available Bluetooth devices. Select "PAW119_OPTIX" from the list of devices.
- 4. Once successfully paired, you will hear a prompt tone, and the indicator lights on both sides will flash blue every 5 seconds.
- **5.** After pairing, the OPTIX smart glasses. will remember the device and automatically pair with it when the device's Bluetooth is activated and within range.
- There is no need to re-pair with previously connected devices. The Sunglasses with TWS Earphones will attempt to automatically reconnect to the last paired device if Bluetooth mode is on. If you want to pair with a new device, turn off Bluetooth on the last connected device, then search and select the new device from your list.
- **6.** If the OPTIX smart glasses. are not connected to a Bluetooth device, they will automatically shut down after 5 minutes.

Playing Your Music

- 1. When your smartphone or tablet is paired with the OPTIX smart glasses, use your music app to play music.
- 2. To play or pause your music, press the MFB button on any temple arm.

Phone Calls

- 1. Press the MFB button on any temple arm to answer or hang up phone calls.
- 2. Press and hold the MFB button on any temple arm for 2 seconds to reject an incoming call.

Remote Control Photography

- 1. Open the camera app on your device.
- 2. Press and hold the MFB button on any temple arm for 1 second to take a picture.

Specifications

Battery Capacity	2×110mAh
Bluetooth Version	5.3
Transmission Distance	10m
Control Mode	Touch
Frequency Response	2.402 GHz to 2.480 GHz
Playback Time	6H
Recharge Time	2H
Standby Time	110H
Charging Interface	Type-C
Impedance	7Ω
Product Weight	45.5g
Model Number	PDSGUVP119



This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo