



Porodo Gaming

WIRELESS MECHANICAL KEYBOARD 68-Key Tactical Keyboard with Built-in Battery

SKU: PDX214

Table of Contents

Specifications	2
Combination Keys	2
LED Control Function	3
Operation Instructions	3
1. Wired Mode (Plug & Play)	3
2. Bluetooth Mode	3
Disposal	4
Warranty	4
Contact Us	4

Specifications

Layout	US + Arabic
Switch	Xinda Black
Keys	68-Key Anti-Ghosting
Battery	Built-in 1300mAh
Wired Mode	1.5m Type-C
Weight	420g

Combination Keys

FN + ESC = ~

FN + 1 = F1

FN + 2 = F2

FN + 3 = F3

FN + 4 = F4

FN + 5 = F5

FN + 6 = F6

FN + 7 = F7

FN + 8 = F8

FN + 9 = F9

FN + 0 = F10

FN + - = F11

FN += = F12

FN + "V" = USB Mode

FN + "Z" = Bluetooth Device 1, short press to switch, long press for 3 seconds to enter pairing mode

FN + "X" = Bluetooth Device 2, short press to switch, long press for 3 seconds to enter pairing mode

FN + "C" = Bluetooth Device 3, short press to switch, long press for 3 seconds to enter pairing mode

FN + "A" = Switch to Windows Mode

FN + "S" = Switch to Mac Mode

Note: Support for Win Lock function: FN + WIN to lock Windows, repeat to unlock.

LED Control Function

Press FN + INS to switch between LED light modes.

FN + "↑" = Increase LED brightness

 $FN + "\downarrow" = Decrease LED brightness$

FN + "←" = Decrease LED speed

FN + "→" = Increase LED speed

Operation Instructions

- 1. Wired Mode (Plug & Play)
- 1.1 When the switch is set to "OFF", connect the keyboard's USB port to the PC.
- **1.2** When the switch is set to "ON", press FN + "V" to enter USB Mode, then connect the keyboard to the PC.
- 1.3 Ensure that the PC can recognize the keyboard once connected.
- 2. Bluetooth Mode
- **2.1** Turn the keyboard switch to "ON" and press FN + "Z", "X", or "C" to select a channel. Then, long press for 3 seconds to enter pairing mode.
- **2.2** Enable the Bluetooth function on your device and select "PDX214" from the list to connect.





This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo