



# **Porodo Gaming**

## **Ultra Low-Latency Gaming Earbuds**

SKU:PDX420

# Table of Contents

Product Overview	2
Specifications	2
Package Contents	3
Wearing Instructions	3
Pairing Instructions	3
Usage Guide	4
Maintenance	4
Safety Precautions	4
Warranty	5
Contact Us	5

## Product Overview



**1. Multi Function Touch Button**

**2. Sound Output**

**3. Microphone**

**4. Charging Case**

(Made from ABS material)

## Specifications


Battery Capacity	30mAh×2 (Earbuds), 200mAh (Charging Case)
Playtime	5 hours @ 50% Volume
Call Time	4 hours
Standby Time	Up to 100hrs
Charging Interface	Type-C
Speaker	Φ13mm
Bluetooth	V5.4
Transmission Range	Up to 15m
Frequency Range	2.402GHz - 2.480GHz
Response Time	<60ms
ENC	Support

## K Package Contents

1. Two earbuds
2. Charging case
3. Charging cable

## K Wearing Instructions

1. Open the charging case lid.
2. Remove the right earbud and carefully insert the speaker end into your right ear canal.
3. Gently adjust the earbud for a secure fit, ensuring it is not loose.
4. Repeat the same process for the left earbud.



## K Pairing Instructions

1. Open the charging case. Remove the earphone, which will automatically power on and enter pairing mode.
2. On your mobile phone or other Bluetooth-enabled devices, open the Bluetooth settings, search for the Bluetooth name "PDX420," and select "Connect."
3. Place the earphone back into the charging case. The red light will remain on, indicating that the earphone is charging and will automatically power off.
4. The wireless earphones can also be connected individually to other Bluetooth devices.
5. If the wireless earphones are not connected within 5 minutes, the Bluetooth function will automatically turn off.



# Usage Guide

**1. Single-tap:** Play, pause, answer calls, or hang up.

**2. Double-tap:** Increase or decrease volume.

**3. Tap three times:**

When not connected to a mobile phone: Switch between languages

When connected to a mobile phone: Adjust volume up or down.

**4. Five taps:** Switch to game mode.

**5. Press and hold for 2 seconds:** Activate Siri or reject a call.

**6. Press and hold for 4 seconds:** Power on/off the device.

## Maintenance

**1.** Avoid overcharging the earbuds unless the power level has depleted, as it can shorten the battery life and reduce its overall capacity.

**2.** If not in use for an extended period, store the earbud in a dry place. To maintain battery performance, charge the earbuds fully every 1-2 weeks.

## Safety Precautions

**Warning:** Keep away from children, infants, and pets.

**1.** Do not try to disassemble or repair the product yourself. Please contact the professional service agents for assistance.

**2.** Avoid using the product in high temperatures or near heat sources, as the built-in battery may be affected.

**3.** Use the provided Type-C cable to charge the product.

**4.** Extended exposure to loud volumes may cause hearing damage. It's recommended to set the volume at a safe level.

**5.** For your safety, avoid wearing the headset while driving, as it may cause distractions.

**6.** Be aware of your surroundings when using the headset to avoid potential hazards.

**7.** Dispose of or recycle the product following local environmental regulations.

## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**porodo.net/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:  
**info@porodo.net**  
Website: **porodo.net**  
Service Support: **support@porodo.net**  
Instagram: **porodo**