



Green Lion

Ultra 3 In 1 Vacuum Cleaner

SKU: GN3N1VC12YL

Model No: WDX15

Table of Contents

Product Overview	2
Safety Warnings	2
Specifications	4
Overview of Nozzles	5
Assembly Guide	5
Wet Vacuum Cleaning	6
Dry Vacuum Cleaning	7
Blowing Functions	8
Maintenance and Cleaning	8
Disposal	9
Warranty	9
Contact Us	9

Product Overview

1. Handle
2. On/Off Switch
3. Blower Connector
4. Top Cover
5. Air Inlet
6. Side Locks
7. Container
8. Pedestal
9. Fabric Dust Bag
10. Wheels
11. Hose
12. Sponge Filter
13. Crevice Nozzle
14. Plastic Tubes
15. Floor Brush
16. Water Suction Nozzle
17. Water Suction Nozzle Connector



Safety Warnings

1. Read the operating instructions carefully.
2. Keep the device and its accessories away from children, infants, and pets.
3. Before cleaning or maintaining the appliance, always remove the power plug from the socket.
4. If the supply cord is damaged, it must be replaced by a service agent, or a similarly qualified person to avoid a hazard.
5. Check all accessories before connecting and using them to ensure they are in the correct position and free from defects.
6. Verify that the mains voltage matches the specifications of the device.

- 7.** Always unplug the unit when not in use, before opening, and before cleaning or maintenance.
- 8.** Never clean with solvents.
- 9.** Do not use the cable to pull the plug out of the socket.
- 10.** Do not leave the unit unattended when in use.
- 11.** Keep the unit out of the reach of children.
- 12.** The power cord must be handled with care to prevent damage from being driven over, crushed, stretched, or subjected to any other form of mechanical stress.
- 13.** Do not operate the unit if the connector and the power cord is damaged.
- 14.** Replacement mains connection leads should only be used if they conform to the specifications provided by the manufacturer. The main connection cable: HO5VV-F 2x 0.75mm².
- 15.** Never use the unit be used to vacuum burning matches, glowing ashes, cigarette ends, or any substances that are inflammable, corrosive, fire-hazardous, or explosive in nature, including vapors and liquids.
- 16.** This unit is not intended for vacuuming dust that may pose a health risk.
- 17.** The unit should be stored in a dry location.
- 18.** Do not operate the unit if it is damaged.
- 19.** Servicing must only be performed by an authorized service provider. Do not disassemble or repair the product yourself.
- 20.** The unit should only be used for its intended purposes.
- 21.** Extra caution should be exercised when cleaning stairs.
- 22.** Only use attachments and spare parts supplied by the manufacturer.
- 23.** The appliance must not be used by individuals (including children) with reduced physical, sensory, or mental capabilities, or lacking experience and knowledge, unless supervised or instructed.
- 24.** Children must be supervised to ensure they do not play with the appliance.

25. Switch off the appliance and disconnect from the power supply before changing accessories or approaching moving parts during operation.

26. This appliance is intended for use in households and similar applications, including:


- Staff kitchen areas in shops, offices, and other work environments.
- Farmhouses.
- By clients in hotels, motels, and other residential-type environments.

27. Retain this manual for future references.

Specifications

Model No.	WDX15
Material	Stainless Steel + PP
Rated Power	1000W
Rated Voltage	220-240V
Rated Frequency	50/60Hz
Noise Level	94 dB
Suction Power	≥15 kPa
Flow Rate	≥25 l/s
Dustbin Capacity	12L
Waterproof	IPX4
Power Plug	BS Plug
Cord Length	3m
Product Weight	4.06 kg
Product Dimensions	270×270×400 mm


Overview of Nozzles



Assembly Guide

- 1. Warning:** Make sure the device is NOT plugged in when performing the assembly.
2. Loosen the locking hooks.
3. Remove the suction group.
4. Empty the contents of the tank.
5. Attach the wheels to the bottom of the tank.
6. Place the supplied sponge filter over the filter basket for wet vacuum cleaning.

7. Attach the paper dust bag to the suction mouth for dry vacuum cleaning.
8. Place the top cover onto the tank.
9. Ensure the clips are securely locked on the cover.
10. Insert the suction hose into the hole on the side of the tank, then connect the tubes and brush. The unit is now ready for use.




Wet Vacuum Cleaning

1. **Warning:** Make sure the device is NOT plugged in when performing the assembly.
2. Loosen the locking hooks, place the supplied sponge filter over the filter basket for wet vacuum cleaning, and then secure the clips on the cover.
3. Insert the suction hose into the hole on the side of the tank, then connect the tubes and brush.
4. Plug the device into the electrical socket.
5. Press the switch to begin operation.

6. After use or when the bin is full, resulting in a significant decrease in suction power, disconnect the plug from the electrical outlet and clean the drum.

7. To clean, unhook the two locks, remove the suction unit, and take out the filter.



D Dry Vacuum Cleaning

1. Warning: Make sure the device is NOT plugged in when performing the assembly.

2. Loosen the locking hooks, then place the supplied paper dust bag onto the suction mouth for dry vacuum cleaning.


3. Place the top cover onto the tank and secure the clips to lock the cover in place.

4. Insert the suction hose into the hole on the side of the tank, then connect the tubes and brush.

5. Plug the device into the electrical socket.


6. Press the switch to start the machine.

7. To clean, unhook the two locks, remove the suction unit, and take out the filter. When the paper dust bag is full, dispose of the ash into the dust bin.




Blowing Functions

Insert one end of the hose into the air outlet on the top cover. Then, plug the device into the socket, press the switch, and the machine will begin to operate. You can then use it to blow out the dust.



Maintenance and Cleaning

After use or when the dust tank is full, which significantly reduces suction power, unplug the device from the electrical outlet and clean the drum. To do this, unhook the two locks, then remove the suction unit and filter.



Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at [**https://www.greenlion.net/warranty**](https://www.greenlion.net/warranty) and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

[**https://www.greenlion.net/warranty**](https://www.greenlion.net/warranty)

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: [**https://www.greenlion.net/**](https://www.greenlion.net/)

Sales: [**sales@greenlion.net**](mailto:sales@greenlion.net)

Service Support: [**Support@greenlion.net**](mailto:Support@greenlion.net)

Telegram: [**@greenlion_global**](https://t.me/greenlion_global)

Instagram: [**@greenlion_global**](https://www.instagram.com/greenlion_global)