



Green Lion

GP Pro 7 Gaming Console

SKU: GNGPRO7GCBK

Table of Contents


| | |
|--------------------------|---|
| Precautions | 2 |
| Schematic View | 2 |
| Button Function Guide | 3 |
| Important Settings | 3 |
| Install Games | 3 |
| Primary Features | 4 |
| Low Battery Instructions | 4 |
| Video Output | 5 |
| System Function | 5 |
| Specifications | 6 |
| Troubleshooting | 6 |
| Disposal | 7 |
| Warranty | 7 |
| Contact Us | 7 |

Precautions

This section provides essential guidelines for the proper use of the player. Please read and follow the instructions carefully.

1. Do not strike the console.
2. Do not touch benzene, solvents, or other chemicals.
3. Do not expose the device to strong magnetic fields or electrical sources.
4. Do not expose the player to direct sunlight or heat.
5. Do not disassemble, repair, or modify the device on your own.
6. Do not use the player or headset while riding, driving, or operating a vehicle or motorcycle.
7. Do not listen at high volumes to avoid hearing damage.
8. Do not expose the console to water.

Schematic View



Button Function Guide

| | |
|--------|---|
| A | Confirm key, enter the game or start the function to use |
| B | Cancel button |
| X | Control characters to punch/shoot/jump/different interface game functions are different |
| Y | Control characters to punch/shoot/jump/different interface game functions are different |
| Return | Used to call out the game menu in the game |

Important Settings

After booting, press the "SELECT+START" key to enter the settings interface.

1. Language Setting: Go to System Settings > Language. Use the D-pad or joystick to change the language, then press the A key to confirm.
2. Brightness Setting: Use the D-pad or joystick to adjust the brightness, then press the A key to confirm.
3. Sleep Setting: Use the D-pad or joystick to set the time, then press the A key to confirm.
4. Reset Settings: Reset to factory default settings.

Install Games

1. Use your computer to read the TF card and transfer both the game file and the preview file. The game file should have the same name as the preview file.
2. Copy the files to the path "/game" in the corresponding simulator or folder.

Primary Features


1. The device has a 7.0-inch HD screen with a resolution of 1024x600.
2. It supports connection to a TV.
3. The device is compatible with TF card expansion.
4. The product supports a wired controller.
5. The device supports various game formats, including CPS, FBA, FC, GB, GBA, GBC, NEOGEO, SFC, MD, and PS, and allows users to self-download related games in the appropriate format.
6. The game search function enables users to search for a game by entering the first letter of its phonetic name.
7. The device has an instant archive function to save progress quickly.
8. The device records game history to track previously played games.
9. The standby function allows the device to save power when not in use.
10. Users can set their favorite games for quick access.
11. The device includes language settings to adjust to user preferences.
12. It offers the option to display and adjust energy-saving settings, display brightness, interface background, and other functional attributes.

Low Battery Instructions

1. When the battery level is low, the game machine may experience screen flickering or sound issues. At this time, it is recommended to charge the device promptly.
2. When the battery is low, save your progress and connect the adapter to charge the device.
3. The recommended charging voltage is 5V.

Note: It is not recommended to charge for more than 4 hours at a time.

Video Output



Primary Features

A. Main Interface

1. SELECT Button to Set Favorites/Unfavorites
2. Select any game in the game list on the main page, then press the SELECT button to set it as a favorite or unfavorite.
3. Type: Enter the game category and use the joystick or arrow keys to select the simulator type.
4. History: Display the most recently visited games.
5. Search
 - 5.1 A: Input characters
 - 5.2 B: Retract the keyboard
 - 5.3 X: Select characters
 - 5.4 Y: Delete characters

B. When playing, press the Return key to open the menu. In the menu, you can: Restart the game, Return to the game, Save your progress, Load your progress, Access the option settings, and Exit the game.

Specifications

| | |
|-------------------|---|
| Display screen | 7inch TN screen |
| Resolution | 600×1024 |
| CPU | ATM7051 Quad Core, ARM Cortex-A900 9 MHz |
| RAM | LPDDR128 2MB |
| Memory | 64GB |
| System | Linux system |
| Image function | JPG, JPEG, JPE, BMP, & PNG |
| Video format | FLV MP4 |
| Music functions | MP3 full format audio |
| Number of games | 3000+ |
| Language | Chinese, English |
| Playback function | Dual high sound quality speakers |
| Battery | Polymer lithium-ion battery 3500mA |
| TF card | TF card expansion, up to 64GB |
| Handle | Supports two wired controllers |
| Game | CPS, FBA, FC, GB, GBA, GBC NEOGEO, SFC, MD, PS |

Primary Features

Problem 1: Game console cannot be turned on.

Check if the battery is out of charge. If so, connect the USB cable or charger and try turning the console on again.

Problem 2: No sound is emitted in headphones.

1. Ensure that the volume is not set to 0.

2. Make sure the headphones are properly plugged into the jack.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
Website: <https://www.greenlion.net/>

Sales: sales@greenlion.net

Service Support: Support@greenlion.net

Telegram: [@greenlion_global](https://www.greenlion.net/)

Instagram: [@greenlion_global](https://www.greenlion.net/)