

PORODO



Porodo

FM Transmitter Car Charger 3.4A

SKU: PD-BT201D

Table of Contents

Introduction	2
Specifications	2
Features	3
Precautions	3
Instructions for Use	4
Using FM Transmitter Function	5
Using Bluetooth Function	5
Bluetooth Calling	6
Using USB Charger Function	6
Bass Music	6
Disposal	7
Warranty	7
Contact Us	7

K Introduction

Thank you for choosing the Porodo FM Transmitter. This device streams music and makes calls directly from your Bluetooth device to your car's FM stereo system. The built-in microphone offers an excellent hands-free function. It also features a Micro SD card/USB Disk slot that allows you to enjoy your favorite MP3, WMA, WAV, and FLAC files through your car's stereo system. The dual USB ports provide a total output of 3.4A for charging. Additionally, the bass button enhances your music experience. Please read the User Manual carefully before use.

K Specifications

Bluetooth Version	5.0
Bluetooth Protocol	AVRCP, HFP, A2DP
Frequency Range	87.5 to 108.0MHZ
Frequency Stability	±10ppm
Product Input	12 to 24V
Music Format	MP3\ WMA\ WAV\ FLAC
USB and TF (Max Capacity)	32GB
Charger Output	5V/3.4A
Size of Screen	4*8*20mm(yellow)
Power Supply IC	CX8826 SOP-8
Material	ABS
Product Size	43.2*38.7*85.3
Product Weight	33.8g



Features

1. Wirelessly transmit phone calls from your Bluetooth-enabled mobile phone to your car's FM stereo system.
2. Enjoy Bass Music with a single button press. Stream music from Bluetooth devices to your car's FM stereo system using the A2DP function.
3. Automatically switch to hands-free mode from music playback when receiving calls. The device features a built-in microphone.
4. Dual USB outputs (5V/3.4A) to charge devices such as iPods, iPhones, iPads, and more.
5. Supports USB Disk and Micro SD Card for easy media access.
6. Powered through the car's cigarette socket (DC 12V to 24V).
7. Elegant LED display for clear visibility of settings, and voice prompts for easy operation.
8. Equipped with over-current protection, short-circuit protection, and over-temperature protection for safe use.

Features

1. Please read all safety instructions carefully before using this product. Improper use may result in damage to this product or attached items.
2. Do not use the device in moist or underwater environments.
3. Do not use near heaters or high-temperature sources.
4. Do not place the device under direct and strong sunlight.
5. Keep the device in a safe location to avoid the risk of falling or being subjected to impacts.
6. Never dismantle the product by yourself. This can cause the product to malfunction and result in injury.

Instructions for Use



1. Short Press:

1.1 Answer/Reject call

1.2 Play/Pause Music

2. Double Press: Redial the last number

3. Long Press:

3.1 Press and hold until the frequency starts flashing. Rotate clockwise to increase the frequency and rotate counterclockwise to decrease the frequency.

3.2 Reject a call during the call status.

3.3 Switch to private mode during the call.



Next Song



Previous Song



Increase Volume



Decrease Volume

Rotate clockwise to play the next song.

Rotate counterclockwise to play the previous song.

Rotate clockwise and hold to increase the volume.

Rotate counterclockwise and hold to decrease the volume.

Using FM Transmitter Function

1. Plug the FM transmitter into your vehicle's cigarette lighter or power port.
2. Tune your radio to an unused FM frequency, then match the frequency of this unit.
3. Insert a Micro SD card or USB disk containing MP3 files into the card/left USB slot.
4. The unit will automatically play and transmit the file.

Using Bluetooth Function

1. When using Bluetooth for the first time, pair your mobile phone with this unit.
2. Activate your mobile phone's Bluetooth function, then search for new devices.
3. When your mobile phone detects this unit (named as "BT201D"), pair and connect using the default password "0000".
4. In music playing mode, when there is an incoming call, the unit will automatically switch to telephone mode.

Bluetooth Calling

1. Press "" to answer an incoming call.
2. Press "" to end a call.
3. Press "" twice to dial the last number automatically.
4. During a call, long press "" to switch to private conversation mode.
5. When making a call, you can only dial the phone number from your mobile phone, but once the call is connected, you can use the hands-free function to enjoy it.

Using USB Charger Function

Connect the USB charger port (both ports are suitable) to your mobile phone using a USB cable (not included) when the product is powered by the car lighter socket.

The product will function as a mobile phone charger.

Please note:

- a. The maximum output of the right USB port is 2.4mA.
- b. The maximum output of the left USB port is 1mA.
- c. Read MP3/WMA files from a USB disk using the left USB port.

Bass Music

When listening to music via SD/USB or mobile phone, press the button "b" to enjoy the bass music. Press it again to return to the original audio.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net
Website: **porodo.net**
Service Support: **support@porodo.net**
Instagram: **porodo**