

PORODO



Porodo

**Rotating Base Three-Device
Wireless Charger**

SKU: PPD-FWCH039

Table of Contents

Overview	2
Instructions for Use	2
LED Guide	3
Applicable Devices	3
Specifications	4
Precautions	4
FAQ	4
Disposal	5
Warranty	6
Contact Us	6

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.


Note: To ensure safe and efficient charging for three devices, use a 9V/2.7A adapter along with a quick charge cable. If the appropriate adapter and quick charge cable are not used, the charger may fail to charge your phone, may not support charging three devices simultaneously, or could even result in damage to the charger.

Overview

The 3-in-1 wireless charger, a compact charging hub powered by just one outlet, can charge three devices simultaneously. When charging your mobile phone, Apple Watch, and your Airpod, or other earbuds devices, simply place them on the charger, and wireless charging will automatically begin. This helps keep your desk clean, organized, and hassle-free. The space-saving design integrates seamlessly with your mobile lifestyle, especially for Apple users. Additionally, the stylish light ring provides a sleek touch while clearly indicating the charging status.

Instructions for Use

1. Connect the charger to a 9V/2.7A adapter using a Type-C quick charge cable to power it on.
2. Place your phone on the charging pad to begin charging.
3. Attach your Apple Watch, ensuring it magnetically aligns to start charging.
4. Place your earphone case on the charging pad to charge it.



LED Guide

Power On: Flashes once.

Standby: The white indicator stays on for 30 seconds, then turns off.

Charge: The running light stays on for 60 seconds, then turns off.

Fully-Charged: The green light remains steady.

Foreign Body: The red light blinks.

Applicable Devices

A. Smartphones

1. Apple: iPhone 15, iPhone 15 Plus, iPhone 15 Pro, iPhone 15 Pro Max, iPhone 14, iPhone 14 Plus, iPhone 14 Pro, iPhone 14 Pro Max, iPhone 13, iPhone 13 mini, iPhone 13 Pro, iPhone 13 Pro Max, iPhone 12, iPhone 12 mini, iPhone 12 Pro, iPhone 12 Pro Max, iPhone 11, iPhone 11 Pro, iPhone 11 Pro Max, iPhone X, iPhone Xs, iPhone Xs Max, iPhone XR, iPhone 8, iPhone 8 Plus.

2. Samsung Galaxy: S23, S23 Ultra, S22, S22 Ultra, S5 21G, S5 +21G, S21 Ultra 5G, FE 5G, S5 20G, S5 +20G, S20 Ultra 5G, 10 ,+10 ,10e, 7 ,7 ,+8 ,*9 ,9 edge, 6 ,6 edge, 6 edge+, G6 ,9209Active; Galaxy Note: 5 ,6 ,7 ,8 ,9 ,+10 ,+10 ,10.

3. LG: G2 (VS980, Verizon version), G3, G6, G6+, G7, G7 ThinQ, G8, G8 ThinQ, V30, V30+, V35, V40 ThinQ, V50, V50 ThinQ, LG Lucid2 (VS870), LG Optimus Vu 3, Spectrum 2, Optimus G Pro, Optimus Vull, Optimus LTE 2, etc.

4. Motorola: Droid Turbo, Droid Turbo2, Droid 5, Moto Maxx, Ultra M, Moto X Force.

5. Huawei: Mate 60, Mate 60 Pro, Mate 60 Pro+, P60, P60 Pro, P50, P50 Pro, Mate 40 Pro, Mate 40 Pro+, Mate 40 RS, Mate 30, Mate 30 RS, Mate 30 Pro, Mate 30E Pro, P40 Pro, P40 Pro+, P30 Pro, Mate 20 Pro, Mate RS.

6. Xiaomi: 11 Ultra, 11 Pro, 10 ,11S, MIX 10 ,10 ,4 Pro, 9 ,9 Pro, 9X, MIX 3, MIX 2S. Including other devices with wireless charging built-in; some devices may need a wireless charging receiver.

Note: All devices must meet the Qi standard.

B. Smartwatches

Apple: iWatch S1, S2, S3, S4, S5, S6, S7, S8, S9, SE.

C. TWS Bluetooth Earphones

1. Apple AirPods 2, AirPods 3, AirPods 4, AirPods Pro, AirPods Pro 2
2. Samsung Galaxy Buds/Buds+/Buds Pro/Buds Live
3. Huawei FreeBuds 4/3/2i/Pro, and more TWS (with wireless charging case.

Specifications

Input	9V/2A, 9V/2.7A
Input Interface	Type-C
Wireless Output	5W, 7.5W, 10W, 15W
Earbuds Output	3W
Watch Output	2.5W
Transmission Distance (Phone)	≤8mm
Conversion Rate (Phone)	≥73 %
Dimensions	24.7×95.8×98.3mm

Precautions

1. Keep the charger away from children, infants, and pets.
2. Protect the device from impacts and drops. Do not disassemble or attempt repairs yourself, as this may pose a danger to both you and the device. Instead, send it to a professional service center for inspection.
3. Keep the charger away from water or other liquids. If it comes into contact with water, do not use it and have it checked by a professional.
4. Before cleaning the charger, ensure it is disconnected from the power supply.
5. Use the charger in an environment with a temperature range of 0°C to 45°C.
6. Ensure the smartphone charging environment does not exceed 55°C (131°F).

FAQ

- A. If you're experiencing interrupted or slow charging, check the following:
- (1) Ensure the back of your phone is free from metal objects, pop sockets, or credit cards.

- (2)** Place the phone in the center of the charging surface to align the charging coil in your phone with the one inside the wireless charger.
- (3)** For Sony phones, position them slightly below the center, as their wireless charging coil is located there.
- (4)** Use phone cases no thicker than 5 mm to ensure effective charging.
- (5)** Verify that the adapter being used is a QC3.0 fast charger.

B. If you're failing to charge your device, please try the following:

- (1)** Restart your phone and test with another USB cable.
- (2)** Check whether the indicator light turns on.
- (3)** Verify if the adapter is a Quick Charger (Output: 9V/2.7A).

Note: Original iPhone adapters may not be compatible with the wireless charger.

- (4)** Ensure your phone case thickness is ≤ 5 mm. Metal rings or magnetic pads may interfere with charging.

C. If you're using the recommended wireless charger with a 9V/2.7A adapter and have removed any potential charging obstructions but are still experiencing issues, try:

- (1)** Replacing the cable connecting the wireless charger.
- (2)** Rebooting your phone.
- (3)** Unplugging the adapter and reinserting it.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**