

PORODO
LIFESTYLE



Porodo Lifestyle
Face and Body Epilator

SKU: PD-LFST111-WH

Table of Contents

Overview	2
Specifications	2
Features	3
Application	3
Usage Tips	3
Heads and Overlays	4
Important Notes	6
Preparing for Use	7
Instructions for Use	7
Charging Guide	8
Cleaning and Maintenance	8
Disposal	9
Warranty	9
Contact Us	9

Overview

Thank you for purchasing Porodo Lifestyle Face and Body Epilator. The head can be fitted with easily replaceable tips, allowing you to care for your entire body. The kit includes attachments for depilation, shaving, massaging, exfoliating dead skin, and an electric foot file.

Specifications

Battery	600mAh
Input Power	DC 5V/1A
Rated Power	3W
Charging Time	90min
Working Time	120min
Charging Interface	Type-C
Motor Speed	5800RPM \pm 10%
Noise Level	\leq 70dB
Speed Levels	2 Levels
Waterproof Rating	IPX7
Heads	Massage Head, Cleaning Head, Callus Head, Shaver Head, Detail Shaver, Bikini Head

Features

Thank you for choosing our new epilator. It allows you to remove unwanted hair easily and effectively, leaving you feeling more confident and polished.

1. The two-speed design and rotating discs capture even the shortest hairs and pull them out by the root. Epilating with this device will leave your skin smooth and hair-free for several weeks.
2. It can replace the head part and groom easily on the body with the grooming function.
3. The rechargeable function has a charging time of 90 minutes and can work for 90 minutes after a full charge.

Application

1. The appliance is suitable for use in the bath or shower, but it can also be used dry. If you want to use creams or body lotions, apply them after using the appliance.
2. For a gentler, less painful epilation, use the appliance on wet skin, with or without your regular shower gel.
3. A slight skin irritation, such as redness or red dots, may occur after epilation. This is normal.
4. We recommend epilating before going to bed at night, as any redness or skin irritation usually disappears overnight.

Note: The appliance can only be used without the cord.

Usage Tips

1. When you epilate (with or without an accessory on the epilating head), place the appliance on your skin at the angle shown in the illustration.
2. When using the appliance with other heads and accessories, ensure that the heads and accessories are placed flat on the skin.
3. When using the appliance on sensitive areas, stretch the skin with your free

hand. For underarms, raise your arm and place your hand on the back of your head to stretch the skin.

4. Move the appliance slowly against the direction of hair growth.

Note: If you move the appliance over your skin too quickly, you may not achieve a smooth result.

Note: If your hair is longer than 3 to 4mm, pre-trim it for a more comfortable and easier epilation.

Heads and Overlays



1. Epilating Head

You can use the epilating head to remove hair from your legs, underarms, and bikini line. Select speed 2 for the most efficient epilation. Select speed 1 for areas with less hair growth or for hard-to-reach areas such as knees and ankles.



2. Massager Roller Head

For an extra gentle epilation experience by stimulating your skin.



3. Skin Stretcher Cap

You can attach the skin stretcher cap to the epilating head. It keeps the skin tight during epilation to reduce pain.



4. Delicate Area Cap

You can attach the delicate area cap to the epilating head for more comfortable epilation of delicate areas, such as the underarms and bikini line.



5. Facial Cap

You can attach the facial cap to the epilating head for precise epilation of facial hair (e.g., above your upper lip).

Note: Do not use the appliance to epilate eyelashes, eyebrows, or scalp hair.



6. Shaving Head

You can use the shaving head to shave your legs and body.

Note: The appliance can be moved in two directions for easier shaving of underarms.



7. Comb for Shaving Head

You can attach the comb to the shaving head to trim hairs to a length of 3mm.

Alternative Use: You can attach the comb to the trimming head to trim hairs in the bikini area to a length of 3mm.



8. Body Massage Head

The body massage head rotates firmly to relax your muscles.



9. Body Exfoliation Brush

You can use the body exfoliation brush to remove dead skin cells.



10. Callus Head

You can use the callus head to remove dead skin on the feet.



11. Detail Shaver

You can use the detail shaver to remove hair in detailed areas.

Important Notes

- 1.** Read these instructions carefully before using the appliance and save them for future reference.

- 2.** Check that the main voltage indicated on the appliance corresponds to the local voltage before connecting the appliance.
- 3.** Regular cleaning and proper maintenance ensure optimal performance and a long life for your appliance.
- 4.** To prevent damage and injuries, keep the appliance away from your hair, eyebrows, eyelashes, threads, clothes, etc.
- 5.** If the product is damaged, it must be replaced by qualified personnel to avoid any hazards.
- 6.** Keep the appliance out of the reach of children.

Preparing for Use

- 1.** Make sure your skin is clean, completely dry, and free from grease. Do not apply any cream before you start epilating.
- 2.** Epilation is easier right after taking a bath or shower.
- 3.** After epilation, you can apply a mild cream or lotion to help reduce potential skin irritation.

Instructions for Use

1. Charging

- 1.1** Insert the appliance plug into the appliance.
- 1.2** Insert the main plug into the wall socket.

2. Shaving

- 2.1** To achieve the best results, move the appliance over the skin against the direction of hair growth.
- 2.2** Stretch the skin with your free hand to keep the razor flat on the skin and allow the trimmer and foil to work simultaneously.

3. Epilating

- 3.1** Press the button to change the head parts, then press both sides of the razor head with your thumb to remove the bead parts. Install the epilator parts and

proceed with use.

3.2 Select speed 1 for areas with little hair growth, hard-to-reach areas, and areas where bones are located directly beneath the skin, such as knees and ankles.

3.3 Select speed 2 for larger areas with stronger hair growth.

3.4 Stretch the skin with your free hand to make the hairs stand upright.

3.5 Place the epilator perpendicular to the skin with the On/Off slider pointing in the direction you plan to move the appliance.

3.6 Move the appliance slowly over the skin, against the direction of hair growth.

3.7 Switch the appliance off by pushing the On/Off slider to position 0.

Charging Guide

1. Turn off the switch and connect the transformer to the machine. Then, switch on the power. The indicator light will show when the device is charging.

2. It takes about 1.5 hours to fully charge the epilator. Charging for a shorter period may affect battery life and potentially cause unnecessary circuit damage.

3. The device can only be charged after fully releasing the power to avoid interfering with the charging process. After charging, proceed with shaving and epilating as shown in sections A and B.

Cleaning and Maintenance

1. For optimal and smooth epilating results, it is essential to clean the epilating head after each use.

2. Switch the appliance off.

3. Clean the epilating discs and all other parts that are accessible using the brush supplied.

4. Do not use aggressive cleaners, scouring agents, petrol, acetone, or similar substances to clean the plastic housing of the appliance.

5. Never attempt to remove the epilating discs from the epilating.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**