

PORODO



Porodo

**60000mAh Power Bank
Multi-Device PD Charging**

SKU: PD-PBFCH079

Table of Contents

Precautions	2
Specifications	3
Disposal	4
Warranty	4
Contact Us	4

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Precautions

- 1.** Carefully read all instructions before using the product.
- 2.** When using this product for the first time, perform a full charge and discharge cycle to extend its service life.
- 3.** Ensure the device you want to charge is compatible with the power bank's specifications.
- 4.** Keep the power bank out of reach of children, infants, and pets.
- 5.** Avoid dropping or subjecting the power bank to impacts.
- 6.** Do not expose the power bank to water or immerse it in water.
- 7.** Warning: If the power bank comes into contact with water, do not use it.
- 8.** Do not puncture or disassemble the power bank. Do not disassemble the product under any circumstances. This may cause overheating, fire, or an explosion.
- 9.** Never throw the power bank into a fire, as it may cause an explosion.
- 10.** If the power bank malfunctions or is swallowed, stop using it and contact a service center immediately.
- 11.** Do not dispose of the power bank as household waste.
- 12.** Avoid leaving the power bank in a car on hot days. Do not expose the battery to direct sunlight, fire, or extreme heat.
- 13.** Do not use the power bank in environments with high temperatures or humidity. Store it in a cool, dry place when not in use.
- 14.** Always monitor the power bank when it is charging other devices or being charged. Never leave it unattended.
- 15.** Disconnect the charger once the battery is fully charged. Do not leave it charging for an extended period.
- 16.** Improper battery replacement may result in an explosion.
- 18.** When using a power adapter for charging, only use a branded certified adapter that complies with standard requirements.

Specifications

Battery Capacity	60000mAh 3.7V 222Wh
USB-C1/USB-C2 Input	5V/3A, 9V/3A, 12V/3A, 15V/3A 20V/3.25A, 65W Max
USB-C1/USB-C2 Output	5V/3A, 9V/3A, 12V/3A, 15V/3A 20V/3.25A, 65W Max
USB-A1/USB-A2/USB-A3/USB-A4 Output	5 to 10V/2.25A, 5V/3A, 9V/2A 12V/1.5A, 22.5W Max
Net Weight	1220g
Product Dimension	153×71.3×78mm
Sharing Output	
USB-C1 + USB-C2	PD30W+PD30W
USB-C1 + USB-A1	5V/3A 15W, USB-C1 + USB-A5 :2V/3A 15W
USB-C1 + USB-A3	PD30W + QC 18W, USB-C1 + USB-A4: PD30W + QC18W
USB-C2 + USB-A1	PD30W + QC18W, USB-C2 + USB-A2: PD30W + QC18W
USB-C2 + USB-A3	5V/3A 15W, USB-C2 + USB-A5 :4V/3A 15W
USB-A1 + USB-A2	5V/3A 15W
USB-A1 + USB-A3	15W + QC18W
USB-A1 + USB-A4	15W + QC18W
USB-A2 + USB-A3	QC18W + QC18W
USB-A2 + USB-A4	QC18W + QC18W
USB-A3 + USB-A4	5V/3A 15W
USB-C1+ USB-C2 + USB-A1+ USB-A2 + USB-A3 + USB-A4	15W+15W

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**