



# **Porodo Gaming** **Projector with** **Controllers**

SKU: PDX639

# Table of Contents


Attention	2
Projector Overview	2
Projector Remote Control	3
Switching Between Applications	4
Projector Settings	4
Networking Setting	5
Bluetooth Setting	5
Language Setting	6
Other Setting	6
Projection Setting	7
Audio Setting	7
Date and Time Setting	8
Input Signal Selection	8
Miracast Instructions	9
AirPlay Instructions	10
Gaming Stick Overview	11
Main Menu Function	11
Game Instruction	13
Game Settings	14
Safety Instructions	14
Warning	15
Projector Specifications	15
Gaming Stick Specifications	15
Disposal	16
Warranty	16
Contact Us	16

## Attention

Please read this manual carefully before using the projector and keep it for future reference.


1. The projector is not dustproof or waterproof, so avoid exposing it to moisture or dust.
2. Keep away from children, pets, and infants.
3. To prevent the risk of fire or electric shock, do not expose the projector to rain or fog.
4. Always use the original power adapter that came with the projector, and make sure the projector is connected to the correct power supply.
5. Do not look directly into the lens while the projector is on, as the bright light may cause discomfort or slight pain to your eyes. Supervise the children when the projector is in use.
6. Do not block the vents on the projector, as overheating can damage the projector and create safety risks.
7. Regularly clean the projector's vents to prevent dust buildup, which can lead to cooling problems.
8. Avoid using the projector in greasy, damp, dusty, or smoky environments. These conditions can cause malfunctions due to the buildup of oil or chemicals.
9. Handle the projector carefully during use to ensure its longevity.
10. If the projector will not be in use for an extended period, turn it off to conserve energy and prevent any potential issues.
11. Do not attempt to disassemble the projector for testing or maintenance unless you are a qualified professional.

## Projector Overview






## Projector Remote Control




## Switching Between Applications

1. Click on "My Apps" to view the installed programs.
2. Click the program icon to switch between applications.
3. Navigate to "My Apps" and press OK to enter.
4. All applications can be clearly identified by their distinct icons.




## Projector Settings

Enter the settings menu to configure the following: Networking, Bluetooth Language, Other Settings, Projection, Audio, Date and Time




## Networking Setting

1. Go to Settings > Networking Setting > WiFi Setting.
2. Turn WiFi ON and select the desired WiFi network (WiFi ID).
3. Enter the password to connect to the internet.




## Bluetooth Setting

1. Go to Settings > Bluetooth Setting.
2. Turn Bluetooth ON.
3. Click Refresh Device and select the desired device to pair with.




## Language Setting

1. Go to Settings > Language Setting.
2. Enter the language setup menu to select your preferred language and input method.




## Other Setting

1. Go to Settings > Other Setting.
2. Enter this menu to access the following options: Application Settings, Factory Reset Settings, Developer Options




## Projection Setting

1. Go to Settings > Projection Settings.
2. Enter this menu to set up the projection mode and perform keystone correction.




## Audio Setting

1. Go to Settings > Audio Setting.
2. Enter this menu to adjust the volume.




## Date and Time Setting

1. Go to Settings > Date and Time Setting.
2. Enter this menu to set up the following: Timezone, Time format, Date format  
Date and time



## Input Signal Selection

After connecting the projector to another output device, select HDMI or Audio/Video input.




## Miracast Instructions

Ensure that your Android devices (phone, tablet, etc.) are connected to the same local wireless LAN as the projector.

1. From the Home Screen, go to My Apps.
2. Select Miracast and open the Miracast service.
3. Turn on Phone Mirroring and click Connect to establish the connection.




## Operations on Android Phone Devices




## AirPlay Instructions

Ensure that your Apple devices (iPhone, iPad, etc.) are connected to the same local wireless LAN as the projector.


1. From the Home Screen, go to My Apps.
2. Select AirPlay and open the AirPlay service.
3. Turn on Phone Mirroring and click Connect to establish the connection.



## Operations on iOS Devices



## Gaming Stick Overview



## Main Menu Function

1. List: All the games in the folder will be displayed on this page, with up and down selection, and left and right page turning. (The simulator in which the game is running will be indicated with prompts on the screen).



2. Classification: Identify all simulators integrated into the machine.




3. History: After playing, the game record will be stored in this interface.



**4. Collection:** Your favorite games can be added to the collection list.




**5. Search:** Filter games based on their names, recognizing uppercase letters. (Note: The search is case-insensitive.)



## **Game Instruction**

- 1.** Press the directional key to navigate the game menu, then press the Start or A key to enter the game.
- 2.** Press B in the game list to return to the home page.
- 3.** Hold down the Select/Start key simultaneously during gameplay to open the game menu, where you can pause, save, load, or exit the game.



## Game Settings

Press the Select key to access the settings menu. Options include language settings, key tone, local file search, restoring default settings, exiting, system information, and other settings.

## Safety Instructions

1. Read this manual carefully to ensure the safe operation and maintenance of the projector. Following these safety guidelines will help extend the projector's lifespan.
2. For installation and repairs, consult qualified personnel. Do not use damaged wires, accessories, or peripherals.
3. Keep the projector away from flammable or explosive materials and strong electromagnetic interference (e.g., radar stations, power stations, substations). Avoid exposure to strong ambient light, including direct sunlight.
4. Do not cover the projector's vents.
5. Use only the original power adapter.
6. Ensure proper ventilation and keep vents unobstructed to prevent overheating.
7. Do not look directly into the lens while the projector is operating, as the strong light may cause eye discomfort.
8. Do not bend, drag, or place heavy objects on the power cord.
9. Avoid covering the power cord with soft materials.
10. Do not expose the power cord to heat.
11. Avoid handling the power adapter with wet hands.

## Warning

Avoid looking directly into the lens while the projector is in use, as the intense light may cause eye damage. Children should use the projector only under adult supervision.

## Projector Specifications

AC Input	90 to 240V, 60-50Hz
Projection Technique	2.69" LCD TFT Display
Operating System	Android 11.0
CPU	H713 (Quad-Core ARM Cortex-A53)
GPU	Mali-G31
RAM + ROM	1 +8GB
Projection Area	40 to 130 Inches
Projection Distance	1.2 to 3.5m
Brightness	150 to 200 Ansi Lumens
Bulb Lifetime	50000H
Throw Ratio	1.37
Aspect Ratio	4:3 & 16:9
Contrast	1500:1
Connectivity	Wi-Fi 5/2.4GHz, BT5.0
Speaker	3W
Fan Noise	<35dB
Interface	HDMI, Headphone, USB
Power Cord	1.2m UK Plug

## Gaming Stick Specifications

CPU	Amlogic S905L
GPU	Penta-Core Mali-450MP
RAM	DDR1 3GB, Flash 8G
TF Card Memory	32G
Game Compatibility	PSP, PS1, N64, CP1, CP2 ,CP3, Neogeo, MAME FC, SFC, GB, GBA, GBC, MDandother+14 More

Language	English + 23 Languages
Connectivity	2.4G Wireless

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **[porodo.net/warranty](https://porodo.net/warranty)** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**[porodo.net/warranty](https://porodo.net/warranty)**

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:  
**[info@porodo.net](mailto:info@porodo.net)**  
 Website: **[porodo.net](https://porodo.net)**  
 Service Support: **[support@porodo.net](mailto:support@porodo.net)**  
 Instagram: **[porodo](https://www.instagram.com/porodo)**