



Green Lion

**LINT Y
Lint Remover**

SKU: GNLINTYWH

Table of Contents

Safety Precautions	2
Battery Safety Warnings	3
Special Safety Instructions	4
Product Overview	5
Charging the Lint Remover	5
Usage Instructions	6
Cleaning Instructions	6
Specifications	7
Disposal	7
Warranty	8
Contact Us	8

Before using the product, please carefully read this User Manual. This appliance is intended for home use only. Carefully read the instructions provided in this manual. Keep this manual handy for future reference throughout the product's lifecycle. It contains vital information on the appliance's functions and provides safety guidelines for installation, use, and maintenance.

Safety Precautions

1. This device is a power tool, not a toy. Always store it out of reach of children after use, and keep packing materials such as plastic bags and cartons away from children.
2. Suitable for use by children aged 8 years and older, and by adults with reduced physical, sensory, or mental capabilities. However, it must only be operated under the close supervision and instruction of an adult responsible for their safety.
3. This appliance should not be used by any person with reduced physical, sensory, or mental capabilities, or a lack of experience and knowledge, unless they are under direct supervision by someone responsible for their safety, who has provided them with detailed instruction on safe operation.
4. Ensure continuous supervision when children are using the appliance to prevent them from playing with it.
5. Always pay close attention when using the machine around children.
6. Never leave the machine running unattended.
7. To avoid injuries, keep your hands, hair, and clothes away from the machine while it's on. Make sure nothing else gets too close to the moving parts.
8. Wait until the machine has completely stopped before touching any parts that move.
9. Don't try to clean the machine while it's on. Avoid using sharp items to take out anything stuck inside.

10. Make sure children are watched by an adult if they help clean the machine.
11. Keep the machine away from bad weather conditions like rain or direct sunlight.
12. Do not use the machine if your hands are wet or if it looks broken or damaged.
13. If the machine needs fixing, have a professional repair person take care of it. Trying to fix it yourself could be very dangerous.
14. To clean the machine, just use a damp cloth. Avoid using any harsh cleaners or scrubbers.
15. This machine is for household use only.

Battery Safety Warnings

1. Charging should be supervised by an adult at all times.
2. Do not submerge the device or its batteries in water.
3. Avoid exposing batteries to heat or direct flame.
4. In the event of leakage from batteries, cleanse affected skin or clothing with water immediately and consult a medical professional.
5. Discontinue use of batteries if any abnormalities are observed.
6. Prevent contact between batteries and metal objects such as keys or coins, as this could lead to explosions or the release of harmful chemicals.
7. Batteries should not be opened, crushed, modified, disassembled, punctured, heated, or burned.
8. Treat each battery pack as a single, integral unit that must not be dismantled or altered.
9. Batteries, battery packs, or rechargeable batteries should never be placed in the mouth. If ingestion occurs, contact a medical practitioner or poison control center immediately.
10. Avoid causing short circuits with batteries to prevent risks of burns or

fire.

11. Should the batteries swell, cease usage immediately and dispose of the device in accordance with applicable environmental regulations.

12. Additional Note: The device contains a battery that is integrated and non-removable.

Warning: Ignoring the Battery Safety Warnings may lead to electric shock, leakage, overheating, explosion, or fire, potentially causing severe personal injury or property damage.

Caution: Do not dispose of batteries or electronic equipment as regular municipal waste. Follow the directives 2002/96/EC and 2006/66/EC, along with any national laws regarding the disposal of end-of-life products. These items should be collected separately to prevent environmental damage.

Special Safety Instructions

1. This device is designed exclusively for removing lint from clothing, fabrics, and similar materials. Do not use it while wearing the clothes you are treating, and avoid using it on body hair or pet fur.

2. Always ensure the device is turned off before starting any cleaning process.

3. The blades are very sharp. Exercise caution to avoid injuries when handling or cleaning the device.

4. Operate the device only when the blade guard is securely in place to ensure safe usage.

5. Avoid bending or damaging the blade guard, as this could interfere with the proper rotation of the blades.

Product Overview

1. Lint Tray
2. Blade Cover
3. Blades
4. Hand Grip
5. USB Charging Port



Charging the Lint Remover

1. Insert one end of the supplied USB charging cable into the device's charging socket.
2. Connect the other end of the cable to a USB charger, computer, or any available USB port. The charging indicator will illuminate to show that charging is in progress.
3. Allow the device to charge for approximately 2 hours. Once fully charged, it can operate for about 45 minutes.
4. Disconnect the USB charging cable after charging is complete to ensure safety and prolong battery life.

Usage Instructions

1. Preparing the Garment:

- 1.1 Lay the garment flat on a surface and smooth out any creases.
- 1.2 For very thin or delicate garments, consider folding them twice over an ironing board to safely remove creases without damaging the fabric.

2. Operating the Device:

- 2.1 Power on the device by pressing the on/off button.
- 2.2 Carefully place the cutting disc onto the garment. Move the device gently up and down over the fabric. Avoid pressing the device too hard against the clothing to prevent damage to the blade guard.

3. Maintenance and Precautions:

- 3.1 Empty the trimmer when it is about 3/4 full to maintain optimal performance.

Caution: Test the device on a less visible part of the garment before full use to ensure it does not damage the fabric.

- 3.2 Exercise caution when using the device near buttons, zippers, seams, and prints to avoid accidental snags or damage.

Cleaning Instructions

- 1. Ensure the device is switched off before beginning any cleaning procedures.
- 2. Gently rotate the head counterclockwise to detach it from the device for cleaning.
- 3. Once the head is removed, empty and clean the blade guard using a brush.

Note: the cleaning brush is not included with the device.

- 4. After cleaning, reattach the head by placing the protective cover back on and turning it clockwise until it is secure.
- 5. Always charge the device fully before storing it for long periods.

6. Recharge the battery at least once every three months, regardless of how frequently the device is used, to maintain battery health.

Specifications

Material	ABS
Battery	500mAh
Power	3W
Blade	6 Blades
Speed	1 Gear
Motor	7200 RPM
Noise Level	<75 dB
Lint Container	30 ml
Input	5V 1A
Charging Port	Type-C
Charging Time	2 Hrs
Working Time	45 min
Product Weight	160g
Product Size	75*85*160 mm

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.greenlion.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: **<https://www.greenlion.net/>**

Sales: **sales@greenlion.net**

Service Support: **Support@greenlion.net**

Telegram: **[@greenlion_global](https://t.me/greenlion_global)**

Instagram: **[@greenlion_global](https://www.instagram.com/greenlion_global)**