

LèPRESSO



LePresso

PORTABLAST PRO

Automatic Portafilter Cleaner

SKU: LPCFFM0042

Table of Contents

Safety Precautions	2
Product Overview	3
Installation Steps	4
Instructions for Use	5
Disassembly Steps	6
Notice	8
Specifications	8
Warranty	9
Contact Us	9

Safety Precautions


- 1.** To avoid the risk of fire, electric shock, and personal injury, ensure that wires, plugs, and the body of the machine are not immersed in water or other liquids.
- 2.** This product should not be operated by children or individuals with mobility impairments.
- 3.** Always unplug the machine before installing or removing components or when cleaning the machine.
- 4.** If the power cord or plug is damaged, or if the device malfunctions, do not attempt to repair it yourself. Please return the equipment to an authorized service center for inspection and repair.
- 5.** Using non-approved parts may result in fire, electric shock, or injury.
- 6.** This product is intended for indoor use only. Do not use it outdoors, or on vehicles, boats, or airplanes. Also, avoid using the product on a tilted surface.
- 7.** Ensure that the power cord does not hang over the edge of a table or cabinet, and avoid placing it near a heat source or allowing it to become tangled.
- 8.** Before each use, inspect the electric cleaner and coffee powder bowl for any foreign objects.
- 9.** Always operate the product with the brush head and powder sweeping head properly assembled.
- 10.** Do not place the machine on or near a gas or electric burner, or inside a heated oven.
- 11.** This product is designed specifically for coffee powder in the

extracted coffee powder bowl. Do not use it for other purposes to prevent damage to the machine.

12. If the power cord is damaged, it must be replaced by a qualified professional from the manufacturer or an authorized service center to prevent safety risks.


Caution: After turning on the power, avoid pressing the powder scraper with your hands to prevent injury.

Product Overview




Installation Steps

- 1.** Ensure that the plug is unplugged and the power supply is disconnected.
- 2.** Attach the powder scraper head and brush head to the motor connector, following the direction of the arrow. The installation is complete once the hexagonal groove aligns with the hexagonal convex groove of the connecting head.




- 3.** Verify that the scraper head and brush head are properly assembled.




Instructions for Use

1. After assembling the brush head, turn on the power and switch on the power button. Align the portafilter that needs cleaning with the correct brush head and gently press it down. The brush will automatically scrape off the powder residue inside the portafilter. Once cleaning is complete, lift the coffee powder bowl upwards, and the machine will automatically stop.




2. Switch to the left brush head, align it with the portafilter, and press it down. The brush head will automatically rotate and clean. After cleaning is complete, lift the portafilter upwards, and the brush head will automatically stop working.





Disassembly Steps


1. Turn off the power before starting the disassembly process.




2. As shown in the figure, gently lift the brush head using your fingers to easily remove it, following the direction of the arrow.



3. Lift the body upwards in the direction of the arrow to complete the disassembly.



4. After disassembling the main body, the waste box can be lifted out of the shell, allowing you to dispose of the waste inside.



Notice

- 1. Do not press the brush head directly with your hands.**
- 2. There is no need to press hard during use; a light press is sufficient.**
- 3. Please use an electric coffee powder bowl cleaner and avoid using the machine on a horizontal or flat countertop.**
- 4. Only use the original DC12V power adapter for operation.**
- 5. Do not flush the machine with water.**
- 6. This equipment comes with a one-year warranty. Unauthorized disassembly and damage caused by misuse are not covered by the warranty.**

Specifications

Rated Power	20W
Rated Voltage	100-240V
Rated Frequency	50/60Hz
Motor Speed	340RPM
Net Weight	1.9kg
Product Size	216 x 138 x 262mm
Model Number	LP042

Warranty

Products that you buy directly from our **LePresso** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **LePresso** website or store. If **LePresso** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **<https://www.lepresso.com/warranty>** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:

<https://www.lepresso.com/warranty>

Contact Us

If you have any questions or concerns about our Shipping and Returns Policy, please contact us at: **info@lepresso.com**

Website: **<https://www.lepresso.com/>**

Instagram: **[lepresso_official](#)**