

PORODO
LIFESTYLE



Porodo Lifestyle

Bi-Directional Juicer

SKU: PD-LFST123-BK

Table of Contents

Safety Precautions	2
Schematic View	3
Instructions for Use	4
Specifications	5
Cleaning and Maintenance	5
Disposal	6
Warranty	6
Contact Us	6

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Safety Precautions


Before using this electrical appliance, always follow these essential safety precautions:

- 1. Read all instructions thoroughly before using the appliance.**
- 2. Verify that the appliance's voltage matches the power supply indicated on the nameplate.**
- 3. To reduce the risk of electrical shock, never immerse the motor unit in water or any other liquid.**
- 4. Unplug the appliance from the outlet when not in use, before attaching or removing parts, and before cleaning.**
- 5. Do not use the appliance if the cord or plug is damaged, or if the appliance malfunctions, is dropped, or is damaged in any way. Return it to an authorized service facility for inspection, repair, or adjustment.**
- 6. The use of attachments not recommended or sold by the manufacturer may result in fire, electrical shock, or injury.**
- 7. Always place the appliance on a flat, stable surface. Do not place it on or near hot gas or electric burners, or in a heated oven.**
- 8. Avoid allowing the supply cord to hang over the edge of tables or counters.**
- 9. Close supervision is required when the appliance is used by or near children.**
- 10. Do not use the appliance for any purpose other than its intended use.**
- 11. This appliance is designed solely for squeezing citrus fruits. Do not use it for juicing other types of fruits.**
- 12. The appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or by those lacking experience and knowledge, unless they have received supervision or instruction regarding its use from a person responsible for their safety.**
- 13. Always supervise children to ensure they do not play with the appliance.**
- 14. Do not use the appliance outdoors.**

- 15.** Keep these instructions for future reference.
- 16.** This appliance is intended for household use and similar applications, including: Staff kitchen areas in shops, offices, and other work environments; Farmhouses; Use by clients in hotels, motels, and other residential-type environments; and Bed and breakfast-type establishments.
- 17.** Warning: Misuse of the appliance may result in potential injury.
- 18.** Always disconnect the appliance from the power supply when left unattended, and before assembling, disassembling, or cleaning.
- 19.** The appliance can be used by children aged 8 years and above, provided they have received supervision or instruction on safe usage and understand the potential hazards. Cleaning and maintenance should not be performed by children unless they are at least 8 years old and are supervised. Keep the appliance and its cord out of reach of children under 8 years of age.
- 20.** For Household Use Only.

Schematic View

- 1.** Large Head
- 2.** Small Head
- 3.** Sieve
- 4.** Juice Collect Tray
- 5.** Motor Unit
- 6.** Juice Container



Instructions for Use

1. Before First Use: Thoroughly clean the top lid, large and small cones, upper and lower sieves, and the cup with warm water.
2. Use the appropriate cone according to the size of the fruit. Small fruits should be squeezed with the smaller cone, while for larger fruits, both cones should be used together by placing the large cone over the small one.
3. Plug the power cord into the outlet, and turn the knob to select the desired hole size. This controls the speed of juice flow.
4. Halve the fruit, place it onto the cone, and apply light pressure. The motor will start running, and the extracted juice will flow into the cup through the sieve. The pulp and pith will remain in the sieve. The motor may rotate in different directions.

Caution: Do not apply excessive force when pressing the fruit to avoid blocking the motor or causing damage.

5. Once the squeezing is complete, release pressure on the cone and the motor will stop running. The appliance will be idle. You can restart it at any time by pressing the cone down again.

Caution: The appliance should operate for 15 seconds and then be turned off for 15 seconds. After 10 consecutive cycles, allow the appliance to cool down for 30 minutes.

Note: The maximum capacity of the cup is 1.4L. Ensure that the cup is not overfilled.

6. After use or if the appliance will not be used, unplug it from the power outlet.
7. If storing the juice in the cup, ensure the top lid is securely in place. For cleanliness and sanitation, do not store the juice in the cup for more than one day. Also, the cup must not come into contact with food exceeding 70°C.

Caution: When the juicer is not in use, do not hold the two pins of the plug while turning the cone manually, as this could result in an electric shock.

Specifications

Material	PP, ABS
Juice Cup Capacity	1.4L
Rated Voltage	220-240V
Rated Frequency	50Hz
Power	30W
Power Plug	UK 3-Pin
Product Weight	830g
Product Size	206.2x140.9x249.4mm
Model Number	LFS123

Cleaning and Maintenance

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. Clean the filter, reamer, and cup with hot, soapy water. Rinse thoroughly under running water and wipe them dry.
3. Wipe the rotating axis with a soft, damp cloth. Never immerse the power base in water or any other liquid.
4. After cleaning, reassemble all the parts together.

K Disposal



This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

K Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

K Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net
Website: **porodo.net**
Service Support: **support@porodo.net**
Instagram: **porodo**