



**Porodo Soundtec**  
**FLEXFIT Open-Ear Clip-On**  
**Wireless Earbuds**

SKU: PDSTYX51

# Table of Contents


Specifications	2
Product Overview	2
Instructions for Use	3
Charging Indicator Light	3
Safety Precautions	4
Disposal	5
Warranty	5
Contact Us	5

# Specifications

Model	PDSTYX51
Charging Input	5V/300mA
Battery Case Capacity	300mAh
Earbuds Capacity	40mAh
Recharge Time	≤1 hour
Bluetooth Version	V5.4
Talk Time	3.5 hours
Music Playback	5.5 hours
Transmission Range	10 meters
Frequency Range	2.402 - 2.480GHz
Net Weight	41.5g
Product Dimension	27.65×47.7 × 64.5mm

# Product Overview

Multi-Function  
Touch Button



## Instructions for Use

### **Bluetooth Name:** YX51

After unboxing, take the earphones out of the charging case.

- 1. Pairing and Connection:** Open the charging case and remove the earphones. Wait for 3-5 seconds for both earphones to automatically pair with each other. Then, search for the Bluetooth name "YX51" in your phone's Bluetooth settings and tap to connect.
- 2. Power On:** When you remove the earphones from the charging case, they will automatically power on and connect to the last paired device.
- 3. Power Off:** Place the earphones back into the charging case and close the lid. They will automatically power off and begin charging.
- 4. Volume Up:** Long-press the touch area on the right earphone to increase the volume.
- 5. Volume Down:** Long-press the touch area on the left earphone to decrease the volume.
- 6. Next Track:** While music is playing, triple-tap the touch area on the right earphone to skip to the next track.
- 7. Previous Track:** While music is playing, triple-tap the touch area on the left earphone to return to the previous track.
- 8. Pause/Play:** Single-tap the touch area on either earphone to pause or resume playback.
- 9. Answer/Hang Up Call:** Single-tap the touch area on either earphone to answer or hang up a call.
- 10. Voice Assistant:** Double-tap the touch area on either earphone to activate the voice assistant.
- 11. Reject Call:** During an incoming call, double-tap the touch area on either earphone to reject the call.

## Charging Indicator Light

- 1.** When the charging case is charging the earphones, the running lights on the digital

display will flash.

**2.** When the charging case is being charged via a cable, the font on the digital display will flash. Once fully charged, the font will remain lit.

**Note:** Ensure to use a 5V/1A charging cable or the included charging cable when using the product.

## **Safety Precautions**

- 1.** Always place the earbuds in the correct position when charging.
- 2.** Do not expose the battery (battery pack or combination battery) to extreme conditions such as sunlight, fire, or overheating.
- 3.** Listening to music at high volumes for extended periods can cause hearing damage. Please adjust the volume appropriately during use.
- 4.** Avoid using the device during thunderstorms, as this may affect the device's performance and increase the risk of electric shock.
- 5.** Do not dismantle or modify the headset for any reason, as this may lead to malfunctions or damage, which is not covered by warranty.
- 6.** Keep the device away from children.
- 7.** Do not immerse the device in water.
- 8.** Avoid using abrasive cleaners to clean the device.
- 9.** Protect the device from drops or impacts.
- 10.** Do not disassemble the product yourself, as this could cause damage.
- 11.** Do not expose the product to high temperatures, and avoid leaving it in a hot car.
- 12.** Do not use the device in high humidity environments.
- 13.** The product contains a battery; mishandling could result in dangerous consequences.
- 14.** If the consumer ignores the above warnings and uses the product improperly, resulting in personal injury or property damage, the company will not be responsible.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **[porodo.net/warranty](https://porodo.net/warranty)** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**[porodo.net/warranty](https://porodo.net/warranty)**

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:  
**[info@porodo.net](mailto:info@porodo.net)**

Website: **[porodo.net](https://porodo.net)**

Service Support: **[support@porodo.net](mailto:support@porodo.net)**

Instagram: **[porodo](https://www.instagram.com/porodo)**