



Powerology


2500W Universal Travel Adapter with 4000mAh Power Bank

SKU: PWCUQC054BK

Table of Contents

Product Overview	2
Specifications	3
Compatible Plug and Outlet	4
Using with 2-Pole Devices	5
USB Devices	5
Instructions for Use	6
Replacement of the Fuse	8
Caution	9
Disposal Warning	9
Compatibility	10
Warranty	13
Contact Us	13

Product Overview



1. Multi-socket

2. USA/JP Socket

3. USA, AU, UK, EU Plugs

4. LED Indicator:

Solid LED light: Normal operation

LED Off: Possible overload. Unplug one device and check the status indicator again.

5. USB-C2 Port

6. USB-A1 Port

7. USB-C1 Port

Specifications


1. General Technical Data	
Model	PWC054
Input	100-250V~ AC, 50/60Hz, 0.6A
Rating	100-250V~ AC, 10A Max, 2500W Max
Battery Capacity	4000mAh
Total Output (DC)	20W
Size	42 x 53 x 86 mm
Weight	250g
Fuse Rating	10A Max + Spare Fuse
Compatibility	Laptop, MacBook, Tablet, TV, PC, Video Games, Router, Printer, Smart Phones, Smart Watch, Camera, Power Bank, Electric Shaver
2. Adapter Output	
USB-C 5	1V/3.0A, 9V/2.2A, 12V/1.67A
USB-A 5	1V/3.0A, 9V/2.0A, 12V/1.5A
USB-C 5	2V/3.0A, 9V/2.0A, 12V/1.5A
USB-C1+USB-C 5	2V/3.0A
3. Power Bank Output	
USB-C 5	1V/3.0A, 9V/2.2A, 12V/1.67A
USB-A 5	1V/3.0A, 9V/2.0A, 12V/1.5A

USB-C 5	2V/3.0A, 9V/2.0A, 12V/1.5A
USB-C1+USB-C 5	2V/3.0A


Compatible Plug and Outlet




Type A



Type B




Type C




Type D




Type E




Type F




Type G




Type H




Type I




Type J



Type L




Type N




Type O

Note: Type K and Type M plugs are not accepted.




Type K




Type M


The adapter can plug into the following outlet types:




Type A




Type B




Type C




Type D




Type E




Type F




Type G




Type H




Type I




Type J




Type K



Type L



Type N



Type O

D Using with 2-Pole Devices

The product is suitable for use with most electronic devices up to 2500W at 250V and 1000W at 100V. It can be used with a variety of appliances, including:



Laptops



Small travel hair dryers



Travel irons



Electric fan



Table lamp



Electric razors

Note: Please check the safety data sheet or the data plate on the device to confirm compatibility before plugging it in.

D USB Devices

The product is compatible with the following devices: Camera, Smartphone, Tablet, Portable Game Console, Bluetooth speaker, Power bank, etc.



Cameras



Smart-
phones



Tablets



Portable Game
Console



Headsets




Power
banks

Instructions for Use

This adapter comes with built-in multi-nation plugs that can be selected to fit a wide range of outlets across different countries. The safety function switch ensures that only one plug is energized at any given time.

Important Notes:


1. Ensure the button is fully reset when pushed out and retracted to the bottom. If the button is not reset, it indicates the plug has not been properly seated, which could affect normal operation.
2. Only one plug type can be used at a time. To switch plugs, simply slide the knob to select the desired type. The other plug pins will be automatically locked in place.



USA Plug

To use the USA plug, gently press the button and slide it downward to extend the plug, ensuring the contact blades are aligned in a parallel position.


To retract the plug: press and hold the "USA" button to release, continue pulling the plug upward until it is fully retracted. Once fully retracted, release the button to lock the plug in place.



AUS Plug

Slightly press the button and slide it down to fully extend the AUS plug as shown. Make sure the contact blades are turned to the parallel position.


To retract the plug: press and hold the "AUS" button, continue pulling upward until the plug is fully retracted. Once retracted, release the button to lock the plug in place.



UK Plug

Slightly press the button and slide it down to fully extend the UK plug as shown. Be sure to pull out the insulated ground pin from the housing.

To retract the plug: press and hold the "UK" button, continue pulling upward until the plug is fully retracted. Once retracted, release the button to lock the plug in place.



EU Plug


Slightly press the button and slide it down to fully extend the EU plug as shown. Make sure the contact blades are turned to the parallel position.

To retract the plug: press and hold the "EU" button, continue pulling upward until the plug is fully retracted. Once retracted, release the button to lock the plug in place.

Replacement of the Fuse

1. Remove (1).
2. Take out (2) and place (2) back into the original position of (1). The adapter will work again.
3. Alternatively, you can replace the fuse with a new one.

Standard: 250Vac 10A, 25.4*6.3mm.



Notes:

1. Ensure that all devices are removed before replacing the fuse.
2. Verify that no water is flowing from the access equipment in the power rating.
3. Confirm whether the product is wet and if any water is flowing out.

Caution

1. Always disconnect the adapter from the outlet when not in use.
2. Before use, please read these instructions carefully. This product does not convert voltage (AC-AC).
3. To avoid potential damage to your device or other safety hazards, ensure that the power outlet you intend to use provides the proper voltage to run your device before using the adapter.
4. Indoor use only.
5. Misuse may lead to electrical shock.
6. The length of the USB cable should be no more than 3 meters.
7. This travel adapter is for temporary use only and should not be used permanently.
8. Do not insert an adapter into another adapter. Such use should only be provided by the manufacturer.
9. No grounding. This product is for use with unearthing or double-insulated appliances only.

Disposal Warning



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.

D Compatibility

EU Plug

A	Albania	Comoros	I	Iceland
	Algeria	Congo		India
	Angola	Croatia		Indonesia
	Argentina	Cote d' Ivoire		Iran
	Austria	Cyprus		Iraq
	Azores	D Denmark		Israel
B	Balearic Islands	Djibouti		Italy
	Bangladesh	E Egypt	K	Kazakhstan
	Belgium	El Salvador		Korea
	Bolivia	Equatorial Guinea		Kuwait
	Bosnia	Eritrea	L	Laos
	Brazil	Faeroe Islands		Lebanon
	Bulgaria	Finland		Lithuania
	Burkina Faso	France		Luxembourg
	Burundi	G Gabon	M	Macedonia
C	Cameroon	Germany		Madagascar
	Canary Island	Gibraltar		Madeira
	Cape Verde	Greece		Mali
	Central African Republic	Greenland		Martinique
	Channel Islands	Guadeloupe		Mauritania
	Chile	Guinea		Mauritius
		Guinea-Bissau		Monaco
		H Hungary		Morocco

Mozambique
Myanmar
N Nepal
Netherlands
Niger
Norway
O Oman
P Pakistan
Paraguay
Peru
Philippines
Poland
Portugal
R Romania
Russia
Rwanda
S Senegal
Somalia
Spain
Sudan
Suriname
Sweden
Switzerland
Syria
T Thailand

Togo
Tunisia
Turkey
U Uruguay
V Vietnam
Z Zambia
AUS PLUG:
A American Samoa
Argentina
Australia
C China
E El Salvador
F Fiji
G Guatemala
K Kiribati
N Nauru
New Zealand
P Panama
Papua New Guinea
S St. Vincent
T Tajikistan
Tonga
U Uruguay

USA PLUG:
A American Samoa
Anguilla
Antilles
Aruba
B Bahamas
Bangladesh
Barbados
Bermuda
Bolivia
Brazil
C Cambodia
Canada
Cayman Islands
China
Colombia
Costa Rica
Cuba
E Ecuador
El Salvador
G Guam
Guatemala
Guyana
H Honduras

J	Japan	Y	Yemen
L	Jamaica	UK PLUG:	Macau
	Laos	B	Malawi
	Lebanon	Bahrain	Malaysia
M	Liberia	Bangladesh	Maldives
	Maldives	Bellze	Malta
	Mexico	Botswana	Mauritius
N	Micronesia	Brunei	Myanmar
	Montserrat	Cameroon	Nigeria
O	Netherlands	D	Qman
P	Nicaragua	Channel Islands	Qatar
	Niger	E	St. Lucia
	Okinawa	G	St. Vincent
S	Panama	Dominica	Saudi Arabia
T	Peru	El Salvador	Seychelles
	Philippines	Gambia	Sierra Leone
	Puerto Rico	Ghana	Singapore
V	St. Vincent	I	Tanzania
	Saudi Arabia	Gibraltar	Uganda
	Tahiti	Grenada	United Arab Emirates
	Taiwan	J	United Kingdom
	Thailand	Guatemala	Vietnam
	United States	K	Yemen
	Venezuela	Hong Kong	Zambia
	Vietnam	Iraq	Zimbabwe
	Virgin Islands(US&British)	Ireland	
		Isle of Man	
		Jordan	
		Kuwait	
		Lebanon	

Warranty

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website [**powerology.me/warranty**](http://powerology.me/warranty) and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:
[**powerology.me/warranty**](http://powerology.me/warranty)

Contact Us

If you have any questions about this Privacy Policy, please contact us at: [**hey@powerology.me**](mailto:hey@powerology.me)

Website: [**powerology.me**](http://powerology.me)

Instagram: [**powerology_official**](https://www.instagram.com/powerology_official)

Facebook: [**powerology.ME**](https://www.facebook.com/powerology.ME)