



Green Lion

KYOTO 10000mAh Power Bank

SKU: GNKYPB10K BK

Model No: GL-PX35

Table of Contents

Operating Instruction	2
Specifications	2
Charging Instructions for Power Bank	3
Mobile Phone Charging Instructions	3
Note	3
Safety Information	4
Package Content	5
Disposal	6
Warranty	6
Contact Us	6

Operating Instructions

Press the power button to display the remaining power.

Power Input and Output: Use the power cable to connect the power adapter to charge the power bank, and connect the power bank to charge the device via the power cable.

Specifications

Model No.	GL-PX35
Material	ABS + Fabric
Battery Capacity	10000mAh
USB-C1 Input	5V/3A, 9V/2A, 12V/1.5A (18W Max)
USB-C2 Input	5V/2A, 9V/2A, 12V/1.5A (18W Max)
USB-A Output	5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A (22.5W Max)
USB-C1 Output	5V/3A, 9V/2.22A, 12V/1.67A (PD20W)
Product Weight	180g
Product Dimensions	108*71*16.2 mm



Charging Instructions for Power Bank

1. Use the Type-C charging cable to charge the power bank.
2. It is recommended to connect the power adapter to charge the power bank.
3. It can also be connected to the USB port of a computer to charge the power bank.
4. After pressing the power button, the remaining battery capacity of the power bank is displayed in LED, and the indicator light turns white. Green light flashes while fast charging.
5. During charging, the white indicator light of the power bank flashes continuously.
6. When fully charged, the indicator light of the power bank stays on and is white.

Mobile Phone Charging Instructions

1. The power bank is used to charge digital products like mobile phones.
2. Connect the power bank and mobile phone with the power cable, and the mobile phone will be charged automatically by the power bank.

Note

1. The charging time of this power bank is about 5-6 hours (5V/2A). The specific time is subject to the actual situation.
2. If the power bank cannot be charged or mobile phone cannot be charged by the power bank, please check if the connection

cable is normal and firm. Ensure the charging port accessory is suitable. It is recommended to use a regular brand power adapter to charge the power bank.

3. There is a conversion rate for the power bank, so the capacity of the power bank is not equal to the rechargeable capacity.

4. If the power bank cannot be turned on for short circuit protection due to improper operation, please charge the power bank to activate it.

Safety Information

Warning: Failure to follow these safety instructions may result in fire, electric shock, damage, or other injury.

Please try to keep the storage temperature of the product between 10-35°C.

Do not fall, do not disassemble or puncture, and do not repair the power bank by yourself.

Do not expose the power bank to fire, high temperature, or water.

Stop using the power bank if you find any abnormal phenomena such as expansion or leakage of the charged device.

This device is not suitable for use by persons with immature physical, perceptual, and mental abilities (including children), nor by persons lacking relevant experience and knowledge, unless supervised and guided by someone who is professionally responsible for their personal safety. Please control children to ensure they do not use this device as a toy.

Do not leave the product in the car for a long time, especially when parked in the sun.

Do not put foreign bodies into the product interface.

Please charge your power bank at least every three months.

The above information is for reference only and is subject to change without prior notice.

1. Please try to keep the storage temperature of the product between 10-35°C.
2. Do not fall, do not disassemble or puncture, and do not repair the power bank by yourself.
3. Do not expose the power bank to fire, high temperature, or water.
4. Stop using the power bank if you find any abnormal phenomena such as expansion or leakage of the charged device.
5. This device is not suitable for use by persons with immature physical, perceptual, and mental abilities (including children), nor by persons lacking relevant experience and knowledge, unless supervised and guided by someone who is professionally responsible for their personal safety. Please control children to ensure they do not use this device as a toy.
6. Do not leave the product in the car for a long time, especially when parked in the sun.
7. Do not put foreign bodies into the product interface.
8. Please charge your power bank at least every three months.

The above information is for reference only and is subject to change without prior notice.

Package Contentst

Powerbank *1

User manual *1

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: sales@greenlion.net

Service Support: Support@greenlion.net

Telegram: [@greenlion_global](https://t.me/greenlion_global)

Instagram: [@greenlion_global](https://www.instagram.com/greenlion_global)