



**Powerology**

**OURA Open-Ear Earbuds**

SKU: PWYX24

# Table of Contents


|                          |   |
|--------------------------|---|
| Specifications           | 2 |
| Touch Area Diagram       | 2 |
| Instructions for Use     | 3 |
| Charging Indicator Light | 4 |
| Safety Precautions       | 4 |
| Disposal                 | 5 |
| Warranty                 | 6 |
| Contact Us               | 6 |

# Specifications

|                        |                                         |
|------------------------|-----------------------------------------|
| Model                  | PWYX24                                  |
| Battery Capacity       | 400mAh (Charging Case), 50mAh (Earbuds) |
| Charging Interface     | Type-C                                  |
| Playtime               | 8.5H (Music Playtime), 5.5H (Talktime)  |
| Recharge Time          | 1H                                      |
| Bluetooth              | V5.4                                    |
| Bluetooth Transmission | 10M                                     |
| Bluetooth Frequency    | 2.402-2.480GHZ                          |
| Net Weight             | 64.2g                                   |
| Product Dimension      | 56×27.5×95mm                            |

# Touch Area Diagram

Touch Area



## Operation Instructions

- 1.** After opening the packaging, remove the earphones from the charging compartment.
- 2.** Open the lid of the charging case, take out the left and right earphones, and place them on a flat surface or in your hand. Wait for 5–3 seconds, and the two earphones will automatically pair. Then, search for the Bluetooth name " Pow\_Oura" on your phone and tap it to connect.
- 3.** Power On: Open the lid of the charging case, and the earphones will automatically power on, pairing and connecting to the previously paired device.
- 4.** Power Off: Place the earphones back into the charging compartment and close the lid. The earphones will automatically power off and begin charging.
- 5.** Volume Down: Long touch the left earphone to decrease the volume.
- 6.** Volume Up: Long touch the right earphone to increase the volume.
- 7.** Activate Siri: Double tap either the left or right earphone to call Siri.
- 8.** Next Track: Triple tap the right earphone to skip to the next song.
- 9.** Previous Track: Triple tap the left earphone to return to the previous song.
- 10.** Play/Pause: Tap either the left or right earphone once to pause or play music.
- 11.** Answer/End Call: Tap either the left or right earphone once to answer or end a call.

## Charging Box Indicator Light

1. **Charging the Earphones:** When placing the earphones into the charging case, the digital display light will flash to indicate that the earphones are charging.
2. **Charging via Type-C Cable:** When charging with a Type-C cable, the digital display font on the screen will flash. Once fully charged, the display will remain on.

**Note:** Please ensure you use a 5V/1A charging cable or the included charging cable when using the product.

## Safety Precautions

1. Ensure the headset is placed in the correct position for charging.
2. Do not expose the battery (or battery pack) to conditions such as direct sunlight, fire, or any source of excessive heat.
3. Prolonged listening to music at high volumes may cause hearing damage. Please adjust the volume to a safe level when using this device.
4. Avoid using the device during thunderstorms, as electrical storms can interfere with the device's operation and increase the risk of electric shock.
5. Do not disassemble or modify the headset for any reason, as this may lead to malfunction or damage.
6. Keep the device away from small children and pets.
7. Do not immerse the device in water.

8. Avoid using abrasive cleaners to clean the earphones.
9. Check the charging source before connecting the device to ensure compatibility.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



## **Warranty**

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:  
**powerology.me/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at: **hey@powerology.me**

Website: **powerology.me**

Instagram: **powerology\_official**

Facebook: **powerology.ME**