



Porodo Soundtec

ZUMA 2-In-1 Headphone Speaker

SKU: PDSTHPV18


Table of Contents

Specifications	2
Schematic View	2
Charging	3
Power ON/OFF	3
Wireless Connection	3
Wireless Mode Function	3
MP3 Mode	4
FM Mode	4
Speaker Function	4
Wired Headphone Mode	4
Disposal	5
Warranty	5
Contact Us	5

Specifications

Model	PDSTHPV18
Input	5V/1A
Battery Capacity	1200mAh
Recharge Time	4H
Speaker Diameter	Φ40mm
Playtime	30H (Headphone Mode), 5H (Speaker Mode)
Bluetooth Version	V5.4
Transmission Distance	>15m
FM Frequency	87.5-108.0 MHz
Bluetooth Frequency	2402 - 2480 GHz
Speaker Frequency	20Hz-20KHz
Maximum Radiated Power	1.66dbm
Audio Decoding Format	MP3/WAV
FM Range	87.5-108.0 MHz
Microphone Sensitivity	-32db
Working Range	10-15m

Schematic View



Charging

1. For first-time use, fully charge the headphone battery. To charge, insert the charging cable into the charging port and connect it to a power source.
2. While charging, the indicator will turn on. Once the battery is fully charged, the indicator will turn off. It takes approximately 3 hours to charge.
3. When the battery is running low, an alarm sound will be heard. Please charge the battery immediately.

Turn ON/OFF

1. **Power ON:** Press and hold the ON/OFF button for 3 seconds. The indicator will flash blue and red alternately, signaling that it is ready for wireless connection.
2. **Power OFF:** Press and hold the ON/OFF button for 3 seconds, then the indicator will turn off.

Wireless Connection

Wireless mode enables hands-free functionality and music playback.

1. Press and hold the ON/OFF button to power on the headphones. The indicator will flash blue and red.
2. Activate the wireless function on your phone, search for the device "POW_ZUMA" and select it to connect.
3. Once the connection is successful, you can freely play music and make or answer phone calls.

Wireless Mode Function

1. Answer/End a Call:
 - 1.1 When connected to your phone, press the call button once to answer an incoming call. Press again to end the call.
 - 1.2 To adjust the volume, press and hold the (+) or (-) button to set your desired level.

2. **Make a Phone Call:** When connected to your phone, double press the "Call" button to redial the last number dialed.
3. **Reject a Call:** Press and hold the "Call" button for 2 seconds, then release to reject an incoming call.

MP3 Mode

1. Turn on the headphones and insert the SD card into the TF slot. The device will automatically start playing the song.
2. To adjust the volume, press and hold the (+) or (-) button until you reach your desired level.
3. Press the (+) or (-) button to skip to the next or previous track.
4. Press the Multi-function button to play or pause the music.

FM Mode

1. Press and hold the Multi-function button to enter FM mode. Then, press the Multi-function button once to scan and save the FM radio station.
2. Press the (+) or (-) button to select the desired channel.
3. Press and hold the (+) or (-) button to adjust the volume to your preferred level.

Speaker Function

To activate the wireless speaker function, twist out the headphones to enable this feature, allowing the headphones to be used as a speaker.

Wired Headphone Mode

To use the headphones in wired mode, turn on the headphones first. Plug the 3.5mm cable into the "Aux-in" port and connect the other end to the computer or any other music device to use the headphones as a wired headphone.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**