PORODO



Porodo CHARGEJET TURBO DUST BLOWER

SKU: PDA1001BK

Table of Contents

Product Overview	2
Specifications	2
Product Catalogue	3
Product Description	3
Product Items	4
Safety Precautions	4
Disposal	5
Warranty	6
Contact Us	6


Product Features


The Porodo ChargeJet Turbo Dust Blower offers powerful cleaning with a maximum speed of 130,000 RPM. It features four adjustable speed levels for versatile dust removal, making it ideal for various cleaning needs. Additionally, it has a built-in power bank function, allowing for 100 minutes of working time. With Type-C charging, this compact tool provides convenience and efficiency in maintaining cleanliness.


Specifications

Material	ABS + PC
Motor Type	Brushless
Rated Power	180W
Battery Capacity	8000mAh (4000mAh x2)
Type-C Input	30W Max
Blowing Force	285g
Working Time	100 Minutes
Recharge Time	1.5H
Motor Speed	50,000RPM to 130,000RPM
Speed Levels	4
Type-C Output	30W Max
Product Weight	280g
Size	35 x 69 x 139mm
Model Number	PDA1001


Bluetooth Connection








2. Replaceable Nozzles x 2



3. Charging Cable x 1

Bass Effect

- 1. Wind speed button
- 2. TYPE-C
- 3. Air outlet
- 4. Air inlet
- 5. Gear LED indicators
- 6. Power button
- 7. Charging LED indicators





1. Power On / Off Button

Press and hold to power on. Press briefly to switch between gears:

1st Gear: 30,000 RPM

2nd Gear: 50,000 RPM

3rd Gear: 70,000 RPM

4th Gear: 90,000 RPM

2. Stepless Speed Regulation

Long press the wind speed button to adjust speed (130,000-0 RPM).

3. Gear Power Indicator

The four LED lights represent four power levels (1-2-3-4) from right to left. If all four indicators flash simultaneously, it indicates low power. If the device continues to be used, it will automatically shut down.

4. Type-C Charging

Supports fast charging. Avoid using the device while charging.

If the device has been used, wait at least 10 minutes before charging.

Bass Effect

1. Avoid High Temperature, Humidity, or Flammable Areas

Do not use this product in environments with high temperatures, excessive humidity, or near flammable substances. Exposure to such conditions may damage the product or cause safety hazards.

2. Keep Out of Reach of Children and Pets

Ensure this product is stored safely, away from children and pets, to prevent accidents or misuse.

3. Monitor During Charging

Always supervise the product while it is charging to prevent overcharging or discharging. Charge the product in a well-ventilated area, away from flammable materials, and avoid charging it in confined spaces. If the product or charging cable becomes excessively hot, discontinue charging immediately.

4. Check for Foreign Objects in Air Inlet

Before each use, ensure that the air inlet is clear of any debris, hair, or other obstructions. Blocking the air inlet can cause the motor to overheat and damage the product.

5. Avoid Direct Airflow to Body Parts

Do not direct the airflow from the product at sensitive areas of the body, such as the eyes, nose, ears, or mouth, as it may generate excessive heat, causing skin irritation or burns.

Self-Heating After Prolonged Use

After using the product at the highest wind speed for an extended period, switch to a lower speed to allow the motor to self-heat for 10 seconds. If the vacuuming time exceeds 15 seconds, remove any accessories and blow for another 10 seconds to help cool down the device.

7. Do Not Place in Confined Spaces While Operating

Never place the product in a bag or any confined space while it is turned on. Always ensure the battery is fully discharged before storing it to avoid overheating.

8. Prevent Drops and Collisions

Avoid dropping the product from a height or colliding it with other objects. If you notice any abnormal signs, such as the absence of airflow, motor jams, smoke, or strange noises, stop using the product immediately to prevent damage, short circuits, or fire hazards.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.





Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo