Green Lion

TECTRA| Foldable Keyboard Case

SKU: GNTEKEYBDGY

Model No: GKM-50

Table of Contents

Package Content

Bluetooth Office Keyboard *1
Type_C Charging Cable*1
Type -C *1
Instruction Manual *1

Multi- functional Leather

1. Open the multi-functional leather

2. Press down the magnetic area as shown and turn the leather toward back.

3. Place your phone or tablet on the leather support plate. It's both productive cover of key caps and bracket.

1   2   3

Quick View

Bluetooth Connect Channel Switching

Charging and Low Battery Caps Lock

Multi-functional Leather

Type-C Charging

Power On/Off

Multi- Finger Trach-pad

Before First Use

- Carefully Remove The Device And Accessories From The Package And Check The Package Content To Ensure It Is Complete And That Nothing Got Damaged. If The Content Is Incomplete Or Something Is Damaged, Immediately Contact Your Dealer.
- This Product Is Only Intended For Use In Private Households And Not Suitable For Commercial Use. Use The Device Only In Dry Indoor Rooms.

Important Notes

1. The Bluetooth Keyboard Is Suitable For iPAD/iMac/Mac Mini/Mac Book/Windows PC, And Compatible With iPAD OS 14.0/Mac OS 10.15/Windows 10/Windows 11 Or Higher.

2. Read Through The Operating Instructions Thoroughly Before The Initial Commissioning. Note The Warnings On The Product And In The Operating Instructions. They Contain Important Safety Instructions As Well As Operating And Maintenance Instructions For The Product.

3. Your Mac OS Computer Might Have FileVault Enabled, Which Could Prevent You From Entering Your Password At Start Or Reboot When Connected To Bluetooth. Please Contact Your Computer Service Provider For Solutions.

4. Please Charge The Keyboard Before Use.

Bluetooth Connection

Turn On The Power Switch: The Power Indicator Light Will Briefly Turn Red And Then Go Off.

1. Press And Hold The Combination Key "fn+1" For 3 Seconds. The Blue Light Will Flash, Indicating That The Keyboard Is In Bluetooth Pairing Mode.

2 . On The Device You Want To Pair With, Open Settings – Bluetooth – Search For Bluetooth Devices: Wireless Keyboard, Click To Connect. After Successfully Connecting To Bluetooth Device 1, The Blue Light Will Turn Off.

You Can Use The Same Method By Long-Pressing The Combination Keys "fn+2" And "fn+3" To Connect Bluetooth Device 2 And Bluetooth Device 3.

Channel Switching

Press The "fn+1" Combination Key Briefly To Select Bluetooth Device 1. The Blue Light Will Flash Once And Then Turn Off.

You Can Use The Same Method By Briefly Pressing The "fn+2" And "fn+3" Combination Keys To Switch To Bluetooth Device 2 And Bluetooth Device 3.

1. Press "fn+1" For 3S, Enter Pairing Mode

Press "fn+1" For 1S, Turn To Bluetooth Device 1

2. Press "fn+2" For 3S, Enter Pairing Mode

Press "fn+2" For 1S, Turn To Bluetooth Device 2

3. Press "fn+3" For 3S, Enter Pairing Mode

Press "fn+3" For 1S, Turn To Bluetooth Device 3

fn + A $_1$	fn + S $_2$	fn + D $_3$
1	**2**	**3**

Touch Pad Gestures

Windows System:

One Finger

1. MoveCursor	2. Type And Slide	3. Double Click Enter The File

Double Fingers

1. Move Right Mouse

2. Scroll And Pan

3. Pinch ZoomOut

4. Pinch Zoom In

Three Fingers

1. Search

2. Multi-Task Switching

3. Browse Task (Win+Tab)

4. Show Desktop (Win+D)

Four Fingers

Invoke Action Center

IOS(iPad) System:

One Finger

1. Move Cursor

2. Click Once To Enter The File

3. Type Twice And Slide

Double Fingers

1. Scroll And Pan

2. Move Task Windows

3. Pinch Zoom Out

4. Pinch Zoom In

5. Open "Today"

6. Open Search From Home Page

Three Fingers

1. Multi-Task Switching

2. Open/Shutdown Hidden Task Below (Cmd+Alt+D)

3. Open The App Switch Page

IOS (iPhone) System: Please confirm Assistive is opened your phone (Settings- Accessibility- Touch AssistiveTouch-Open).

One Finger

1. Move Cursor

2. Click once enter the file

| Double Fingers

4. Scroll and Pan

Android System:

One Finger

1. Move Cursor

2. Click once enter the file

| Double Fingers

1. Mouse right

2. Scroll and pan

Note: The Gesture Operation Logic In Different Operating SystemVersions And Different Applications May Be Different. Please Refer To The Actual Situation.

Shortcut Keys Instruction

| ~ ⇧ esc | ! 1 F1 | @ 2 F2 | # 3 F3 | $ 4 F4 | % 5 F5 | ∧ 6 F6 | & 7 F7 | * 8 F8 |

1. home
2. open browser
3. emotion
4. copy
5. cut
6. search
7. prev
8. break
9. next

| (9 F9 |) 0 F10 | — - F11 | + = F12 |

10.mute
11. volume-
12. volume+
13. lock screen

| fn | + | W Windows | Switch to Windows

| fn | + | Q iOS | Switch to IOS

| fn | + | E Android | Switch to Android

| fn | + | R Mac OS | Switch to Mac OS

| fn | + | ⌧ | Lock touch pad

Specifications

Model No.	GKM-50
Material	ABS+PC
Bluetooth Version	V5.0
Battery Capacity	500 mAh
Operating Voltage	3.3–4.2V
Touchpad Current	7–8 mA
Standby Current	0.5 mA
Key Operation Current	2.5 mA
Sleep Time	10 minutes
Operating Range	10 meters
Button Lifespan	5 million cycles
Charging Interface	Type-C
Charging Time	2.5 hours
Working Time	20–30 days
Supported Systems	Windows, Android, iOS, Mac OS
Product Weight	360 g
Folded Dimensions	250.5*91.0*16.0 mm
Unfolded Dimensions	250.5*182.0*7.5 mm

Important Notes

1. Please Use A Charger With A 5V1A Specification.

2. This Product Is Not Waterproof. Please Avoid Water From Entering The Product.

3. Do Not Use Organic Solvents To Clean The Surface Of The Product.

Safety Instructions

1. Use The Product Only For Its Intended Purpose, Using The Recommended Accessories And Components. Improper Or Incorrect Use Is Dangerous.

2. Never Leave The Product Unattended While It Is Turned On. Do Not Place Any Objects Onto The Product. Never Immerse Electrical Components Of The Product In Water Or Other Liquids While Cleaning Or During Operation. Never Place The Product Under Running Water.

3. Never Perform Any Repairs On The Product Yourself. Only An Authorized Service Center May Carry Out Maintenance Work And Repairs.

4. This Product Is Not Intended For Use By Persons (Including Children) With Limited Physical, Sensorial Or Mental Abilities Or Lack Of Experience And/Or Knowledge, Unless They Are Supervised Or Have Been Instructed Concerning Safe Use Of The Appliance By A Person Responsible For Their Safety.

5. Children Should Be Supervised To Ensure That They Do Not Play With The Product.

6. Protect The Product From Extreme Temperatures, Direct Sunlight, Strong Vibrations, High Humidity, Moisture, Flammable Gases, Vapors And Solvents. Do Not Expose The Product To Any Mechanical Stress.

7. In The Case Of Safe Operation Being No Longer Possible, Switch Off The Product And Prevent It From Being Used Accidentally.

⚠ Danger Of Suffocation! Keep All Packaging Material Away From Children.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **https://www.greenlion.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
https://www.greenlion.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
Website: **https://www.greenlion.net/**
Sales: **sales@greenlion.net**
Service Support: **Support@greenlion.net**
Telegram: **@greenlion_global**
Instagram: **@greenlion_global**