

PORODO



Porodo

DUAL-MODE Hair Straightening Brush

SKU: PDLFSTHC115PK

Table of Contents

Important Safety Instructions	2
Precaution for Use	2
Product Components	4
Specifications	5
Instructions for Use	5
a. Hair Straightener	5
b. Hair Straightening Brush	6
Install and Remove the Protective Plate	7
Disposal	8
Warranty	8
Contact Us	8

Important Safety Instructions

1. Always unplug the appliance after use.
2. Do not immerse the appliance in water or any other liquid.
3. If the appliance falls into water, immediately unplug it. Do not attempt to retrieve it from the water.
4. Verify that the voltage indicated on the appliance matches the local mains voltage before connecting the appliance. Regularly inspect the condition of the mains cord. Do not use the appliance if the plug, cord, or appliance is damaged.
5. Use this appliance solely for its intended purpose as outlined in this manual. Do not use attachments that are not recommended by the manufacturer.
6. Allow the appliance to cool down before storing it. Keep the cord away from heated surfaces. Avoid pulling, twisting, or wrapping the cord around the appliance.
7. Do not drop or insert objects into any openings, particularly the ventilation holes. To ensure safety, the straightener brush will automatically power off if a foreign object is inserted.
8. The appliance becomes hot during use. Avoid contact with eyes or bare skin on heated surfaces.
9. The appliance will automatically power off if left unused for 60 minutes.

Precaution for Use

- Warning:** To reduce the risk of burns, electrocution, fire, or injury to persons:
1. Never leave this appliance unattended while it is plugged in.
 2. This appliance should not be used by or near children, or individuals with certain disabilities.
 3. Use this appliance only for its intended purpose, as described in this manual. Do not use attachments that are not recommended by the manufacturer.

- 4.** Never operate the appliance if the cord or plug is damaged, if it is not functioning properly, or if it has been dropped or damaged, or submerged in water. Return the appliance to an authorized service center for inspection and repair.
- 5.** Keep the cord away from heated surfaces. Do not pull, twist, or wrap the cord around the appliance.
- 6.** Never use the appliance while sleeping.
- 7.** Never drop or insert any object into any openings or hoses.
- 8.** Do not use outdoors or operate the appliance in areas where aerosol (spray) products are being used or where oxygen is being administered.
- 9.** The unit becomes hot during use. Avoid contact with heated surfaces, especially the eyes or skin.
- 10.** Do not place the heated unit directly on any surface while it is hot or plugged in. Always use the stand provided.
- 11.** Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be obstructed. Keep air openings free from lint and other debris.
- 12.** Do not touch hot surfaces of the appliance. Always use the handles or knobs.
- 13.** Avoid touching the housing of the appliance near the barrel, as it becomes hot during use.
- 14.** Do not operate the appliance with a voltage converter.
- 15.** Do not use an extension cord with this appliance.
- 16.** This appliance is hot during use. Avoid contact with eyes and bare skin on heated surfaces.
- 17.** This appliance is intended for household use only.
- 18.** Do not insert anything into the vents.
- 19.** Failure to follow these warnings may result in damage or safety accidents. Our company will not be responsible for any such incidents.



Product Components

Temperature indicators


Heating plates

Blowing button

Power button



Detachable protective plate







Specifications

Rated Power	76W
Rated Voltage	100-240V
Rated Frequency	50/60Hz
Heating Method	PTC
Power Cord	2m, UK Plug
Temperature Control	160°C-180°C-200°C
Product Size	6.6 × 32 × 275.5mm
Product Weight	496g
Model Number	PDLFSTHC115




Instructions for Use


a. Hair Straightener

1. Install the detachable plastic protective plate.
2. Plug the appliance into a socket. The five indicator lights will flash three times in a cycle, and the appliance will enter standby mode.
3. Turn the lock switch to unlock () the appliance.
4. Turn the function switch to hair straightener mode ().
5. Press and hold the power button () for 1.5 seconds to turn the appliance on.

6. The "M" mode indicator will turn red, indicating that the appliance is in hair straightener mode.
7. The default temperature is 180°C.
8. You can press the power button to change the temperature to 160°C, 180°C, or 200°C.
9. When the corresponding red temperature indicator flashes, it indicates the appliance is heating up.
10. When the corresponding red temperature indicator remains on, the temperature has been reached.
11. When the temperature approaches -20°C of the set temperature, the hot air will automatically turn on.
12. You can turn off the hot air by pressing the blowing button ().
13. Turn off the appliance by holding the power button for 1.5 seconds after use.
14. Unplug the appliance immediately after use.
15. If no operation is performed, the appliance will automatically power off after 60 minutes.


b. Hair Straightening Brush

1. Install the detachable brush.
2. Plug the appliance into a socket. The five indicator lights will flash three times in a cycle, and the appliance will enter standby mode.
3. Turn the lock switch to the "lock" position ().
4. Turn the function switch to hair straightening brush mode ().
5. Press and hold the power button () for 1.5 seconds to turn the appliance on.
6. The "M" mode indicator will turn green, indicating that the appliance is in hair straightening brush mode.
7. The default temperature is 180°C.
8. You can press the power button to change the temperature to 160°C, 180°C, or 200°C.
9. When the corresponding red temperature indicator flashes, it indicates the appliance is heating up.


10. When the corresponding red temperature indicator remains on, the temperature has been reached.
11. When the temperature approaches -20°C of the set temperature, the hot air will automatically turn on.
12. You can turn off the hot air by pressing the blowing button ().
13. Turn off the appliance by holding the power button for 1.5 seconds after use, and unplug the appliance immediately.
14. If no operation is performed, the appliance will automatically power off after 60 minutes.

Install and Remove the Protective Plate

Install: Align the corresponding holes as shown in the picture and push in the direction indicated by the arrow to install the protective plate or brush.



Remove: Press the release button in the direction shown in Picture 1. Remove the protective plate or brush in the direction indicated in Picture 2.



Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**