



Green Lion

TRI-FOLD WIRELESS KEYBOARD

SKU: GNTRIKYBDGY Model No: GKM-55

Table of Contents

| Product Overview | 2 |
|--------------------------|---|
| Specifications | 2 |
| Setup Guide | 3 |
| Cleaning and Maintenance | 8 |
| Safety Precautions | 8 |
| Disposal | 9 |
| Warranty | 9 |
| Contact Us | 9 |

Product Overview


The Green Lion Tri-Fold Wireless Keyboard features a sleek and compact design with a scissor-switch structure, providing smooth and quiet keystrokes. It offers a long-lasting 5 million keystroke lifespan and efficient 400-hour standby time. This keyboard is highly portable due to its tri-fold design, making it an ideal option for on-the-go use. Additionally, it features high-sensitivity touchpad functionality, supports stable wireless connectivity up to 10 meters, and is compatible with multiple devices, ensuring convenient and quick input.

Specifications

| Model | GKM-55 |
|-------------------|------------|
| Material | ABS+PC |
| Bluetooth Version | V5.0 |
| Battery Capacity | 180 mAh |
| Operating Voltage | 3.3-4.2 V |
| Touchpad Current | ≤ 7.5 mA |
| Standby Current | < 0.5 mA |
| Operating Current | ≤ 2.5 mA |
| Sleep Time | 10 minutes |
| Operating Range | 10 meters |

| Button Lifespan | 5 million cycles |
|--------------------|------------------------------|
| Charging Interface | Type-C |
| Charging Time | 2 hours |
| Working Time | ≥ 20 days |
| Supported Systems | Windows, Android, iOS, MacOS |
| Product Weight | 158 grams |
| Folded Size | 15.8*98*157.5 mm |
| Unfolded Size | 8.2*98*315 mm |

Setup Guide



- Press Fn + A for 3S, enter pairing mode. (Bluetooth KB-01)
 Press Fn + A for 1S, turn to Bluetooth device.
- Press Fn + S for 3S, enter pairing mode. (Bluetooth KB-02)
 Press Fn + S for 1S, turn to Bluetooth device.
- Press Fn + D for 3S, enter pairing mode. (Bluetooth KB-03)
 Press Fn + D for 1S, turn to Bluetooth device.

1. Bluetooth Connect

Switch the power to "ON." The Bluetooth LED will light up. Then, press the combination keys "FN + A/S/D" to enter Bluetooth pairing mode. On your computer or phone, go to "Settings," turn on Bluetooth, and search for Bluetooth devices. When the "Bluetooth Keyboard" appears, click to pair. Once successfully connected, the Bluetooth indicator light will turn off, and the keyboard will be ready to use.

2. Status Display LED

Connect: Open the power switch; the red light will illuminate. Press the connect button, and the red light will blink.

Charging: The indicator light will show red. After full charging, the light will turn off.

Low Voltage Indication: When the voltage drops below 3.3V, the red light will blink.

Remarks: To extend the battery life, please turn off the power when the keyboard is not in use for an extended period.




3. Function Keys

| Fn + C | | n to iOS | Fn + E | Switch | to Android |
|-----------------------------------|----------|-------------------------|--|-------------|-------------------------|
| Fn+ | = | Corresponding functions | Fn+ | = | Corresponding functions |
| ~ 協 、 Esc | Û | Home | ~ 公 、 Esc | Û | Home |
| ! all 1 F1 | all | Select all | ! all 1 F1 | all | Select all |
| @ [] 2 F2 | C] | Сору | @ [] 2 F2 | cj | Сору |
| # 🖫 3 F3 | | Paste | # 🖫 3 F3 | 国 | Paste |
| \$ \(\sum_{4} \) \(\text{F4} \) | * | Cut | \$ \$\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\ | \ | Cut |
| % Q 5 F5 | Q, | Search | % Q 5 F5 | Q | Search |
| ^ Idd 6 F6 | MA | Prev | ^ Idd 6 F6 | Ma | Prev |
| & ⊳II 7 F7 | ⊳II | Break | & ⊳II 7 F7 | ÞII | Break |
| * DDI 8 F8 | DDI | Next | * ÞÞ 8 F8 | ⊳ ⊳l | Next |
| (t) 9 F9 | □ | Volume - | (| □ | Volume - |
| () (d))) () F10 | ط))) | Volume + | () (d))) () F10 | ط))) | Volume + |
| - □× - F11 | Ц× | Mute | - は× - F11 | ٦× | Mute |
| + 🗀 = F12 | | Lock screen | + 🗀 = F12 | | Lock screen |
| | Delete | Delete | | Delete | Delete |


| Fn + Q Switch to Win | | Fn + E | Switch | to Mac OS | |
|----------------------|--------------------------|-------------------------|--|--------------------------|-------------------------|
| Fn + shift + | = | Corresponding functions | Fn + | = | Corresponding functions |
| ~ G | Û | Home | ~ G | Û | Desktop |
| ! al 1 F1 | all | Select all | ! all 1 F1 | all | Select all |
| @ © 2 F2 | ្បា | Сору | @ © 2 F2 | ij | Сору |
| # 🔄 3 F3 | 国 | Paste | # 3 F3 | | Paste |
| \$ \(\begin{align*} | \ | Cut | \$ \$ \(\begin{aligned} \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ | \ | Cut |
| % Q 5 F5 | Q | Search | % Q 5 F5 | Q | Search |
| ^ Idd 6 F6 | MA | Prev | ^ Idd 6 F6 | MA | Prev |
| & ⊳II 7 F7 | ÞII | Break | & ▷ 7 F7 | ÞII | Break |
| * DDI 8 F8 | $\triangleright \bowtie$ | Next | * ÞÞ 8 F8 | $\triangleright \bowtie$ | Next |
| (-t1) 9 F9 | D | Volume - | (4) 9 F9 | D | Volume - |
| () (d))) () F10 | 니))) | Volume + | () (J))) () F10 | 口))) | Volume + |
| - □× - F11 | Ц× | Mute | - 덕× - F11 | Ц× | Mute |
| + 🗀 = F12 | | Lock screen | + 🗀 = F12 | | Lock screen |
| | Delete | Delete | | Delete | Delete |

4. Touch pad function


Function of Win10+ Version



Function of iOS13+ Version



Android 系统对触摸板功能



| 1-Finger | 2-Finger | 3-Finger | | |
|--------------------------------------|---|--|--|--|
| Left Click Double Click Move Cursor | Zoom in (out) on the web page Scroll/Pan | 3-Swipe right Switch active window to the right(Cmd+Tab) 3-Swipe left Switch the active window to the left(Cmd+Shift+Tab) | | |
| 4-Finger | Invoke Action Center (Cmd+Shift) | | | |



Cleaning and Maintenance

Keep the keyboard away from liquid or humid environments, such as saunas, swimming pools, or steam rooms. Avoid getting the keyboard wet in the rain.

Do not expose the keyboard to extreme temperatures.

Avoid leaving the keyboard under direct sunlight for extended periods.

Keep the keyboard away from flames, such as those from cooking stoves, candles, or a fireplace.

Prevent sharp objects from scratching the keyboard and ensure it is regularly recharged for optimal performance.

Troubleshooting

For assistance, please contact customer service.



Safety Precautions

This section outlines cases not covered by the warranty:

Damage caused by accidents, misuse, improper operation, unauthorized repairs, modifications, or removals.

Improper operation or maintenance, including violations of the provided instructions or use with incompatible power supplies.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **https://www.greenlion.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: https://www.greenlion.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: https://www.greenlion.net/

Sales: sales@greenlion.net

Service Support: Support@greenlion.net

Telegram: @greenlion_global
Instagram: @greenlion_global