

PORODO
LIFESTYLE



Porodo Lifestyle
COOKING SET
Dual Stove Camping Table

SKU: PDLFST219BK

Table of Contents

Product Overview	2
Specifications	2
Product Features	3
Safety Precautions	4
Safety Prohibitions	5
Operation Guide	7
Disposal	8
Warranty	8
Contact Us	8

Product Overview

The Porodo Lifestyle Dual Stove Camping Table is a versatile and practical cooking set designed for outdoor adventures. Made with durable 304 stainless steel, this camping stove ensures reliable performance while using butane fuel for optimal heating efficiency. It offers precise flame control, allowing you to adjust the heat for different cooking needs. The compact and portable design makes it easy to carry and set up, making it perfect for camping trips. With thermal power options of 3000W and 5000W, this stove ensures quick and even heating, enhancing your outdoor cooking experience.

Specifications

Table Material	Aluminum
Stove Material	304 Stainless Steel
Table Size	44.5 x 63 x 82cm
Stove Folded Size	8.5 x 13 x 36cm
Stove Expanded Size	9.5 x 18 x 36cm
Gas Hose Length	65cm
Gas Type	Butane
Ignition	Electric

Thermal Power (1-Eye Stove)	3000W
Thermal Power (3-Eye Stove)	5000W
Model Number	PDLFST219

Product Features

- 1. Multi-Functional Design:** The 304 stainless steel construction provides durability, while the foldable legs offer easy portability and storage. This design makes the cooking set perfect for outdoor adventures such as camping, picnics, or beach outings.
- 2. Quick and Even Heating:** The stove's burner is designed to heat up rapidly, allowing for quick cooking. It ensures consistent heat distribution across the surface for evenly cooked meals every time.
- 3. Precise Flame Control:** Equipped with dual burners that allow precise flame adjustment, you can easily control the heat to suit different cooking techniques—whether you need a high flame for boiling or a low one for simmering.
- 4. Compact and Portable:** The stove is lightweight, weighing only [insert weight here], and it folds into a compact size that can easily fit into your car or storage space, making it ideal for travel and camping.
- 5. Two Power Options:**
 - a. 3000W Thermal Power:** Perfect for smaller groups or simple meals, providing sufficient power for most outdoor cooking needs.
 - b. 5000W Thermal Power:** Offers higher thermal output, allowing you to cook larger meals for bigger groups faster and more efficiently.

Safety Precautions




1



3



2



4

1. Avoid Placing Near Heat Sources

Do not place the butane gas tank near hot gas or heat sources. Ensure the gas is fully vaporized for safe operation. Temperature changes in the liquefied butane gas tank are normal.

2. Store Away from Open Flames and Direct Sunlight

After sealing the cap, keep the tank away from open flames and direct sunlight (including indoor areas like beside beds and windows). Store in a well-ventilated space with temperatures under 40°C.

3. Do Not Place the Gas Tank in Fire

Never place the butane gas tank into a fire. Doing so could cause an explosion.

4. Discard the Tank After Gas Is Expended

If there is a sound when shaking the tank, it means there is still gas inside. Once the gas is fully used, discard the tank following local disposal regulations. If residual gas remains, it could pose a hazard during cleaning.

5. Use High-Quality Gas

The butane gas tank must be filled with high-quality gas. If poor-quality gas is used repeatedly, the portable furnace may become unusable or leak.

6. Danger of Inhalation

Do not intentionally inhale butane gas into your body. Inhaling large amounts of butane gas can cause serious injury to your health.

7. Avoid Hitting the Gas Tank

Never intentionally hit or drop the butane gas tank. Dropping it from a height may cause damage or gas leakage, creating a fire hazard.

8. Do Not Use Deformed Tanks




Deformed butane gas tanks are prone to leakage. Do not use tanks that have become deformed.

9. Check Storage Tanks Regularly

The butane gas tank in storage should be checked periodically to ensure it remains safe and in proper condition.

Note: If the gas tank has not been used for a long time, check the rubber seal for aging or damage, and remove the gas cylinder promptly after use.


K Safety Prohibitions




5




6




7



8




9




10



11



12



1. Avoid use in narrow or sealed spaces.

Using the stove in confined spaces like tents or cars is prohibited. The burning process consumes a large amount of oxygen, leading to insufficient oxygen in the area, which can cause asphyxiation and increase the risk of fire from surrounding combustibles.

2. Do not use in unstable or shaky locations.

Using the stove in unstable areas may cause it to tilt or move, resulting in an enlarged flame and increasing the risk of fire. Additionally, the pot may overturn. Always place the stove on a stable, flat surface.

3. Keep away from hot objects.

Do not use the portable stove near high-temperature objects, as this could cause the gas tank to explode.

4. Do not use outdoors in windy conditions.

Using the stove outdoors in windy weather may cause the flame to flare up, potentially damaging the stove or causing accidents.

5. Do not use alcohol-based cleaners or chemicals to clean the stove, as they may cause burns.

6. Do not leave the stove unattended while in use.

7. Keep flammable liquids away from the stove. Do not spray flammable liquids near it.

8. Avoid using the stove near flammable objects.

9. Do not use the stove for direct exposure.

10. Do not allow children to use the stove.

11. After use, avoid touching the stove's surface immediately to prevent scalding.

12. Only use the stove on a flat, clean surface. Keep it away from dust, sand, and other debris to prolong its life.

Operation Guide

1. Open the supporting feet or place the stove on a stable, flat surface to ensure it is upright.

2. Connect the Alpine gas tank and check for any air leakage.

3. Turn the intake knob to the "desktop" position and press the ignition button once you hear the sound of venting.

4. Once ignition is successful, adjust the flame size using the knob.

5. After use, turn the regulator to the "off" position to extinguish the flame.



This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty



If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net
Website: **porodo.net**
Service Support: **support@porodo.net**
Instagram: **porodo**