



Porodo Lifestyle HANDHELD HAIR STRAIGHTENER

SKU: PDBL006PK

Table of Contents

Product Overview	2
Specifications	2
Safety Precautions	3
Setup Guide	4
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Porodo Handheld Hair Straightener is a compact and efficient styling tool designed for on-the-go use. With a temperature range of 120°C to 200°C, it offers customizable heat settings to suit various hair types. Powered by a 2000mAh battery, it ensures convenience and portability, making it perfect for travel. Its sleek pink design features a user-friendly interface and a safety shut-off function. The product is designed for easy use, with a 24-month warranty, ensuring durability and reliability for everyday styling.

Specifications

Input	DC 5V/2A
Rated Power	22W
Battery Capacity	2600mAh
Recharge Time	3H
Working Time	25 Minutes
Charging Interface	Type-C
Temperature Range	140°C ~ 200°C
Product Size	2.5 × 2.5 × 22cm
Product Weight	165g
Model Number	PDBL006

Safety Precautions

When using the product, a slight burnt smell may occur, which is a normal phenomenon when the new product is exposed to high temperatures. Please be assured that as you continue using it, the smell will gradually decrease.

Before disposing of the appliance, ensure the battery is removed. When removing the battery, the appliance must be powered off.

Please dispose of the battery properly.

Danger:

Only use a qualified plug to charge this product, as improper use may damage it. Do not use the product if you have a reduced sensitivity to heat, as it may cause burns or scalds.

If the product is malfunctioning, please stop using it immediately, as it could lead to accidents or serious personal injury. Do not use the product near bathtubs, showers, or basins filled with water.

Warnings:

- 1. Avoid use during showers: Do not use the product while taking a shower or bath, or near bathtubs, showers, or other water sources.
- 2. Prevent damage: If the product becomes deformed or damaged, stop using it immediately to avoid electrical shock or fire risks.
- **3.** Keep away from flammable materials: Do not use near flammable or explosive materials (e.g., alcohol, gasoline, nail polish remover). Doing so may cause fire or explosion.
- 4. Handle with care: Avoid dropping the product. If damaged due to dropping, do not continue use.
- **5.** Cool down after use: Allow the product to cool down for a short period before turning it off or storing it.
- **6.** Avoid covering the product: Do not place any items on the product while it is in use.
- 7. Temperature caution: The surface of the heating element can reach up to 200°C. Do not place the product on soft cushions or blankets while in operation.

- **8.** Warning about heating teeth: When in use, the heating teeth become very hot. Never touch them directly during operation.
- **9.** Flammable substances: Before use, avoid contact with flammable substances (e.g., styling agents, hair mousse) while using the product.
- 10. Not for individuals with health conditions: This product is not suitable for use by individuals with physical, sensory, or mental health issues, or those lacking the required knowledge or experience, unless supervised by a guardian.
- 11. Supervision for children: Ensure children do not use or play with the product without proper supervision.
- 12. Packaging: Please dispose of packaging materials (e.g., plastic bags) properly, and keep them out of reach of children.
- 13. Not for pets: This product is not suitable for pets.

Setup Guide

- A. Operation Method
- 1. Press and hold the power button to turn on the device, which will automatically shut off after 30 minutes.
- 2. Choose the desired temperature range by pressing the switch according to your hair quality requirements.
- **3.** When the product heats up, the white LED light will blink, indicating the current gear. When the product reaches the set temperature, the white LED light will remain on.
- 4. Press and hold the power button for 3 seconds to turn the device off. After shutdown, all indicator lights will turn off, and the heating will stop.
- **5.** While charging, the charging indicator light will flash white, and the light will remain on once fully charged. The product cannot be used while charging.
- B. Operation of Wireless Hair Perm
- 1. When using the product, ensure your hair is dry, as wet hair may not achieve the desired effect.

- 2. Confirm that the device is powered off before charging to prevent accidental power-on during transportation.
- **3.** While charging, the ambient temperature should not exceed 40°C, and the device cannot charge if the temperature is too high. Charging time from 0% to 100% takes approximately 3-4 hours. Using a plug that exceeds 5V–2A for charging will lock the product, preventing it from charging (this may vary depending on the charging time).
- 4. Please fully charge the product before using it for the first time.
- 5. Fast charging is not supported.
- C. Temperature Selection Recommendations

140°C: For dyed, damaged, or delicate hair

160°C: For ordinary hair

180°C: For ordinary or slightly curly hair

200°C: For very thick, curly, and rough hair

1. Pre-Styling Preparation:

Clean hair and blow dry it, thoroughly combing until smooth and free from tangles.

After turning on the device, select the temperature best suited for your hair type.

2. Operation of Wireless Hair Perm

Turn on the device and press the temperature control button to adjust the temperature according to your hair quality needs.

After reaching the desired temperature, hold the handle, ensuring the distance between the heating element and your skin/eyes is safe.

Divide the hair evenly, grip, and tighten it. Place the comb 1-3 cm from the root, then smoothly pull down from root to tip. Repeat the process to achieve the desired straight hair effect.

After styling, press and hold the power button for 3 seconds to turn off the device. Once cooled, comb the hair with a separate comb.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.





Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo