

PORODO



Porodo

FOLDABLE MINI STRAIGHTENER BRUSH

SKU: PDLFSTHC313PK

Table of Contents

Product Overview	2
Specifications	2
Product Features	3
Safety Precautions	4
Hair Straightener Brush Instructions	4
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Porodo Foldable Mini Straightener Brush is a versatile, cordless styling tool designed for travel. With three heat modes, it allows you to customize your styling experience, while the ceramic-coated teeth ensure smooth and frizz-free results. The even heat distribution technology helps to prevent hot spots, ensuring consistent performance. The brush features USB-C fast charging for quick and convenient power-ups, and an auto safety shut-off for peace of mind. Its compact, foldable design makes it perfect for on-the-go styling, fitting easily into any travel bag. Whether you're at home or traveling, this mini straightener brush offers a convenient and efficient solution for your hair care needs.

Specifications

Input	5V/2A
Battery Capacity	3200mAh
Rated Power	28W
Temperature Settings	160°C / 180°C / 200°C
Charging Interface	Type-C
Cable Included	1m Type-C
Product Size	22.8×58×112.1mm
Product Weight	136g
Model Number	PDLFSTHC313

Product Features

a. Ceramic Coating

The brush is equipped with a high-quality ceramic coating that ensures smooth and gentle styling while protecting your hair from heat damage. The coating helps to maintain hair's natural shine and reduce frizz for a polished look.

b. Even Heat Distribution

With advanced technology, this straightener ensures that heat is evenly distributed throughout the brush. This guarantees consistent results, whether you're styling a small section or larger areas of your hair.

c. 3 Heat Modes

The straightener comes with three adjustable heat settings, allowing you to choose the optimal temperature based on your hair type and styling needs. Whether you have fine, thick, or coarse hair, this feature provides versatility for the best results.

d. Ceramic-Coated Teeth

The teeth of the brush are also coated with ceramic, ensuring that each strand of hair glides through smoothly without tugging or pulling. This also reduces hair breakage and helps in achieving a sleek, frizz-free style.

e. USB-C Fast Charging

Equipped with USB-C fast charging, this brush allows you to quickly recharge the device for long-lasting performance. Whether you're traveling or at home, you can enjoy the convenience of fast, reliable charging.

f. Auto Safety Shut-Off

For added safety, the straightener features an auto shut-off function that turns the device off after a period of inactivity. This feature ensures you don't need to worry about leaving the appliance on by accident, providing extra peace of mind.

g. Cordless Travel Styling

Designed for convenience, this mini straightener is cordless, making it perfect for travel. You can easily take it with you for on-the-go styling without needing to search for a plug, making it ideal for those busy mornings or when traveling.

h. Foldable Design

The straightener brush is foldable, which means it can be compacted into a smaller, space-saving size. This design feature makes it easy to store in a bag or luggage, making it the perfect companion for travel or home use.

Safety Precautions

1. Always unplug the appliance after use.
2. Do not place or drop the appliance into water or any other liquid.
3. If the appliance falls into water, immediately unplug it. Do not reach into the water.
4. Check that the voltage indicated on the appliance matches the local voltage before use. Regularly inspect the appliance, plug, and cord for damage.
5. Only use the appliance for its intended purpose as outlined in the manual. Avoid using non-recommended attachments.
6. Allow the appliance to cool before storing. Keep the cord away from heated surfaces. Do not twist, pull, or wrap the cord around the appliance.
7. Do not drop or insert objects into the appliance's openings, especially the ventilation holes. The appliance will automatically shut off if foreign objects are detected.
8. Be cautious of heated surfaces when using the appliance. Avoid direct contact with skin or eyes.
9. The appliance will automatically power off after 60 minutes of non-operation.
10. Never leave the appliance unattended while plugged in.

Hair Straightener Brush Instructions

1. Turn On the Appliance

Press the power button  for 1.5 seconds. The default temperature is 180°C, but you can change it to 160°C, 180°C, or 200°C by pressing the power button.

- a. When the corresponding red temperature indicator flashes, the appliance is heating.
- b. When the indicator stays on, the desired temperature has been reached.

2. Turn Off and Unplug

After use, hold the power button for 1.5 seconds to turn off the appliance and unplug it instantly.

3. Auto Power Off

If no operation occurs, the appliance will automatically power off after 60 minutes.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**