

PORODO
LIFESTYLE



Porodo Lifestyle
CAMPSHADE
Camping Dual Chair

SKU: PDLFSTCH21BK

Table of Contents

Product Overview	2
Specifications	2
Product Features	3
Usage Guide	4
Safety Precautions	4
Unfolding Instructions	5
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Porodo Camping Dual Chair with a detachable sun umbrella is designed for maximum comfort and convenience during outdoor activities. Made with a strong steel frame and featuring dual, wide seats that are 60 cm in width, this chair offers stability and durability. It features an integrated ice pouch to keep your beverages cool, with a drain hole and cap for easy emptying. The chair also includes a handy storage pocket for snacks, gadgets, or essentials. The detachable sun umbrella provides adjustable shade for two people, ensuring you stay protected from the sun. With a weight capacity of up to 120 kg and 600D Oxford fabric, this camping chair is built to withstand various outdoor conditions. Perfect for camping, picnics, or any outdoor adventure, it seamlessly blends practicality and comfort.

Specifications

Frame Material	16mm Powder-Coated Steel Tube
Fabric	600D Oxford Cloth
Seat Width	60cm each side
Net Weight	6.7kg
Weight Capacity	120kg x2
Umbrella Size	140cm (Diameter)
Storage Capacity	12L (Ice Pouch & Storage Pocket)

Folded Dimensions	23 x 26 x 96 cm
Unfolded Dimensions	53 x 167.5 x 173 cm
Carrying Bag Dimensions	49 x 104 cm
Model Number	PDLFSTCH21

Product Features

- 1. Strong X-Frame:** Provides sturdy and reliable support for lasting durability.
- 2. Detachable Sun Umbrella:** Protect yourself from the sun with an easily removable umbrella.
- 3. Ice Pouch and Storage Pocket:** Keep drinks cold with the integrated ice pouch and store small items in the convenient pocket.
- 4. Cup Holder:** Stay refreshed by having your cup or bottle within easy reach.
- 5. Dual Wide Seats:** 60cm seats made from durable 600D Oxford fabric for ultimate comfort.
- 6. Strong Steel Frame:** 16mm powder-coated steel tubing ensures long-lasting durability.
- 7. Integrated Ice Pouch:** Keep your beverages cool with a built-in ice pouch and a drain hole for easy cleanup.
- 8. Extra Storage Pocket:** Convenient space for snacks, gadgets, or essentials.
- 9. Mesh Backrest:** Provides breathability and comfort during use.
- 10. Foldable Design:** Easy to carry and store, making it perfect for outdoor activities.

Usage Guide

1. Separate and count all parts and hardware before beginning assembly.
2. Review each step carefully and follow the sequence as outlined.
3. Assemble items as close as possible to their intended use area to avoid unnecessary movement post-assembly.
4. Ensure the product is placed on a flat, firm, and stable surface during use.
5. Keep all small parts and packaging materials out of reach of children and babies to prevent choking hazards.

Safety Precautions

1. Ensure Stability: Always set up the chair on a flat, stable surface to prevent tipping or imbalance.
2. Check Frame Condition: Regularly inspect the steel frame for any signs of wear, cracks, or rust before use to avoid structural failure.
3. Avoid Overloading: Do not exceed the weight limit to ensure safe and secure seating.
4. Secure Umbrella: Always make sure the umbrella is properly secured before use to avoid accidental dislodging or damage.
5. Use the Ice Pouch Correctly: Avoid overfilling the integrated ice pouch to prevent leaks and ensure proper drainage.
6. Avoid Sharp Objects: Do not place sharp objects in the storage pocket to prevent damage to the fabric or personal injury.
7. Proper Folding: Always fold the chair carefully to avoid pinching or damaging the fabric and frame.

Unfolding Instructions

1. Unlock the two retention clips to release the chair from its compact form.
2. Unfold the camping chair by spreading it outward from the sides.
3. Place the chair on a stable surface to ensure proper stability.
4. Insert the end of the umbrella into the back of the chair for added shade.
5. Open the umbrella and place it into the sleeve.
6. Once the umbrella height is adjusted, press the armrest on the pole inward to secure it.
7. The installation is now complete.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at porodo.net/warranty and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**