

PORODO
LIFESTYLE



Porodo Lifestyle
COOLBREEZE
70W Smart Tower Fan

SKU: PDLFSTTFBK



Table of Contents

Product Overview	2
Specifications	2
Powering On	3
Button Functions	3
Time and Speed Control	4
Lighting Control	5
Energy Saving Mode	5
Safety Precautions	5
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Porodo Lifestyle 70W Smart Tower Fan, named COOLBREEZE, combines powerful cooling with additional features like aromatherapy and air purification for a refreshing atmosphere. Designed for versatility, it offers timed operation, dynamic wind control, and high light settings for optimal comfort. This fan’s sleek, modern design fits seamlessly into any room, delivering both functionality and style. Whether you’re looking to purify the air or enjoy a soothing fragrance, the COOLBREEZE fan enhances your environment, making it perfect for both cooling and creating a pleasant, healthy space.

Specifications


Rated Power	60-70W
Rated Voltage	230V
Rated Frequency	50Hz
Noise Level	45dB
Wind Speed	12m/s Max
Plug Type	UK 3-Pin
Model Number	PDLFSTTF

Powering On

1. Plug in the power supply. All indicator lights will turn on, and the digital screen will light up fully for 0.5 seconds.
2. The POWER indicator will remain constantly on.
3. The digital screen will display the current ambient temperature in °C.
4. The machine is now in standby mode.
5. Touch the POWER button to turn on the machine.
6. The fan will start at speed 2 for 3 seconds, then switch to speed 1.
7. The display will show the wind speed as "01."
8. After 30 seconds of no operation, the display will switch to show the current ambient temperature.

Button Functions

1. ON/OFF Key
 2. Speed Button
 3. Timer Button
 4. Oscillation Switch
 5. Mode Button
 6. Lighting Button
-
- A. Display screen indicator light
 - B. Temperature display
 - C. Scheduled time display
 - D. Standby display
 - E. Timed indicator light
 - F. Oscillation indicator light
 - G. Wind speed mode
 - H. Natural wind mode
 - I. Sleep wind mode



Time and Speed Control

1. Time settings

- a.** Press the TIMER key to activate the timer. The display will show the set time in increments: 1H, 2H, 3H, 4H, 5H, 6H, 7H, 8H, 9H, 10H, 11H, or 12H. Once the set time is reached, the fan will stop.
- b.** To adjust the timer, press and hold the TIMER key to directly set the time to 12H.
- c.** To deactivate the timer, press the TIMER key again.
- d.** After 5 seconds of inactivity, the display will automatically switch to show the current fan speed. After 30 seconds of no operation, the display will switch to the current environmental temperature.

2. Speed settings

- a.** Touch the SPEED button to adjust the fan speed. The fan speed will change in increments of 01, 02, 03, 01.
- b.** The corresponding indicator light will show as NOR, signaling the normal wind setting.
- c.** After 5 seconds of inactivity, the display will switch to show the current fan speed. After 30 seconds of no operation, the display will switch to the current ambient temperature.

3. Mode settings

- a.** Activate Mode: When the device is powered on, touch the MODE key to activate the speed control function. The fan will operate in the natural wind mode, and the NA indicator light will remain on.
- b.** Switch to Sleep Mode: If you touch the MODE key again, the fan will switch to the sleep wind mode, and the SPL indicator light will remain on.
- c.** Return to Normal Mode: Touch the MODE key once more to return to the normal mode, where the NOR normal wind indicator light will remain on. This cycle will repeat.

Lighting Control

1. To activate the light, press the LIGHT switch. The bulb will emit a soft light.
2. Press it again to brighten the light, and press once more to turn it off.
3. The lighting indicator operates independently of the power control and will continue to function even when the fan is off.

Energy Saving Mode

1. After 5 seconds of inactivity, the fan will display the current ambient temperature on its status screen.
2. The fan's display will automatically dim, reducing its brightness to save energy.

Safety Precautions

1. **Keep Away from Water:** Do not place the fan near water or in areas with high humidity to avoid electric shock or malfunction.
2. **Proper Placement:** Ensure the fan is placed on a flat, stable surface to prevent it from tipping over.
3. **Avoid Blocking Airflow:** Ensure that the air intake and outlet are not obstructed to maintain optimal performance and prevent overheating.
4. **Unplug After Use:** Always unplug the fan when not in use, especially before cleaning or when leaving the room for extended periods.
5. **Keep Away from Children:** Keep the fan out of reach of children and pets to avoid accidents, especially with moving parts.
6. **Do Not Insert Objects:** Never insert any objects into the fan's air vents or moving parts to avoid damage or injury.

- 7. Regular Cleaning:** Clean the fan regularly, but ensure it is unplugged before doing so. Use a dry cloth to wipe the surface and avoid using water or cleaning products that may damage the electrical components.
- 8. Power Cord Handling:** Ensure that the power cord is not pinched, damaged, or stretched. Avoid placing the fan where the cord may be tripped over.
- 9. Check for Overheating:** If the fan becomes unusually hot or malfunctions, turn it off and unplug it immediately for inspection.
- 10.** Only use the fan for its intended purpose as specified in the user manual.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**